for the Embedded C Developer

Quentin Ochem Robert Tice Gustavo A. Hoffmann Patrick Rogers



Aca



Ada for the Embedded C Developer

Release 2025-06

Quentin Ochem and Robert Tice and Gustavo A. Hoffmann and Patrick Rogers.

Jun 27, 2025

CONTENTS

1	I ntroduction 1.1 So, what is this Ada thing anyway?	3 3 5
2	 2.7 Packages	7 778901111122392333694455399664
3	3.1Understanding the various options3.2Tasks3.3Rendezvous	67 70 71 74
4	4.1 Understanding the Ada Run-Time	81 81 82

	4.3 4.4 [4.5] 4.6 2 2 2 2 2	4.2.1 Repres 4.2.2 Embed Interrupt Han Dealing with Volatile and A 4.5.1 Volatile 4.5.2 Atomic Interfacing wi 4.6.1 Size a 4.6.2 Regist 4.6.3 Data s ARM and svd	dded Asseml dling Absence of F atomic data . e e th Devices . ispect and a er overlays . treams	PU with Fiz	xed Point		· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · ·		· · · · · · · · · · · · · · · · · · ·	. 83 . 84 . 90 . 91 . 93 . 94 . 95 . 96 . 99
5	5.1 (5.2 (5.3 (5.4 (5.5 (5.6 (5.6 (5.7 (ncing Verific Understandin Understandin Initialization a Contract-Base Replacing De Proving Abser Proving Abser Final Commen	g Exceptions g Dynamic (and Correct l ed Programm fensive Code nce of Run-T act Propertie	s and Dyna Checks ver Data Flow ning ime Errors	amic Che sus Form	al Proof	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · ·	· · · · · · · · · · · ·	· · · ·	· · · · · · · · · · · ·	. 112 . 115 . 116 . 119 . 121 . 122
6	6.1 1 6.2 1 6.3 1 6.3 1 6.4 4 6.5 1 6.6 1 6.7 1 6.8 1 6.9 1 6.10 1	Ada Transla Naming conv Manually inte Building and Automatic int Using Arrays By-value vs. I Naming and p Pointers Bitwise Opera Mapping Stru 6.10.1 Overla	entions and rfacing C an Debugging r erfacing in C interfac by-reference prefixes ations ctures to Bit	casing con d Ada nixed lang es types -Fields	uage coc	le	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · ·		· · · · · · · · · · · ·	. 125 . 127 . 128 . 128 . 130 . 131 . 131 . 132 . 135 . 138
7	7.1 U 7.2 H 7.3 H	Handling vari 7.3.1 Record 7.3.2 Varian 7.3.2.1 7.3.2.2 7.3.2.3 7.3.3 Object 7.3.3.1 7.3.3.2 7.3.3.2 7.3.3.3 7.3.3.4 7.3.3.5 7.3.3.6 7.3.3.7 7.3.3.8	g static and ability & reu icity a derivation uration prag uration pack ability & reu ds with discri- t records Variant reco Optional co Optional ou	dynamic v sability sta ma files cages sability dyn minants ords and ur mponents tput inform subprogram untagged calls m multiple gged types e derivation	ariability itically namically namically nation nation and tagg	y						 . 155 . 155 . 158 . 164 . 166 . 170 . 170 . 172 . 174 . 176 . 176 . 180 . 180 . 181 . 185 . 185 . 185 . 187 . 188 . 190

	7.4	7.3.4 Pointer to subprograms	. 193 . 198
8	Perf 8.1 8.2 8.3 8.4 8.5	formance considerationsOverall expectationsSwitches and optimizations8.2.1 Optimizations levels8.2.2 InliningChecks and assertions8.3.1 Checks8.3.2 AssertionsDynamic vs. static structuresPointers vs. data copies8.5.1 Function returns	. 203 . 203 . 204 . 205 . 205 . 209 . 209 . 210
	9.1 9.2 9.3 9.4 9.5 9.6	umentation and Business PerspectivesWhat's the expected ROI of a C to Ada transition?Who is using Ada today?What is the future of the Ada technology?Is the Ada toolset complete?Where can I find Ada or SPARK developers?How to introduce Ada and SPARK in an existing code base?	. 218 . 218 . 219 . 219
10)Con	clusion	221
			~~ ~
11	11.1 11.2 11.3	Pendix A: Hands-On Object-Oriented ProgrammingSystem OverviewNon Object-Oriented Approach11.2.1 Starting point in C11.2.2 Initial translation to Ada11.2.3 Improved Ada implementation8 First Object-Oriented Approach11.3.1 Interfaces11.3.2 Base type11.3.3 Derived types11.3.4 Subprograms from parent11.3.5 Type AB11.3.6 Updated source-codeFurther Improvements11.4.1 Dispatching calls11.4.2 Dynamic allocation11.4.4 Updated source-code	225 226 229 233 237 237 237 238 239 240 240 244 244 244 245 246

Copyright © 2020 - 2024, AdaCore

This book is published under a CC BY-SA license, which means that you can copy, redistribute, remix, transform, and build upon the content for any purpose, even commercially, as long as you give appropriate credit, provide a link to the license, and indicate if changes were made. If you remix, transform, or build upon the material, you must distribute your contributions under the same license as the original. You can find license details on this page¹



This course introduces you to the Ada language by comparing it to C. It assumes that you have good knowledge of the C language. It also assumes that the choice of learning Ada is guided by considerations linked to reliability, safety or security. In that sense, it teaches you Ada paradigms that should be applied in replacement of those usually applied in C.

This course also introduces you to the SPARK subset of the Ada programming language, which removes a few features of the language with undefined behavior, so that the code is fit for sound static analysis techniques.

This course was written by Quentin Ochem, Robert Tice, Gustavo A. Hoffmann, and Patrick Rogers and reviewed by Patrick Rogers, Filip Gajowniczek, and Tucker Taft.

1 Note

The code examples in this course use an 80-column limit, which is a typical limit for Ada code. Note that, on devices with a small screen size, some code examples might be difficult to read.

1 Note

Each code example from this book has an associated "code block metadata", which contains the name of the "project" and an MD5 hash value. This information is used to identify a single code example.

You can find all code examples in a zip file, which you can download from the learn website². The directory structure in the zip file is based on the code block metadata. For example, if you're searching for a code example with this metadata:

- Project: Courses.Intro_To_Ada.Imperative_Language.Greet
- MD5: cba89a34b87c9dfa71533d982d05e6ab

you will find it in this directory:

projects/Courses/Intro_To_Ada/Imperative_Language/Greet/ cba89a34b87c9dfa71533d982d05e6ab/

In order to use this code example, just follow these steps:

- 1. Unpack the zip file;
- 2. Go to target directory;

¹ http://creativecommons.org/licenses/by-sa/4.0

- 3. Start GNAT Studio on this directory;
- 4. Build (or compile) the project;
- 5. Run the application (if a main procedure is available in the project).

² https://learn.adacore.com/zip/learning-ada_code.zip

INTRODUCTION

1.1 So, what is this Ada thing anyway?

To answer this question let's introduce Ada as it compares to C for an embedded application. C developers are used to a certain coding semantic and style of programming. Especially in the embedded domain, developers are used to working at a very low level near the hardware to directly manipulate memory and registers. Normal operations involve mathematical operations on pointers, complex bit shifts, and logical bitwise operations. C is well designed for such operations as it is a low level language that was designed to replace assembly language for faster, more efficient programming. Because of this minimal abstraction, the programmer has to model the data that represents the problem they are trying to solve using the language of the physical hardware.

Let's look at an example of this problem in action by comparing the same program in Ada and C:

[C]

Listing 1: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   #define DEGREES MAX
                                     (360)
4
   typedef unsigned int degrees;
5
6
   #define MOD DEGREES(x)
                              (x % DEGREES MAX)
7
8
   degrees add_angles(degrees* list, int length)
9
10
   {
      degrees sum = 0;
11
      for(int i = 0; i < length; ++i) {</pre>
12
        sum += list[i];
13
      }
14
15
      return sum;
16
   }
17
18
   int main(int argc, char** argv)
19
20
   {
      degrees list[argc - 1];
21
22
      for(int i = 1; i < argc; ++i) {</pre>
23
        list[i - 1] = MOD_DEGREES(atoi(argv[i]));
24
      }
25
26
      printf("Sum: %d\n", add_angles(list, argc - 1));
27
28
```

return 0; 29 }

30

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Introduction.Add_Angles_C
MD5: a6d184caaec372c538634c578b5e144b
```

Runtime output

Sum: 0

[Ada]

Listing 2: sum angles.adb

```
with Ada.Command Line; use Ada.Command Line;
1
   with Ada.Text_I0; use Ada.Text_I0;
2
3
   procedure Sum Angles is
4
5
      DEGREES MAX : constant := 360;
6
       type Degrees is mod DEGREES_MAX;
7
8
       type Degrees List is array (Natural range <>) of Degrees;
9
10
       function Add Angles (List : Degrees List) return Degrees
11
       is
12
          Sum : Degrees := 0;
13
      begin
14
          for I in List'Range loop
15
             Sum := Sum + List (I);
16
          end loop;
17
18
          return Sum;
19
      end Add Angles;
20
21
      List : Degrees List (1 .. Argument Count);
22
   begin
23
       for I in List'Range loop
24
          List (I) := Degrees (Integer'Value (Argument (I)));
25
      end loop;
26
27
       Put_Line ("Sum:" & Add_Angles (List)'Img);
28
29
   end Sum_Angles;
```

Code block metadata

Project: Courses.Ada For Embedded C Dev.Introduction.Add Angles Ada MD5: b5a446e5c27aa18c917ae8c2cc6c1605

Runtime output

Sum: 0

Here we have a piece of code in C and in Ada that takes some numbers from the command line and stores them in an array. We then sum all of the values in the array and print the result. The tricky part here is that we are working with values that model an angle in degrees. We know that angles are modular types, meaning that angles greater than 360° can also be represented as Angle mod 360. So if we have an angle of 400° , this is equivalent to 40°. In order to model this behavior in C we had to create the MOD DEGREES macro, which performs the modulus operation. As we read values from the command line, we convert them to integers and perform the modulus before storing them into the array. We then call add_angles which returns the sum of the values in the array. Can you spot the problem with the C code?

Try running the Ada and C examples using the input sequence 340 2 50 70. What does the C program output? What does the Ada program output? Why are they different?

The problem with the C code is that we forgot to call MOD_DEGREES in the for loop of add_angles. This means that it is possible for add_angles to return values greater than DEGREES_MAX. Let's look at the equivalent Ada code now to see how Ada handles the situation. The first thing we do in the Ada code is to create the type Degrees which is a modular type. This means that the compiler is going to handle performing the modulus operation for us. If we use the same for loop in the Add_Angles function, we can see that we aren't doing anything special to make sure that our resulting value is within the 360° range we need it to be in.

The takeaway from this example is that Ada tries to abstract some concepts from the developer so that the developer can focus on solving the problem at hand using a data model that models the real world rather than using data types prescribed by the hardware. The main benefit of this is that the compiler takes some responsibility from the developer for generating correct code. In this example we forgot to put in a check in the C code. The compiler inserted the check for us in the Ada code because we told the compiler what we were trying to accomplish by defining strong types.

Ideally, we want all the power that the C programming language can give us to manipulate the hardware we are working on while also allowing us the ability to more accurately model data in a safe way. So, we have a dilemma; what can give us the power of operations like the C language, but also provide us with features that can minimize the potential for developer error? Since this course is about Ada, it's a good bet we're about to introduce the Ada language as the answer to this question...

Unlike C, the Ada language was designed as a higher level language from its conception; giving more responsibility to the compiler to generate correct code. As mentioned above, with C, developers are constantly shifting, masking, and accessing bits directly on memory pointers. In Ada, all of these operations are possible, but in most cases, there is a better way to perform these operations using higher level constructs that are less prone to mistakes, like off-by-one or unintentional buffer overflows. If we were to compare the same application written using C and with Ada using high level constructs, we would see similar performance in terms of speed and memory efficiency. If we compare the object code generated by both compilers, it's possible that they even look identical!

1.2 Ada — The Technical Details

Like C, Ada is a compiled language. This means that the compiler will parse the source code and emit machine code native to the target hardware. The Ada compiler we will be discussing in this course is the GNAT compiler. This compiler is based on the GCC technology like many C and C++ compilers available. When the GNAT compiler is invoked on Ada code, the GNAT front-end expands and translates the Ada code into an intermediate language which is passed to GCC where the code is optimized and translated to machine code. A C compiler based on GCC performs the same steps and uses the same intermediate GCC representation. This means that the optimizations we are used to seeing with a GCC based C compiler can also be applied to Ada code. The main difference between the two compilers is that the Ada compiler is expanding high level constructs into intermediate code. After expansion, the Ada code will be very similar to the equivalent C code.

It is possible to do a line-by-line translation of C code to Ada. This feels like a natural step for a developer used to C paradigms. However, there may be very little benefit to doing so. For the purpose of this course, we're going to assume that the choice of Ada over C is guided by considerations linked to reliability, safety or security. In order to improve upon the reliability, safety and security of our application, Ada paradigms should be applied in replacement of those usually applied in C. Constructs such as pointers, preprocessor macros, bitwise operations and defensive code typically get expressed in Ada in very different ways, improving the overall reliability and readability of the applications. Learning these new ways of coding, often, requires effort by the developer at first, but proves more efficient once the paradigms are understood.

In this course we will also introduce the SPARK subset of the Ada programming language. The SPARK subset removes a few features of the language, i.e., those that make proof difficult, such as pointer aliasing. By removing these features we can write code that is fit for sound static analysis techniques. This means that we can run mathematical provers on the SPARK code to prove certain safety or security properties about the code.

THE C DEVELOPER'S PERSPECTIVE ON ADA

2.1 What we mean by Embedded Software

The Ada programming language is a general programming language, which means it can be used for many different types of applications. One type of application where it particularly shines is reliable and safety-critical embedded software; meaning, a platform with a microprocessor such as ARM, PowerPC, x86, or RISC-V. The application may be running on top of an embedded operating system, such as an embedded Linux, or directly on bare metal. And the application domain can range from small entities such as firmware or device controllers to flight management systems, communication based train control systems, or advanced driver assistance systems.

2.2 The GNAT Toolchain

The toolchain used throughout this course is called GNAT, which is a suite of tools with a compiler based on the GCC environment. It can be obtained from AdaCore, either as part of a commercial contract with GNAT Pro³ or at no charge with the GNAT Community edition⁴. The information in this course will be relevant no matter which edition you're using. Most examples will be runnable on the native Linux or Windows version for convenience. Some will only be relevant in the context of a cross toolchain, in which case we'll be using the embedded ARM bare metal toolchain.

As for any Ada compiler, GNAT takes advantage of implementation permissions and offers a project management system. Because we're talking about embedded platforms, there are a lot of topics that we'll go over which will be specific to GNAT, and sometimes to specific platforms supported by GNAT. We'll try to make the distinction between what is GNAT-specific and Ada generic as much as possible throughout this course.

For an introduction to the GNAT Toolchain for the GNAT Community edition, you may refer to the Introduction to GNAT Toolchain course.

2.3 The GNAT Toolchain for Embedded Targets

When we're discussing embedded programming, our target device is often different from the host, which is the device we're using to actually write and build an application. In this case, we're talking about cross compilation platforms (concisely referred to as cross platforms).

The GNAT toolchain supports cross platform compilation for various target devices. This section provides a short introduction to the topic. For more details, please refer to the GNAT User's Guide Supplement for Cross Platforms⁵

³ https://www.adacore.com/gnatpro

⁴ https://www.adacore.com/community

⁵ https://docs.adacore.com/gnat_ugx-docs/html/gnat_ugx/gnat_ugx.html

GNAT supports two types of cross platforms:

- cross targets, where the target device has an embedded operating system.
 - ARM-Linux, which is commonly found in a Raspberry-Pi, is a prominent example.
- **bareboard targets**, where the run-times do not depend on an operating system.
 - In this case, the application has direct access to the system hardware.

For each platform, a set of run-time libraries is available. Run-time libraries implement a subset of the Ada language for different use cases, and they're different for each target platform. They may be selected via an attribute in the project's GPR project file or as a command-line switch to **GPRbuild**. Although the run-time libraries may vary from target to target, the user interface stays the same, providing portability for the application.

Run-time libraries consists of:

- 1. Files that are dependent on the target board.
 - These files are responsible for configuring and interacting with the hardware.
 - They are known as a Board Support Package commonly referred to by their abbrevation BSP.
- 2. Code that is target-independent.
 - This code implements language-defined functionality.

The bareboard run-time libraries are provided as customized run-times that are configured to target a very specific micro-controller or processor. Therefore, for different microcontrollers and processors, the run-time libraries need to be ported to the specific target. These are some examples of what needs to be ported:

- startup code / scripts;
- clock frequency initializations;
- memory mapping / allocation;
- interrupts and interrupt priorities;
- register descriptions.

For more details on the topic, please refer to the following chapters of the GNAT User's Guide Supplement for Cross Platforms⁶:

- Bareboard Topics⁷
- Customized Run-Time Libraries⁸

2.4 Hello World in Ada

The first piece of code to translate from C to Ada is the usual Hello World program:

[C]

1 2

5

Listing 1: main.c

```
#include <stdio.h>
  int main(int argc, const char * argv[])
3
4
   {
       printf("Hello World\n");
```

⁶ https://docs.adacore.com/gnat_ugx-docs/html/gnat_ugx/gnat_ugx.html

⁷ http://docs.adacore.com/live/wave/gnat_ugx/html/gnat_ugx/gnat_ugx/bareboard_topics.html

⁸ http://docs.adacore.com/live/wave/gnat_ugx/html/gnat_ugx/gnat_ugx/customized_run-time_libraries.html

6 return 0;
7 }

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Hello_World_C
MD5: 59685c72296a032893cda71dade24196
```

Runtime output

Hello World

[Ada]

Listing 2: hello_world.adb

```
with Ada.Text_I0;
procedure Hello_World
s
begin
Ada.Text_I0.Put_Line ("Hello World");
end Hello World;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Hello_World_Ada
MD5: f1a7c6a4fd679c4caea7ee31d14aab2e
```

Runtime output

Hello World

The resulting program will print Hello World on the screen. Let's now dissect the Ada version to describe what is going on:

The first line of the Ada code is giving us access to the Ada.Text_I0 library which contains the Put_Line function we will use to print the text to the console. This is similar to C's *#include <stdio.h>*. We then create a procedure which executes Put_Line which prints to the console. This is similar to C's printf function. For now, we can assume these Ada and C features have similar functionality. In reality, they are very different. We will explore that more as we delve further into the Ada language.

You may have noticed that the Ada syntax is more verbose than C. Instead of using braces {} to declare scope, Ada uses keywords. **is** opens a declarative scope — which is empty here as there's no variable to declare. **begin** opens a sequence of statements. Within this sequence, we're calling the function Put_Line, prefixing explicitly with the name of the library unit where it's declared, Ada.Text_I0. The absence of the end of line \n can also be noted, as Put_Line always terminates by an end of line.

2.5 The Ada Syntax

Ada syntax might seem peculiar at first glance. Unlike many other languages, it's not derived from the popular C style of notation with its ample use of brackets; rather, it uses a more expository syntax coming from Pascal. In many ways, Ada is a more explicit language — its syntax was designed to increase readability and maintainability, rather than making it faster to write in a condensed manner. For example:

• full words like **begin** and **end** are used in place of curly braces.

- Conditions are written using if, then, elsif, else, and end if.
- Ada's assignment operator does not double as an expression, eliminating potential mistakes that could be caused by = being used where == should be.

All languages provide one or more ways to express comments. In Ada, two consecutive hyphens -- mark the start of a comment that continues to the end of the line. This is exactly the same as using // for comments in C. Multi line comments like C's /* */ do not exist in Ada.

Ada compilers are stricter with type and range checking than most C programmers are used to. Most beginning Ada programmers encounter a variety of warnings and error messages when coding, but this helps detect problems and vulnerabilities at compile time — early on in the development cycle. In addition, checks (such as array bounds checks) provide verification that could not be done at compile time but can be performed either at runtime, or through formal proof (with the SPARK tooling).

Ada identifiers and reserved words are case insensitive. The identifiers VAR, var and VaR are treated as the same identifier; likewise **begin**, **BEGIN**, **Begin**, etc. Identifiers may include letters, digits, and underscores, but must always start with a letter. There are 73 reserved keywords in Ada that may not be used as identifiers, and these are:

abort	else	null	select
abs	elsif	of	separate
abstract	end	or	some
accept	entry	others	subtype
access	exception	out	synchronized
aliased	exit	overriding	tagged
all	for	package	task
and	function	pragma	terminate
array	generic	private	then
at	goto	procedure	type
begin	if	protected	until
body	in	raise	use
case	interface	range	when
constant	is	record	while
declare	limited	rem	with
delay	loop	renames	xor
delta	mod	requeue	
digits	new	return	
do	not	reverse	

2.6 Compilation Unit Structure

Both C and Ada were designed with the idea that the code specification and code implementation could be separated into two files. In C, the specification typically lives in the .h, or header file, and the implementation lives in the .c file. Ada is superficially similar to C. With the GNAT toolchain, compilation units are stored in files with an .ads extension for specifications and with an .adb extension for implementations.

One main difference between the C and Ada compilation structure is that Ada compilation units are structured into something called packages.

2.7 Packages

The package is the basic modularization unit of the Ada language, as is the class for Java and the header and implementation pair for C. A specification defines a package and the implementation implements the package. We saw this in an earlier example when we included the Ada.Text_IO package into our application. The package specification has the structure:

[Ada]

```
-- my_package.ads
package My_Package is
    -- public declarations
private
    -- private declarations
end My Package;
```

The package implementation, or body, has the structure:

```
-- my_package.adb
package body My_Package is
    -- implementation
end My_Package;
```

2.7.1 Declaration Protection

An Ada package contains three parts that, for GNAT, are separated into two files: .ads files contain public and private Ada specifications, and .adb files contain the implementation, or Ada bodies.

[Ada]

```
package Package_Name is
    -- public specifications
private
    -- private specifications
end Package_Name;
```

```
package body Package_Name is
    -- implementation
end Package_Name;
```

Private types are useful for preventing the users of a package's types from depending on the types' implementation details. Another use-case is the prevention of package users from accessing package state/data arbitrarily. The private reserved word splits the package spec into *public* and *private* parts. For example:

[Ada]

Listing 3: types.ads

```
1 package Types is
2 type Type_1 is private;
3 type Type_2 is private;
4 type Type_3 is private;
```

```
procedure P (X : Type_1);
5
6
      - -
   private
7
      procedure Q (Y : Type_1);
8
      type Type_1 is new Integer range 1 .. 1000;
9
      type Type_2 is array (Integer range 1 .. 1000) of Integer;
10
      type Type_3 is record
11
         A, B : Integer;
12
      end record;
13
  end Types;
14
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Private_Types
MD5: ae4a9e4d10b55e7efd92d7952ba22f4f
```

Subprograms declared above the **private** separator (such as P) will be visible to the package user, and the ones below (such as Q) will not. The body of the package, the implementation, has access to both parts. A package specification does not require a private section.

2.7.2 Hierarchical Packages

Ada packages can be organized into hierarchies. A child unit can be declared in the following way:

[Ada]

```
-- root-child.ads
package Root.Child is
    -- package spec goes here
end Root.Child;
-- root-child.adb
package body Root.Child is
    -- package body goes here
end Root.Child;
```

Here, Root.Child is a child package of Root. The public part of Root.Child has access to the public part of Root. The private part of Child has access to the private part of Root, which is one of the main advantages of child packages. However, there is no visibility relationship between the two bodies. One common way to use this capability is to define subsystems around a hierarchical naming scheme.

2.7.3 Using Entities from Packages

Entities declared in the visible part of a package specification can be made accessible using a **with** clause that references the package, which is similar to the C *#include* directive. After a **with** clause makes a package available, references to the package contents require the name of the package as a prefix, with a dot after the package name. This prefix can be omitted if a **use** clause is employed.

[Ada]

Listing 4: pck.ads

```
1 -- pck.ads
2
3 package Pck is
4 My_Glob : Integer;
5 end Pck;
```

Listing 5: main.adb

```
1 -- main.adb
2
3 with Pck;
4
5 procedure Main is
6 begin
7 Pck.My_Glob := 0;
8 end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Using_Pkg_Entities
MD5: 4215ba710eb54478538dc001bb74ce09
```

In contrast to C, the Ada with clause is a *semantic inclusion* mechanism rather than a *text inclusion* mechanism; for more information on this difference please refer to Packages.

2.8 Statements and Declarations

The following code samples are all equivalent, and illustrate the use of comments and working with integer variables:

[C]

Listing 6: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        // variable declarations
5
        int a = 0, b = 0, c = 100, d;
6
7
        // c shorthand for increment
8
        a++;
9
10
        // regular addition
11
        d = a + b + c;
12
13
        // printing the result
14
        printf("d = %d\n", d);
15
16
        return 0;
17
   }
18
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Var_Decl_C
MD5: ba258dac5c052a97da475239e2f2ce96
```

Runtime output

d = 101

[Ada]

Listing 7: main.adb

```
with Ada.Text I0;
1
2
   procedure Main
3
   is
4
       -- variable declaration
5
      A, B : Integer := 0;
6
          : Integer := 100;
      C
7
      D
           : Integer;
8
   begin
9
      -- Ada does not have a shortcut format for increment like in C
10
      A := A + 1;
11
12
      -- regular addition
13
      D := A + B + C;
14
15
      -- printing the result
16
      Ada.Text IO.Put Line ("D =" & D'Img);
17
   end Main;
18
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Var_Decl_Ada
MD5: eaff76f36d5f938bd806d29048df7865

Runtime output

D = 101

You'll notice that, in both languages, statements are terminated with a semicolon. This means that you can have multi-line statements.

1 The shortcuts of incrementing and decrementing

You may have noticed that Ada does not have something similar to the a_{++} or a_{--} operators. Instead you must use the full assignment A := A + 1 or A := A - 1.

In the Ada example above, there are two distinct sections to the **procedure** Main. This first section is delimited by the **is** keyword and the **begin** keyword. This section is called the declarative block of the subprogram. The declarative block is where you will define all the local variables which will be used in the subprogram. C89 had something similar, where developers were required to declare their variables at the top of the scope block. Most C developers may have run into this before when trying to write a for loop:

[C]

Listing 8: main.c

```
1 /* The C89 version */
2
3 #include <stdio.h>
4
5 int average(int* list, int length)
6 {
7 int i;
```

```
int sum = 0;
8
9
        for(i = 0; i < length; ++i) {</pre>
10
             sum += list[i];
11
12
        }
        return (sum / length);
13
   }
14
15
   int main(int argc, const char * argv[])
16
   {
17
        int vals[] = { 2, 2, 4, 4 };
18
19
        printf("Average: %d\n", average(vals, 4));
20
21
        return 0;
22
   }
23
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Average_C89
MD5: 5c89aa28cba0bae4d963b235c53aedf2
```

Runtime output

```
Average: 3
```

[C]

Listing 9: main.c

```
// The modern C way
1
2
   #include <stdio.h>
3
4
   int average(int* list, int length)
5
   {
6
        int sum = 0;
7
8
        for(int i = 0; i < length; ++i) {</pre>
9
             sum += list[i];
10
        }
11
12
        return (sum / length);
13
   }
14
15
   int main(int argc, const char * argv[])
16
   {
17
        int vals[] = { 2, 2, 4, 4 };
18
19
        printf("Average: %d\n", average(vals, 4));
20
21
        return 0;
22
   }
23
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Average_C_Modern
MD5: 6354863137d78adb974743915d1d4530
```

Runtime output

Average: 3

For the fun of it, let's also see the Ada way to do this: [Ada]

Listing 10: main.adb

```
with Ada.Text_I0;
1
2
   procedure Main is
3
      type Int_Array is array (Natural range <>) of Integer;
4
5
      function Average (List : Int_Array) return Integer
6
      is
7
          Sum : Integer := 0;
8
      begin
9
          for I in List'Range loop
10
             Sum := Sum + List (I);
11
          end loop;
12
13
          return (Sum / List'Length);
14
15
      end Average;
16
      Vals : constant Int_Array (1 .. 4) := (2, 2, 4, 4);
17
   begin
18
      Ada.Text_IO.Put_Line ("Average: " & Integer'Image (Average (Vals)));
19
   end Main;
20
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Average_Ada
MD5: 52abb574d7a8b3bdb56715735dcd1d54

Runtime output

Average: 3

We will explore more about the syntax of loops in Ada in a future section of this course; but for now, notice that the I variable used as the loop index is not declared in the declarative section!

1 Declaration Flippy Floppy

Something peculiar that you may have noticed about declarations in Ada is that they are backwards from the way C does declarations. The C language expects the type followed by the variable name. Ada expects the variable name followed by a colon and then the type.

The next block in the Ada example is between the **begin** and **end** keywords. This is where your statements will live. You can create new scopes by using the **declare** keyword:

[Ada]

Listing 11: main.adb

```
with Ada.Text_I0;
    procedure Main
    is
```

```
-- variable declaration
5
      A, B : Integer := 0;
6
      С
           : Integer := 100;
7
      D
           : Integer;
8
   begin
9
      -- Ada does not have a shortcut format for increment like in C
10
      A := A + 1;
11
12
       -- regular addition
13
      D := A + B + C;
14
15
       -- printing the result
16
      Ada.Text_IO.Put_Line ("D =" & D'Img);
17
18
      declare
19
        E : constant Integer := D * 100;
20
      begin
21
             printing the result
22
          - -
         Ada.Text_IO.Put_Line ("E =" & E'Img);
23
      end;
24
25
   end Main;
26
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Var_Decl_Block_Ada
MD5: 9239b993a7eadb13a27bd3618a03431f

Runtime output

 $D = 101 \\ E = 10100$

Notice that we declared a new variable E whose scope only exists in our newly defined block. The equivalent C code is:

[C]

Listing 12: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
        // variable declarations
5
        int a = 0, b = 0, c = 100, d;
6
7
        // c shorthand for increment
8
9
        a++;
10
        // regular addition
11
        d = a + b + c;
12
13
        // printing the result
14
        printf("d = %d\n", d);
15
16
        {
17
            const int e = d * 100;
18
            printf("e = %d\n", e);
19
        }
20
21
```

return 0; 22 }

23

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Var_Decl_Block_C
MD5: 1a837795575ddc026738d92c8655ab6c
```

Runtime output

d = 101e = 10100

Fun Fact about the C language assignment operator =: Did you know that an assignment in C can be used in an expression? Let's look at an example:

[C]

Listing 13: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        int a = 0;
5
6
        if (a = 10)
7
            printf("True\n");
8
        else
9
            printf("False\n");
10
11
        return 0;
12
   }
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Equal_C MD5: 2d00ddf7e154cb888082c86b8fd36c58

Runtime output

True

Run the above code example. What does it output? Is that what you were expecting?

The author of the above code example probably meant to test if a = 10 in the if statement but accidentally typed = instead of ==. Because C treats assignment as an expression, it was able to evaluate a = 10.

Let's look at the equivalent Ada code:

[Ada]

Listing 14: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Main
З
   is
4
      A : Integer := 0;
5
   begin
6
```

```
8 if A := 10 then
9 Put_Line ("True");
10 else
11 Put_Line ("False");
12 end if;
13 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Equal_Ada
MD5: 1500b264531dfcc7a62eeed2f22f511b

The above code will not compile. This is because Ada does no allow assignment as an expression.

1 The "use" clause

You'll notice in the above code example, after **with** Ada.Text_I0; there is a new statement we haven't seen before — **use** Ada.Text_I0;. You may also notice that we are not using the Ada.Text_I0 prefix before the Put_Line statements. When we add the use clause it tells the compiler that we won't be using the prefix in the call to subprograms of that package. The use clause is something to use with caution. For example: if we use the Ada.Text_I0 package and we also have a Put_Line subprogram in our current compilation unit with the same signature, we have a (potential) collision!

2.9 Conditions

The syntax of an if statement:

[C]

Listing 15: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        // try changing the initial value to change the
5
        // output of the program
6
        int v = 0;
7
8
        if (v > 0) {
9
            printf("Positive\n");
10
        }
11
        else if (v < 0) {
12
            printf("Negative\n");
13
        }
14
        else {
15
            printf("Zero\n");
16
        }
17
18
        return 0;
19
   }
20
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Condition_C
MD5: 69203e679085e73394d3620a5954262a
```

Runtime output

Zero

[Ada]

Listing 16: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Main
3
4
   is
          try changing the initial value to change the
5
       - -
             output of the program
6
       - -
       V : constant Integer := 0;
7
   begin
8
       if V > 0 then
9
          Put Line ("Positive");
10
       elsif \overline{V} < 0 then
11
          Put_Line ("Negative");
12
       else
13
          Put_Line ("Zero");
14
       end if;
15
   end Main;
16
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Condition_Ada
MD5: 417e557708472f9022db7d8c1ed6aa33
```

Runtime output

Zero

In Ada, everything that appears between the **if** and **then** keywords is the conditional expression, no parentheses are required. Comparison operators are the same except for:

Operator	С	Ada
Equality	==	=
Inequality	! =	/=
Not	!	not
And	&&	and
Or		or

The syntax of a switch/case statement: [C]

Listing 17: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
       // try changing the initial value to change the
5
       // output of the program
6
       int v = 0;
7
8
       switch(v) {
9
           case 0:
10
```

```
printf("Zero\n");
11
                 break;
12
            case 1: case 2: case 3: case 4: case 5:
13
            case 6: case 7: case 8: case 9:
14
                printf("Positive\n");
15
                 break;
16
            case 10: case 12: case 14: case 16: case 18:
17
                 printf("Even number between 10 and 18\n");
18
                 break;
19
            default:
20
                 printf("Something else\n");
21
                 break;
22
        }
23
24
        return 0;
25
   }
26
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Switch_Case_C
MD5: 1bdb3d0c151d71280ef9039841f7ee58
```

Runtime output

Zero

[Ada]

Listing 18: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
3
   procedure Main
4
   is
          try changing the initial value to change the
5
       - -
            output of the program
       - -
6
      V : constant Integer := 0;
7
   begin
8
      case V is
9
         when 0 =>
10
             Put Line ("Zero");
11
         when 1 .. 9 =>
12
             Put Line ("Positive");
13
         when 10 | 12 | 14 | 16 | 18 =>
14
             Put_Line ("Even number between 10 and 18");
15
         when others =>
16
             Put Line ("Something else");
17
      end case;
18
   end Main;
19
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Switch_Case_Ada
MD5: 09e2318b56069281c95f23310dc121d1
```

Runtime output

Zero

1 Switch or Case?

A switch statement in C is the same as a case statement in Ada. This may be a little strange because C uses both keywords in the statement syntax. Let's make an analogy between C and Ada: C's **switch** is to Ada's **case** as C's **case** is to Ada's **when**.

Notice that in Ada, the case statement does not use the **break** keyword. In C, we use **break** to stop the execution of a case branch from falling through to the next branch. Here is an example:

[C]

Listing 19: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
        int v = 0;
5
6
        switch(v) {
7
            case 0:
8
                 printf("Zero\n");
9
            case 1:
10
                 printf("One\n");
11
            default:
12
                 printf("Other\n");
13
        }
14
15
        return 0;
16
   }
17
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Switch_Case_Break_C
MD5: fd0389205476f161655caf32244d9054

Runtime output

Zero		
Zero One Other		
Other		

Run the above code with v = 0. What prints? What prints when we change the assignment to v = 1?

When v = 0 the program outputs the strings Zero then One then Other. This is called fall through. If you add the **break** statements back into the **switch** you can stop this fall through behavior from happening. The reason why fall through is allowed in C is to allow the behavior from the previous example where we want a specific branch to execute for multiple inputs. Ada solves this a different way because it is possible, or even probable, that the developer might forget a **break** statement accidentally. So Ada does not allow fall through. Instead, you can use Ada's syntax to identify when a specific branch can be executed by more than one input. If you want a range of values for a specific branch you can use the First .. Last notation. If you want a few non-consecutive values you can use the Value1 | Value2 | Value3 notation.

Instead of using the word **default** to denote the catch-all case, Ada uses the **others** keyword.

2.10 Loops

Let's start with some syntax:

[C]

Listing 20: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
    {
        int v;
5
6
        // this is a while loop
7
        v = 1;
8
9
        while(v < 100) {
10
            v *= 2;
        }
11
        printf("v = %d\n", v);
12
13
        // this is a do while loop
14
        v = 1;
15
        do {
16
             v *= 2;
17
        } while(v < 200);</pre>
18
        printf("v = %d\n", v);
19
20
        // this is a for loop
21
        v = 0;
22
        for(int i = 0; i < 5; ++i) {</pre>
23
            v += (i * i);
24
        }
25
        printf("v = %d\n", v);
26
27
        // this is a forever loop with a conditional exit
28
        v = 0;
29
        while(1) {
30
            // do stuff here
31
            v += 1;
32
            if(v == 10)
33
                 break;
34
        }
35
        printf("v = %d\n", v);
36
37
        // this is a loop over an array
38
        {
39
            #define ARR_SIZE (10)
40
             const int arr[ARR_SIZE] = { 1, 2, 3, 4, 5, 6, 7, 8, 9, 10 };
41
            int sum = 0;
42
43
             for(int i = 0; i < ARR_SIZE; ++i) {</pre>
44
                 sum += arr[i];
45
             }
46
             printf("sum = %d\n", sum);
47
        }
48
49
        return 0;
50
   }
51
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loops_C MD5: bcd8963884e2b2a5e364219f9b6b8fbc

Runtime output

v = 128 v = 256 v = 30 v = 10sum = 55

[Ada]

Listing 21: main.adb

```
with Ada.Text_I0;
1
2
   procedure Main is
3
      V : Integer;
4
   begin
5
       -- this is a while loop
6
       V := 1;
7
       while V < 100 loop
8
         V := V * 2;
9
       end loop;
10
       Ada.Text_IO.Put_Line ("V = " & Integer'Image (V));
11
12
       -- Ada doesn't have an explicit do while loop
13
       -- instead you can use the loop and exit keywords
14
       V := 1;
15
       loop
16
          V := V * 2:
17
          exit when V \ge 200;
18
       end loop;
19
       Ada.Text IO.Put Line ("V = " & Integer'Image (V));
20
21
       -- this is a for loop
22
       V := 0;
23
       for I in 0 .. 4 loop
24
         V := V + (I * I);
25
       end loop;
26
       Ada.Text_IO.Put_Line ("V = " & Integer'Image (V));
27
28
       -- this is a forever loop with a conditional exit
29
       V := 0;
30
       loop
31
          -- do stuff here
32
          V := V + 1;
33
          exit when V = 10;
34
       end loop;
35
       Ada.Text_IO.Put_Line ("V = " & Integer'Image (V));
36
37
       -- this is a loop over an array
38
       declare
39
          type Int Array is array (Natural range 1 .. 10) of Integer;
40
41
          Arr : constant Int_Array := (1, 2, 3, 4, 5, 6, 7, 8, 9, 10);
42
          Sum : Integer := 0;
43
       begin
44
          for I in Arr'Range loop
45
             Sum := Sum + Arr (I);
46
          end loop;
47
```

```
Ada.Text_IO.Put_Line ("Sum = " & Integer'Image (Sum));
48
      end;
49
   end Main;
50
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loops_Ada MD5: c09a092f8d2f682ce758d4bf059b954a

Runtime output

V = 128 V = 256 V = 30 V = 10 Sum = 55

The loop syntax in Ada is pretty straightforward. The loop and end loop keywords are used to open and close the loop scope. Instead of using the **break** keyword to exit the loop, Ada has the exit statement. The exit statement can be combined with a logic expression using the **exit** when syntax.

The major deviation in loop syntax is regarding for loops. You'll notice, in C, that you sometimes declare, and at least initialize a loop counter variable, specify a loop predicate, or an expression that indicates when the loop should continue executing or complete, and last you specify an expression to update the loop counter.

[C]

```
for (initialization expression; loop predicate; update expression) {
    // some statements
}
```

In Ada, you don't declare or initialize a loop counter or specify an update expression. You only name the loop counter and give it a range to loop over. The loop counter is **read-only**! You cannot modify the loop counter inside the loop like you can in C. And the loop counter will increment consecutively along the specified range. But what if you want to loop over the range in reverse order?

[C]

2

4

5

7

9

Listing 22: main.c

```
#include <stdio.h>
1
   #define MY RANGE (10)
3
   int main(int argc, const char * argv[])
   {
6
        for (int i = MY_RANGE; i >= 0; --i) {
8
            printf("%d\n", i);
        }
10
11
        return 0;
12
   }
13
```

Code block metadata

```
Project: Courses.Ada For Embedded C Dev.Perspective.Loop Counter C
MD5: 4e70078ae51d113b8fa02340258c5ed5
```

Runtime output

1	
g	
8	
7	
6	
5	
4	
3	
4	

[Ada]

Listing 23: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Main
3
4
   is
      My_Range : constant := 10;
5
   begin
6
      for I in reverse 0 .. My_Range loop
7
         Put Line (I'Img);
8
      end loop;
9
   end Main;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loop_Counter_Ada
MD5: f25ed1a91c82620f16cd3084a6a0f475

Runtime output

0

1 Tick Image

Strangely enough, Ada people call the single apostrophe symbol, ', "tick". This "tick" says the we are accessing an attribute of the variable. When we do 'Img on a variable of a numerical type, we are going to return the string version of that numerical type. So in the for loop above, I'Img, or "I tick image" will return the string representation of the numerical value stored in I. We have to do this because Put_Line is expecting a string as an input parameter.

We'll discuss attributes in more details later in this chapter (page 42).

In the above example, we are traversing over the range in reverse order. In Ada, we use the **reverse** keyword to accomplish this.

In many cases, when we are writing a for loop, it has something to do with traversing an array. In C, this is a classic location for off-by-one errors. Let's see an example in action: [C]

```
Listing 24: main.c
```

```
#include <stdio.h>
1
2
   #define LIST LENGTH (100)
3
4
   int main(int argc, const char * argv[])
5
   {
6
        int list[LIST_LENGTH];
7
8
        for(int i = LIST LENGTH; i > 0; --i) {
9
             list[i] = LIST_LENGTH - i;
10
        }
11
12
        for (int i = 0; i < LIST_LENGTH; ++i)</pre>
13
14
        {
             printf("%d ", list[i]);
15
16
             if (i % 10 == 0) {
17
                 printf("\n");
18
             }
19
        }
20
21
        return 0;
22
   }
23
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loop_Reverse_C MD5: 710ce30066551d1aada8d4e98a6004b1

Runtime output

 0

 99
 98
 97
 96
 95
 94
 93
 92
 91
 90

 89
 88
 87
 86
 85
 84
 83
 82
 81
 80

 79
 78
 77
 76
 75
 74
 73
 72
 71
 70

 69
 68
 67
 66
 65
 64
 63
 62
 61
 60

 59
 58
 57
 56
 55
 54
 53
 52
 51
 50

 49
 48
 47
 46
 45
 44
 43
 42
 41
 40

 39
 38
 37
 36
 35
 34
 33
 32
 31
 30

 29
 28
 27
 26
 25
 24
 23
 22
 21
 20

 19
 18
 17
 16
 15
 14
 13
 12
 11
 10

 9
 8
 7
 6
 5
 4
 3
 2
 1

 </tbr>

[Ada]

Listing 25: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Main
is
type Int_Array is array (Natural range 1 .. 100) of Integer;
List : Int_Array;
begin
```

```
for I in reverse List'Range loop
10
          List (I) := List'Last - I;
11
       end loop;
12
13
       for I in List'Range loop
14
          Put (List (I)'Img & " ");
15
16
          if I mod 10 = 0 then
17
             New Line;
18
          end if;
19
       end loop;
20
21
22
   end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loop_Reverse_Ada
MD5: 340b935d42a80671bb050bdad1b032f7

Runtime output

99	98	97	96	95	94	93	92	91	90
89	88	87	86	85	84	83	82	81	80
79	78	77	76	75	74	73	72	71	70
69	68	67	66	65	64	63	62	61	60
59	58	57	56	55	54	53	52	51	50
49	48	47	46	45	44	43	42	41	40
39	38	37	36	35	34	33	32	31	30
29	28	27	26	25	24	23	22	21	20
19	18	17	16	15		-	12	11	10
9	87	6	5	4 3	2	1	0		

The above Ada and C code should initialize an array using a for loop. The initial values in the array should be contiguously decreasing from 99 to 0 as we index from the first index to the last index. In other words, the first index has a value of 99, the next has 98, the next 97 ... the last has a value of 0.

If you run both the C and Ada code above you'll notice that the outputs of the two programs are different. Can you spot why?

In the C code there are two problems:

- There's a buffer overflow in the first iteration of the loop. We would need to modify the loop initialization to int i = LIST_LENGTH - 1;. The loop predicate should be modified to i >= 0;
- 2. The C code also has another off-by-one problem in the math to compute the value stored in list[i]. The expression should be changed to be list[i] = LIST_LENGTH - i - 1;.

These are typical off-by-one problems that plagues C programs. You'll notice that we didn't have this problem with the Ada code because we aren't defining the loop with arbitrary numeric literals. Instead we are accessing attributes of the array we want to manipulate and are using a keyword to determine the indexing direction.

We can actually simplify the Ada for loop a little further using iterators:

[Ada]

Listing 26: main.adb

with Ada.Text_I0; use Ada.Text_I0;

2

```
procedure Main
3
   is
4
       type Int_Array is array (Natural range 1 .. 100) of Integer;
5
6
       List : Int_Array;
7
   begin
8
9
       for I in reverse List'Range loop
10
          List (I) := List'Last - I;
11
       end loop;
12
13
       for I of List loop
14
          Put (I'Img & " ");
15
16
          if I mod 10 = 0 then
17
             New Line;
18
          end if:
19
       end loop;
20
21
   end Main;
22
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loop_Reverse_Ada_Simplified
MD5: 612046826199b00ed61271d6215596fe

Runtime output

99	98	97	96	95	94	93	92	91	90
89	88	87	86	85	84	83	82	81	80
79	78	77	76	75	74	73	72	71	70
69	68	67	66	65	64	63	62	61	60
59	58	57	56	55	54	53	52	51	50
49	48	47	46	45	44	43	42	41	40
39	38	37	36	35	34	33	32	31	30
29	28	27	26	25	24	23	22	21	20
19	18	17	16	15	14	13	12	11	10
9	8 7	6	5	43	2	1	0		

In the second for loop, we changed the syntax to **for** I **of** List. Instead of I being the index counter, it is now an iterator that references the underlying element. This example of Ada code is identical to the last bit of Ada code. We just used a different method to index over the second for loop. There is no C equivalent to this Ada feature, but it is similar to C++'s range based for loop.

2.11 Type System

2.11.1 Strong Typing

Ada is considered a "strongly typed" language. This means that the language does not define any implicit type conversions. C does define implicit type conversions, sometimes referred to as *integer promotion*. The rules for promotion are fairly straightforward in simple expressions but can get confusing very quickly. Let's look at a typical place of confusion with implicit type conversion:

[C]

```
Listing 27: main.c
```

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
        unsigned char a = 0xFF;
5
        char b = 0 \times FF;
6
7
        printf("Does a == b?\n");
8
        if(a == b)
9
             printf("Yes.\n");
10
        else
11
            printf("No.\n");
12
13
        printf("a: 0x%08X, b: 0x%08X\n", a, b);
14
15
        return 0;
16
   }
17
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Strong_Typing_C
MD5: cablac9e2c86076d8435d53904783ba0

Runtime output

Does a == b? No. a: 0x00000FF, b: 0xFFFFFFF

Run the above code. You will notice that a != b! If we look at the output of the last printf statement we will see the problem. a is an unsigned number where b is a signed number. We stored a value of $0 \times FF$ in both variables, but a treated this as the decimal number 255 while b treated this as the decimal number -1. When we compare the two variables, of course they aren't equal; but that's not very intuitive. Let's look at the equivalent Ada example:

[Ada]

Listing 28: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
3
   procedure Main
   is
4
       type Char is range 0 .. 255;
5
       type Unsigned_Char is mod 256;
6
7
      A : Char := 16#FF#;
8
      B : Unsigned_Char := 16#FF#;
9
   begin
10
11
      Put_Line ("Does A = B?");
12
13
      if A = B then
14
15
          Put_Line ("Yes");
16
      else
          Put_Line ("No");
17
      end if;
18
19
   end Main;
20
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Strong_Typing_Ada
MD5: d6ef2668809159e9fb0d42f91e893222

Build output

```
main.adb:14:09: error: invalid operand types for operator "="
main.adb:14:09: error: left operand has type "Char" defined at line 5
main.adb:14:09: error: right operand has type "Unsigned_Char" defined at line 6
gprbuild: *** compilation phase failed
```

If you try to run this Ada example you will get a compilation error. This is because the compiler is telling you that you cannot compare variables of two different types. We would need to explicitly cast one side to make the comparison against two variables of the same type. By enforcing the explicit cast we can't accidentally end up in a situation where we assume something will happen implicitly when, in fact, our assumption is incorrect.

Another example: you can't divide an integer by a float. You need to perform the division operation using values of the same type, so one value must be explicitly converted to match the type of the other (in this case the more likely conversion is from integer to float). Ada is designed to guarantee that what's done by the program is what's meant by the programmer, leaving as little room for compiler interpretation as possible. Let's have a look at the following example:

[Ada]

Listing	29:	strong	typing	I.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Strong Typing is
3
      Alpha : constant Integer := 1;
4
      Beta : constant Integer := 10;
5
      Result : Float;
6
   begin
7
      Result := Float (Alpha) / Float (Beta);
8
9
      Put_Line (Float'Image (Result));
10
   end Strong_Typing;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Strong_Typing_Ada_2
MD5: bf91f01b499bcd7da1df751a9f91a767

Runtime output

1.00000E-01

[C]

Listing 30: main.c

```
#include <stdio.h>
1
2
   void weakTyping (void) {
3
       const int
                    alpha = 1;
4
       const int
                    beta = 10;
5
       float result;
6
7
       result = alpha / beta;
8
```

```
9
        printf("%f\n", result);
10
   }
11
12
   int main(int argc, const char * argv[])
13
   {
14
        weakTyping();
15
16
        return 0;
17
   }
18
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Strong_Typing_C_2
MD5: e4310900cd1195d6e3d349e0c4aa758a
```

Runtime output

0.000000

Are the three programs above equivalent? It may seem like Ada is just adding extra complexity by forcing you to make the conversion from **Integer** to **Float** explicit. In fact, it significantly changes the behavior of the computation. While the Ada code performs a floating point operation 1.0 / 10.0 and stores 0.1 in Result, the C version instead store 0.0 in result. This is because the C version perform an integer operation between two integer variables: 1 / 10 is 0. The result of the integer division is then converted to a **float** and stored. Errors of this sort can be very hard to locate in complex pieces of code, and systematic specification of how the operation should be interpreted helps to avoid this class of errors. If an integer division was actually intended in the Ada case, it is still necessary to explicitly convert the final result to **Float**:

[Ada]

```
-- Perform an Integer division then convert to Float
Result := Float (Alpha / Beta);
```

The complete example would then be:

[Ada]

Listing 31: strong_typing.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Strong Typing is
3
      Alpha : constant Integer := 1;
4
      Beta : constant Integer := 10;
5
      Result : Float;
6
   begin
7
      Result := Float (Alpha / Beta);
8
g
      Put Line (Float'Image (Result));
10
   end Strong_Typing;
11
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Strong_Typing_Ada_2
MD5: 50d6a6a3270b51880c43c07f077760b6
```

Runtime output

0.00000E+00

Floating Point Literals

In Ada, a floating point literal must be written with both an integral and decimal part. 10 is not a valid literal for a floating point value, while 10.0 is.

2.11.2 Language-Defined Types

The principal scalar types predefined by Ada are **Integer**, **Float**, **Boolean**, and **Character**. These correspond to **int**, **float**, **int** (when used for Booleans), and **char**, respectively. The names for these types are not reserved words; they are regular identifiers. There are other language-defined integer and floating-point types as well. All have implementation-defined ranges and precision.

2.11.3 Application-Defined Types

Ada's type system encourages programmers to think about data at a high level of abstraction. The compiler will at times output a simple efficient machine instruction for a full line of source code (and some instructions can be eliminated entirely). The careful programmer's concern that the operation really makes sense in the real world would be satisfied, and so would the programmer's concern about performance.

The next example below defines two different metrics: area and distance. Mixing these two metrics must be done with great care, as certain operations do not make sense, like adding an area to a distance. Others require knowledge of the expected semantics; for example, multiplying two distances. To help avoid errors, Ada requires that each of the binary operators +, -, *, and / for integer and floating-point types take operands of the same type and return a value of that type.

[Ada]

Listing 32: main.adb

```
procedure Main is
1
      type Distance is new Float;
2
      type Area is new Float;
3
4
      D1 : Distance := 2.0;
5
      D2 : Distance := 3.0:
6
      A : Area;
7
   beain
8
      D1 := D1 + D2; -- OK
9
      D1 := D1 + A; -- NOT OK: incompatible types for "+"
10
      A := D1 * D2; -- NOT OK: incompatible types for ":="
11
      A := Area (D1 * D2); -- OK
12
   end Main;
13
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Application_Defined_Types
MD5: 6a21d6281cc529bbf8ce2216d7e4a770
```

Build output

```
main.adb:11:13: error: expected type "Area" defined at line 3
main.adb:11:13: error: found type "Distance" defined at line 2
gprbuild: *** compilation phase failed
```

Even though the Distance and Area types above are just **Float**, the compiler does not allow arbitrary mixing of values of these different types. An explicit conversion (which does not necessarily mean any additional object code) is necessary.

The predefined Ada rules are not perfect; they admit some problematic cases (for example multiplying two Distance yields a Distance) and prohibit some useful cases (for example multiplying two Distances should deliver an Area). These situations can be handled through other mechanisms. A predefined operation can be identified as abstract to make it unavailable; overloading can be used to give new interpretations to existing operator symbols, for example allowing an operator to return a value from a type different from its operands; and more generally, GNAT has introduced a facility that helps perform dimensionality checking.

Ada enumerations work similarly to C enum:

[Ada]

Listing 33: main.adb

```
procedure Main is
1
       type Day is
2
         (Monday,
3
          Tuesday,
4
          Wednesday,
5
          Thursday,
6
          Friday,
7
          Saturday,
8
          Sunday);
9
10
       D : Day := Monday;
11
12
   begin
       null;
13
   end Main;
14
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Enumeration_Ada
MD5: 51abd1863970e14ff86859c1aae11fe8

[C]

Listing	34:	main.c

1	enum Day {			
2	Monday,			
3	Tuesday,			
4	Wednesday,			
5	Thursday,			
6	Friday,			
7	Saturday,			
8	Sunday			
9	};			
10				
11	<pre>int main(int argc, const char * argv[])</pre>			
12	{			
13	enum Day d = Monday;			
14				

15 return 0; 16 }

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Enumeration_C
MD5: d9f6724759375a126a6b5d8dceea3f24
```

But even though such enumerations may be implemented by the compiler as numeric values, at the language level Ada will not confuse the fact that Monday is a Day and is not an **Integer**. You can compare a Day with another Day, though. To specify implementation details like the numeric values that correspond with enumeration values in C you include them in the original **enum** declaration:

[C]

Listing 35: main.c

```
#include <stdio.h>
1
2
   enum Day {
3
        Monday
                   = 10,
4
        Tuesday
                 = 11,
5
        Wednesday = 12,
6
        Thursday = 13,
7
        Friday
                   = 14,
8
        Saturday = 15,
9
        Sunday
                   = 16
10
   };
11
12
   int main(int argc, const char * argv[])
13
14
   {
        enum Day d = Monday;
15
16
        printf("d = %d\n", d);
17
18
        return 0;
19
   }
20
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Enumeration_Values_C
MD5: 48ae1c84dafabde7a16de5305e106a80

Runtime output

d = 10

But in Ada you must use both a type definition for Day as well as a separate representation clause for it like:

[Ada]

Listing 36: main.adb

```
with Ada.Text_I0;
    procedure Main is
    type Day is
        (Monday,
        Tuesday,
```

```
Wednesday,
7
          Thursday,
8
          Friday,
9
          Saturday,
10
          Sunday);
11
12
       -- Representation clause for Day type:
13
       for Day use
14
         (Monday
                     => 10,
15
          Tuesday
                   => 11,
16
          Wednesday => 12,
17
          Thursday => 13,
18
                     => 14,
19
          Friday
          Saturday => 15,
20
                    => 16);
21
          Sunday
22
       D : Day := Monday;
23
       V : Integer;
24
   begin
25
       V := Day'Enum Rep (D);
26
       Ada.Text_IO.Put_Line (Integer'Image (V));
27
   end Main;
28
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Enumeration_Values
MD5: 9a4fa1a899cb8c240105bf8ad6dbfde3
```

Runtime output

10

Note that however, unlike C, values for enumerations in Ada have to be unique.

2.11.4 Type Ranges

Contracts can be associated with types and variables, to refine values and define what are considered valid values. The most common kind of contract is a *range constraint* introduced with the **range** reserved word, for example:

[Ada]

Listing 37: main.adb

```
procedure Main is
1
       type Grade is range 0 .. 100;
2
3
       G1, G2 : Grade;
4
       Ν
                : Integer;
5
   begin
6
                                -- Initialization of N
7
           . . .
       G1 := 80;
                               -- OK
8
9
       G1 := N;
                                -- Illegal (type mismatch)
       G1 := Grade (N); -- Legal, run-time range check
G2 := G1 + 10; -- Legal, run-time range check
10
11
       G1 := (G1 + G2) / 2; -- Legal, run-time range check
12
   end Main;
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Range_Check
MD5: 0f249b06e373497ae94b6055a37187c8

Build output

```
main.adb:9:10: error: expected type "Grade" defined at line 2
main.adb:9:10: error: found type "Standard.Integer"
gprbuild: *** compilation phase failed
```

In the above example, Grade is a new integer type associated with a range check. Range checks are dynamic and are meant to enforce the property that no object of the given type can have a value outside the specified range. In this example, the first assignment to G1 is correct and will not raise a run-time exception. Assigning N to G1 is illegal since Grade is a different type than **Integer**. Converting N to Grade makes the assignment legal, and a range check on the conversion confirms that the value is within 0 \therefore 100. Assigning G1 + 10 to G2 is legal since + for Grade returns a Grade (note that the literal 10 is interpreted as a Grade value in this context), and again there is a range check.

The final assignment illustrates an interesting but subtle point. The subexpression G1 + G2 may be outside the range of Grade, but the final result will be in range. Nevertheless, depending on the representation chosen for Grade, the addition may overflow. If the compiler represents Grade values as signed 8-bit integers (i.e., machine numbers in the range -128 .. 127) then the sum G1 + G2 may exceed 127, resulting in an integer overflow. To prevent this, you can use explicit conversions and perform the computation in a sufficiently large integer type, for example:

[Ada]

Listing 38: main.adb

```
with Ada.Text IO;
1
2
   procedure Main is
3
      type Grade is range 0 .. 100;
4
5
6
      G1, G2 : Grade := 99;
   begin
7
      G1 := Grade ((Integer (G1) + Integer (G2)) / 2);
8
      Ada.Text_IO.Put_Line (Grade'Image (G1));
9
   end Main;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Range_And_Explicit_Conversion
MD5: d317fd95099e49017c4a4c1c52b7f8be

Runtime output

99

Range checks are useful for detecting errors as early as possible. However, there may be some impact on performance. Modern compilers do know how to remove redundant checks, and you can deactivate these checks altogether if you have sufficient confidence that your code will function correctly.

Types can be derived from the representation of any other type. The new derived type can be associated with new constraints and operations. Going back to the Day example, one can write:

[Ada]

Listing 39: main.adb

```
procedure Main is
1
       type Day is
2
         (Monday,
3
          Tuesday,
4
          Wednesday,
5
          Thursday,
6
          Friday,
7
          Saturday,
8
          Sunday);
9
10
       type Business Day is new Day range Monday .. Friday;
11
       type Weekend_Day is new Day range Saturday .. Sunday;
12
   begin
13
      null;
14
   end Main;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Enum_Ranges_1
MD5: fd775ad4990d5636607d3a0d9b00044d

Since these are new types, implicit conversions are not allowed. In this case, it's more natural to create a new set of constraints for the same type, instead of making completely new ones. This is the idea behind *subtypes* in Ada. A subtype is a type with optional additional constraints. For example:

[Ada]

Listing 40: main.adb

```
procedure Main is
1
       type Day is
2
         (Monday,
3
          Tuesday,
4
5
          Wednesday,
6
          Thursday,
          Friday,
7
          Saturday,
8
          Sunday);
9
10
       subtype Business Day is Day range Monday .. Friday;
11
       subtype Weekend Day is Day range Saturday .. Sunday;
12
       subtype Dice Throw is Integer range 1 .. 6;
13
   begin
14
      null;
15
   end Main;
16
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Enum_Ranges_2
MD5: 5bcbde5b9f1aea57ff172fcfc89e1c41

These declarations don't create new types, just new names for constrained ranges of their base types.

The purpose of numeric ranges is to express some application-specific constraint that we want the compiler to help us enforce. More importantly, we want the compiler to tell us when that constraint cannot be met — when the underlying hardware cannot support the range given. There are two things to consider:

just a range constraint, such as A : Integer range 0 .. 10;, or

• a type declaration, such as type **Result is range** 0 .. 1_000_000_000;.

Both represent some sort of application-specific constraint, but in addition, the type declaration promotes portability because it won't compile on targets that do not have a sufficiently large hardware numeric type. That's a definition of portability that is preferable to having something compile anywhere but not run correctly, as in C.

2.11.5 Unsigned And Modular Types

Unsigned integer numbers are quite common in embedded applications. In C, you can use them by declaring **unsigned int** variables. In Ada, you have two options:

- declare custom unsigned range types;
 - In addition, you can declare custom range *subtypes* or use existing subtypes such as **Natural**.
- declare custom modular types.

The following table presents the main features of each type. We discuss these types right after.

Feature	[C] unsigned int	[Ada] Unsigned range	[Ada] Modular
Excludes negative value	\checkmark	\checkmark	\checkmark
Wraparound	\checkmark		\checkmark

When declaring custom range types in Ada, you may use the full range in the same way as in C. For example, this is the declaration of a 32-bit unsigned integer type and the X variable in Ada:

[Ada]

Listing 41: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
      type Unsigned Int 32 is range 0 .. 2 ** 32 - 1;
4
5
      X : Unsigned Int 32 := 42;
6
  beain
7
      Put Line ("X = " & Unsigned Int 32'Image (X));
8
  end Main;
a
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Unsigned_32_Ada
MD5: 0a179ce327c022468f66b6814a981b62

Runtime output

X = 42

In C, when **unsigned int** has a size of 32 bits, this corresponds to the following declaration: [C]

Listing 42: main.c

```
1 #include <stdio.h>
2 #include <limits.h>
```

```
3
4 int main(int argc, const char * argv[])
5 {
6 unsigned int x = 42;
7 printf("x = %u\n", x);
8
9 return 0;
10 }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Unsigned_32_C
MD5: 546068de216de96282490e81a0f7df26
```

Runtime output

x = 42

Another strategy is to declare subtypes for existing signed types and specify just the range that excludes negative numbers. For example, let's declare a custom 32-bit signed type and its unsigned subtype:

[Ada]

Listing 43: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      type Signed Int_32 is range -2 ** 31 .. 2 ** 31 - 1;
4
5
      subtype Unsigned_Int_31 is Signed_Int_32 range 0 .. Signed_Int_32'Last;
6
      -- Equivalent to:
7
         subtype Unsigned_Int_31 is Signed_Int_32 range 0 .. 2 ** 31 - 1;
      - -
8
9
      X : Unsigned_Int_31 := 42;
10
   beain
11
      Put_Line ("X = " & Unsigned_Int_31'Image (X));
12
   end Main;
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Unsigned_31_Ada
MD5: 2ef2b5bfd54821ceb35faa222e649156

Runtime output

X = 42

In this case, we're just skipping the sign bit of the Signed_Int_32 type. In other words, while Signed_Int_32 has a size of 32 bits, Unsigned_Int_31 has a range of 31 bits, even if the base type has 32 bits.

Note that the declaration above is actually similar to the existing **Natural** subtype. Ada provides the following standard subtypes:

```
subtype Natural is Integer range 0..Integer'Last;
subtype Positive is Integer range 1..Integer'Last;
```

Since they're standard subtypes, you can declare variables of those subtypes directly in your implementation, in the same way as you can declare **Integer** variables.

As indicated in the table above, however, there is a difference in behavior for the variables we just declared, which occurs in case of overflow. Let's consider this C example:

[C]

Listing 44: main.c

```
#include <stdio.h>
1
   #include <limits.h>
2
3
   int main(int argc, const char * argv[])
4
   {
5
        unsigned int x = UINT MAX + 1;
6
        /* Now: x == 0 */
7
8
        printf("x = %u\n", x);
9
10
        return 0;
11
   }
12
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Overflow_Wraparound_C MD5: 7d5dcf65471304ff8f303195359b4790

Runtime output

x = 0

The corresponding code in Ada raises an exception:

[Ada]

Listing 45: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
      type Unsigned Int 32 is range 0 .. 2 ** 32 - 1;
4
5
      X : Unsigned_Int_32 := Unsigned_Int_32'Last + 1;
6
          Overflow: exception is raised!
      - -
7
   begin
8
      Put Line ("X = " & Unsigned Int 32'Image (X));
9
   end Main;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Overflow_Wraparound_Ada
MD5: ee4c3e905c59f5c8d87311e13d079836

Build output

Runtime output

raised CONSTRAINT_ERROR : main.adb:6 range check failed

While the C uses modulo arithmetic for unsigned integer, Ada doesn't use it for the Unsigned_Int_32 type. Ada does, however, support modular types via type definitions using the **mod** keyword. In this example, we declare a 32-bit modular type:

[Ada]

Listing 46: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   procedure Main is
3
      type Unsigned_32 is mod 2**32;
4
5
      X : Unsigned 32 := Unsigned 32'Last + 1;
6
          Now: X = 0
7
   begin
8
      Put_Line ("X = " & Unsigned_32'Image (X));
9
   end Main:
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Overflow_Wraparound_Ada
MD5: 4ed963ab372cafc8e7a19d9c3107276b

Runtime output

X = 0

In this case, the behavior is the same as in the C declaration above.

Modular types, unlike Ada's signed integers, also provide bit-wise operations, a typical application for unsigned integers in C. In Ada, you can use operators such as **and**, **or**, **xor** and **not**. You can also use typical bit-shifting operations, such as Shift_Left, Shift_Right, Shift_Right_Arithmetic, Rotate_Left and Rotate_Right.

2.11.6 Attributes

Attributes start with a single apostrophe ("tick"), and they allow you to query properties of, and perform certain actions on, declared entities such as types, objects, and subprograms. For example, you can determine the first and last bounds of scalar types, get the sizes of objects and types, and convert values to and from strings. This section provides an overview of how attributes work. For more information on the many attributes defined by the language, you can refer directly to the Ada Language Reference Manual.

The 'Image and 'Value attributes allow you to transform a scalar value into a **String** and vice-versa. For example:

[Ada]

Listing 47: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      A : Integer := 10;
4
   begin
5
      Put_Line (Integer'Image (A));
6
      A := Integer'Value ("99");
7
      Put_Line (Integer'Image (A));
8
  end Main;
9
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Image_Attribute
MD5: 1fcfc79ec599a26e21aef7eacffcf96e
```

Runtime output

10 99

1 Important

Semantically, attributes are equivalent to subprograms. For example, **Integer**'Image is defined as follows:

function Integer'Image(Arg : Integer'Base) return String;

Certain attributes are provided only for certain kinds of types. For example, the 'Val and 'Pos attributes for an enumeration type associates a discrete value with its position among its peers. One circuitous way of moving to the next character of the ASCII table is:

[Ada]

Listing 48: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
3
  procedure Main is
      C : Character := 'a';
4
5
  begin
      Put (C);
6
      C := Character'Val (Character'Pos (C) + 1);
7
      Put (C);
8
  end Main;
9
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Character_1
MD5: 742bbaeb74e5dd9fa73089c0d1aa0fde

Runtime output

ab

A more concise way to get the next value in Ada is to use the 'Succ attribute:

[Ada]

Listing 49: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
  procedure Main is
3
      C : Character := 'a';
4
  begin
5
      Put (C);
6
      C := Character'Succ (C);
7
      Put (C);
8
  end Main;
9
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Character_1
MD5: 842eeff2b82dcdb8c73547a33d03995b

Runtime output

ab

You can get the previous value using the 'Pred attribute. Here is the equivalent in C: [C]

Listing 50: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        char c = 'a';
5
        printf("%c", c);
6
        c++;
7
        printf("%c", c);
8
9
        return 0;
10
   }
11
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Loop_Reverse_C
MD5: 40bfbd6a672bc3fdb7e8f2f2d7101b19
```

Runtime output

ab

Other interesting examples are the 'First and 'Last attributes which, respectively, return the first and last values of a scalar type. Using 32-bit integers, for instance, **Integer**'First returns -2³¹ and **Integer**'Last returns 2³¹ - 1.

2.11.7 Arrays and Strings

C arrays are pointers with offsets, but the same is not the case for Ada. Arrays in Ada are not interchangeable with operations on pointers, and array types are considered first-class citizens. They have dedicated semantics such as the availability of the array's boundaries at run-time. Therefore, unhandled array overflows are impossible unless checks are suppressed. Any discrete type can serve as an array index, and you can specify both the starting and ending bounds — the lower bound doesn't necessarily have to be 0. Most of the time, array types need to be explicitly declared prior to the declaration of an object of that array type.

Here's an example of declaring an array of 26 characters, initializing the values from 'a' to 'z':

[Ada]

Listing 51: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Main is
type Arr_Type is array (Integer range <>) of Character;
Arr : Arr_Type (1 .. 26);
```

```
C : Character := 'a';
6
   begin
7
       for I in Arr'Range loop
8
          Arr (I) := C;
9
          C := Character'Succ (C);
10
11
          Put (Arr (I) & " ");
12
13
          if I mod 7 = 0 then
14
             New_Line;
15
          end if;
16
       end loop;
17
18
   end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Range_Ada
MD5: 8e0597f6c040c740b35c79bc4706829b
```

Runtime output

a b c d e f g h i j k l m n o p q r s t u v w x y z

[C]

Listing 52: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        char Arr [26];
5
        char C = 'a';
6
7
        for (int I = 0; I < 26; ++I) {
8
            Arr [I] = C++;
9
            printf ("%c ", Arr [I]);
10
11
            if ((I + 1) % 7 == 0) {
12
                 printf ("\n");
13
            }
14
        }
15
16
        return 0;
17
   }
18
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Range_C
MD5: 1182155f46a0b69f73cd5937c23ed67d
```

Runtime output

a b c d e f g h i j k l m n o p q r s t u v w x y z

In C, only the size of the array is given during declaration. In Ada, array index ranges are

specified using two values of a discrete type. In this example, the array type declaration specifies the use of **Integer** as the index type, but does not provide any constraints (use <>, pronounced *box*, to specify "no constraints"). The constraints are defined in the object declaration to be 1 to 26, inclusive. Arrays have an attribute called 'Range. In our example, Arr'Range can also be expressed as Arr'First .. Arr'Last; both expressions will resolve to 1 ... 26. So the 'Range attribute supplies the bounds for our **for** loop. There is no risk of stating either of the bounds incorrectly, as one might do in C where I <= 26 may be specified as the end-of-loop condition.

As in C, Ada **String** is an array of **Character**. Ada strings, importantly, are not delimited with the special character '0' like they are in C. It is not necessary because Ada uses the array's bounds to determine where the string starts and stops.

Ada's predefined **String** type is very straightforward to use:

[Ada]

Listing 53: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Main is
My_String : String (1 .. 19) := "This is an example!";
begin
Put_Line (My_String);
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Constrained_String
MD5: da2e88900c670f80b7380f87f2b89ec2

Runtime output

```
This is an example!
```

Unlike C, Ada does not offer escape sequences such as 'n'. Instead, explicit values from the ASCII package must be concatenated (via the concatenation operator, &). Here for example, is how to initialize a line of text ending with a new line:

[Ada]

Listing 54: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
procedure Main is
My_String : String := "This is a line" & ASCII.LF;
begin
Put (My_String);
end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Constrained_String
MD5: 684bbbdf99d48ed6fd5c257183a6609f
```

Runtime output

This is a line

You see here that no constraints are necessary for this variable definition. The initial value given allows the automatic determination of My_String's bounds.

Ada offers high-level operations for copying, slicing, and assigning values to arrays. We'll start with assignment. In C, the assignment operator doesn't make a copy of the value of an array, but only copies the address or reference to the target variable. In Ada, the actual array contents are duplicated. To get the above behavior, actual pointer types would have to be defined and used.

[Ada]

Listing 55: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Main is
3
       type Arr_Type is array (Integer range <>) of Integer;
A1 : Arr_Type (1 .. 2);
4
5
       A2 : Arr_Type (1 .. 2);
6
   begin
7
       A1 (1) := 0;
8
       A1 (2) := 1;
9
10
       A2 := A1;
11
12
       for I in A2'Range loop
13
          Put_Line (Integer'Image (A2 (I)));
14
       end loop;
15
   end Main;
16
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Copy_Ada
MD5: 4d4e9aa063c1f488e7cefa90083d06c2

Runtime output

0 1			

[C]

Listing 56: main.c

```
#include <stdio.h>
1
   #include <string.h>
2
3
   int main(int argc, const char * argv[])
4
5
   {
        int A1 [2];
6
        int A2 [2];
7
8
        A1 [0] = 0;
9
        A1 [1] = 1;
10
11
        memcpy (A2, A1, sizeof (int) * 2);
12
13
        for (int i = 0; i < 2; i++) {</pre>
14
15
            printf("%d\n", A2[i]);
16
        }
17
        return 0;
18
   }
19
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Copy_C MD5: 0dade800452673b7a82afe1c656f07e6

Runtime output

0 1

In all of the examples above, the source and destination arrays must have precisely the same number of elements. Ada allows you to easily specify a portion, or slice, of an array. So you can write the following:

[Ada]

Listing 57: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
      type Arr_Type is array (Integer range <>) of Integer;
4
      A1 : Arr_Type (1 .. 10) := (1, 2, 3, 4, 5, 6, 7, 8, 9, 10);
5
      A2 : Arr_Type (1 .. 5) := (1, 2, 3, 4, 5);
6
   begin
7
      A2 (1 \dots 3) := A1 (4 \dots 6);
8
9
      for I in A2'Range loop
10
         Put Line (Integer'Image (A2 (I)));
11
      end loop;
12
   end Main;
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Slice
MD5: cb2a7de2cff8ea19025363886f8821e4

Runtime output

4 5 6 4 5

This assigns the 4th, 5th, and 6th elements of A1 into the 1st, 2nd, and 3rd elements of A2. Note that only the length matters here: the values of the indexes don't have to be equal; they slide automatically.

Ada also offers high level comparison operations which compare the contents of arrays as opposed to their addresses:

[Ada]

Listing 58: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Main is
type Arr_Type is array (Integer range <>) of Integer;
Al : Arr_Type (1 .. 2) := (10, 20);
A2 : Arr_Type (1 .. 2) := (10, 20);
begin
if A1 = A2 then
```

```
9 Put_Line ("A1 = A2");
10 else
11 Put_Line ("A1 /= A2");
12 end if;
13 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Equal_Ada
MD5: 650a734875a02b2fb3678bbc3f8dd82a

Runtime output

A1 = A2

[C]

Listing 59: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        int A1 [2] = { 10, 20 };
5
        int A2 [2] = { 10, 20 };
6
7
        int eq = 1;
8
9
        for (int i = 0; i < 2; ++i) {</pre>
10
             if (A1 [i] != A2 [i]) {
11
                  eq = 0;
12
13
                  break;
             }
14
        }
15
16
        if (eq) {
17
             printf("A1 == A2\n");
18
        }
19
        else {
20
             printf("A1 != A2\n");
21
        }
22
23
        return 0;
24
   }
25
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Equal_C
MD5: efe8717d931324bcbe8b70b03693c92e

Runtime output

A1 == A2

You can assign to all the elements of an array in each language in different ways. In Ada, the number of elements to assign can be determined by looking at the right-hand side, the left-hand side, or both sides of the assignment. When bounds are known on the left-hand side, it's possible to use the others expression to define a default value for all the unspecified array elements. Therefore, you can write:

[Ada]

Listing 60: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      type Arr_Type is array (Integer range <>) of Integer;
4
      A1 : Arr_Type (-2 .. 42) := (others => 0);
5
   begin
6
      -- use a slice to assign A1 elements 11 .. 19 to 1
7
      A1 (11 .. 19) := (others => 1);
8
9
      Put Line ("---- A1 ----");
10
      for I in A1'Range loop
11
         Put_Line (Integer'Image (I) & " => " &
12
                    Integer'Image (A1 (I)));
13
      end loop;
14
   end Main;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Assignment_Ada
MD5: 673d31f633a32b6bb1cce238150cfc80

Runtime output

In this example, we're specifying that A1 has a range between -2 and 42. We use (**others** => 0) to initialize all array elements with zero. In the next example, the number of elements is determined by looking at the right-hand side:

[Ada]

Listing 61: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      type Arr_Type is array (Integer range <>) of Integer;
4
      A1 : Arr_Type := (1, 2, 3, 4, 5, 6, 7, 8, 9);
5
   begin
6
      A1 := (1, 2, 3, others => 10);
7
8
      Put Line ("---- A1 ----");
9
      for I in A1'Range loop
10
         Put_Line (Integer'Image (I) & " => " &
11
                    Integer'Image (A1 (I)));
12
      end loop;
13
   end Main;
14
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Array_Assignment_Ada
MD5: 3e3d69815373d1c61208df265903e89d

Runtime output

---- A1 -----2147483648 => 1 -2147483647 => 2 -2147483646 => 3 -2147483645 => 10 -2147483644 => 10 -2147483643 => 10 -2147483642 => 10 -2147483641 => 10 -2147483640 => 10

Since A1 is initialized with an aggregate of 9 elements, A1 automatically has 9 elements. Also, we're not specifying any range in the declaration of A1. Therefore, the compiler uses the default range of the underlying array type Arr_Type, which has an unconstrained range based on the **Integer** type. The compiler selects the first element of that type (**Integer'First**) as the start index of A1. If you replaced **Integer range** <> in the declaration of the Arr_Type by **Positive range** <>, then A1's start index would be **Positive'First** — which corresponds to one.

2.11.8 Heterogeneous Data Structures

The structure corresponding to a C **struct** is an Ada **record**. Here are some simple records: [Ada]

Listing 62: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      type R is record
4
         A, B : Integer;
5
         C : Float;
6
      end record;
7
8
      V : R;
9
   begin
10
      V.A := 0;
11
      Put_Line ("V.A = " & Integer'Image (V.A));
12
  end Main;
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Struct_Ada
MD5: 013f27dfc827355f32bea37fb267df9b

Runtime output

```
V.A = 0
```

[C]

Listing 63: main.c

```
#include <stdio.h>
1
2
   struct R {
3
        int A, B;
4
        float C:
5
   };
6
7
   int main(int argc, const char * argv[])
8
9
   {
        struct R V;
10
        V.A = 0;
11
        printf("V.A = %d\n", V.A);
12
13
        return 0;
14
   }
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Struct_C MD5: 653b65bbb6ea02a512e439d912e11d7f

Runtime output

V.A = 0

Ada allows specification of default values for fields just like C. The values specified can take the form of an ordered list of values, a named list of values, or an incomplete list followed by others => <> to specify that fields not listed will take their default values. For example:

[Ada]

```
Listing 64: main.adb
```

```
with Ada.Text IO; use Ada.Text IO;
1
2
    procedure Main is
3
4
       type R is record
5
           A, B : Integer := 0;
6
           С
              : Float := 0.0;
7
       end record;
8
9
       procedure Put R (V : R; Name : String) is
10
       begin
11
           Put_Line (Name & " = ("
12
                       & Integer'Image (V.A) & ", "
13
                       & Integer'Image (V.B) & ", "
14
                       & Float'Image (V.C) & ")");
15
       end Put_R;
16
17
       V1 : constant R := (1, 2, 1.0);
18
       V2 : constant R := (A => 1, B => 2, C => 1.0);
19
       V3 : constant R := (C \Rightarrow 1.0, A \Rightarrow 1, B \Rightarrow 2);
20
       V4 : constant R := (C \Rightarrow 1.0, others \Rightarrow <>);
21
22
    begin
23
       Put_R (V1, "V1");
24
       Put_R (V2, "V2");
Put_R (V3, "V3");
Put_R (V4, "V4");
25
26
27
    end Main;
28
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Struct_Default_Ada
MD5: d0a9713e3bd9804c00ebf68cc7c196b7

Runtime output

٧1	=	(1,	2,	1.00000E+00)
V2	=	(1,	2,	1.00000E+00)
٧3	=	(1,	2,	1.00000E+00)
٧4	=	(0,	0,	1.00000E+00)

2.11.9 Pointers

As a foreword to the topic of pointers, it's important to keep in mind the fact that most situations that would require a pointer in C do not in Ada. In the vast majority of cases, indirect memory management can be hidden from the developer and thus saves from many potential errors. However, there are situation that do require the use of pointers, or said differently that require to make memory indirection explicit. This section will present Ada access types, the equivalent of C pointers. A further section will provide more details as to how situations that require pointers in C can be done without access types in Ada.

We'll continue this section by explaining the difference between objects allocated on the stack and objects allocated on the heap using the following example:

[Ada]

Listing 65: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
    procedure Main is
3
       type R is record
4
          A, B : Integer;
5
       end record;
6
7
       procedure Put_R (V : R; Name : String) is
8
       begin
9
          Put_Line (Name & " = ("
10
                     \& Integer'Image (V.A) \& ", "
11
                     & Integer'Image (V.B) & ")");
12
       end Put_R;
13
14
       V1, V2 : R;
15
16
    begin
17
       V1.A := 0;
18
       V1.B := 0;
19
       V2 := V1;
20
       V2.A := 1;
21
22
       Put_R (V1, "V1");
23
       Put_R (V2, "V2");
24
   end Main;
25
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Pointers_Ada
MD5: 0a4ade5aa12de5b0760d149c8e319d5f
```

Runtime output

V1 = (0, 0)V2 = (1, 0)

[C]

Listing 66: main.c

```
#include <stdio.h>
1
2
   struct R {
3
        int A, B;
4
   };
5
6
   void print_r(const struct R *v,
7
                 const char *name)
8
9
   {
        printf("%s = (%d, %d)\n", name, v->A, v->B);
10
   }
11
12
   int main(int argc, const char * argv[])
13
   {
14
        struct R V1, V2;
15
        V1.A = 0;
16
        V1.B = 0;
17
        V2 = V1;
18
        V2.A = 1;
19
```

(continues on next page)

20

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Pointers_C MD5: e604bf19c98927151f3b4989dc50747a

Runtime output

V1 = (0, 0)V2 = (1, 0)

There are many commonalities between the Ada and C semantics above. In Ada and C, objects are allocated on the stack and are directly accessed. V1 and V2 are two different objects and the assignment statement copies the value of V1 into V2. V1 and V2 are two distinct objects.

Here's now a similar example, but using heap allocation instead:

[Ada]

Listing 67: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Main is
3
       type R is record
4
          A, B : Integer;
5
       end record;
6
7
       type R_Access is access R;
8
9
       procedure Put_R (V : R; Name : String) is
10
       begin
11
          Put Line (Name & " = ("
12
                     & Integer'Image (V.A) & ", "
13
                     & Integer'Image (V.B) & ")");
14
       end Put R;
15
16
       V1 : R_Access;
17
       V2 : R_Access;
18
19
   begin
       V1 := new R;
20
       V1.A := 0;
21
       V2 := V1;
22
       V2.A := 1;
23
24
       Put_R (V1.all, "V1");
25
       Put_R (V2.all, "V2");
26
27
   end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Heap_Alloc_Ada
MD5: 963b48bb0a8585a9941d8fb2d0eda390
```

Runtime output

$$V1 = (1, 0)$$

 $V2 = (1, 0)$

[C]

Listing 68: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
З
   struct R {
4
        int A, B;
5
   };
6
7
   void print_r(const struct R *v,
8
                  const char *name)
9
   {
10
        printf("%s = (%d, %d)\n", name, v->A, v->B);
11
   }
12
13
   int main(int argc, const char * argv[])
14
   {
15
        struct R * V1, * V2;
16
        V1 = malloc(sizeof(struct R));
17
18
        V1 - >A = 0;
        V2 = V1;
19
        V2 - >A = 1;
20
21
        print r(V1, "V1");
22
        print_r(V2, "V2");
23
24
        return 0;
25
   }
26
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Heap_Alloc_C MD5: 5c832377403dfa8f00d70ef92bfeff65

Runtime output

V1 = (1, 0)V2 = (1, 0)

In this example, an object of type R is allocated on the heap. The same object is then referred to through V1 and V2. As in C, there's no garbage collector in Ada, so objects allocated by the new operator need to be expressly freed (which is not the case here).

Dereferencing is performed automatically in certain situations, for instance when it is clear that the type required is the dereferenced object rather than the pointer itself, or when accessing record members via a pointer. To explicitly dereference an access variable, append .all. The equivalent of V1->A in C can be written either as V1.A or V1.all.A.

Pointers to scalar objects in Ada and C look like:

[Ada]

Listing 69: main.adb

```
procedure Main is
type A_Int is access Integer;
Var : A_Int := new Integer;
```

```
4 begin
5 Var.all := 0;
6 end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Access_To_Scalars
MD5: 2e2bf53a9b5dc1098921d811be73a7f0
```

[C]

Listing 70: main.c

```
1 #include <stdlib.h>
2
3 int main(int argc, const char * argv[])
4 {
5     int * Var = malloc (sizeof(int));
6     *Var = 0;
7     return 0;
8 }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Pointers_To_Scalars
MD5: f22d7b6f8170587009b0f6bb1299c0a0
```

In Ada, an initializer can be specified with the allocation by appending '(value):

[Ada]

Listing 71: main.adb

```
procedure Main is
type A_Int is access Integer;
Var : A_Int := new Integer'(0);
begin
null;
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Access_Initialization
MD5: 5789253068f77100eec34919b8de66ec

When using Ada pointers to reference objects on the stack, the referenced objects must be declared as being aliased. This directs the compiler to implement the object using a memory region, rather than using registers or eliminating it entirely via optimization. The access type needs to be declared as either **access all** (if the referenced object needs to be assigned to) or **access constant** (if the referenced object is a constant). The 'Access attribute works like the C & operator to get a pointer to the object, but with a *scope accessibility* check to prevent references to objects that have gone out of scope. For example:

[Ada]

Listing 72: main.adb

```
procedure Main is
type A Int is access all Integer;
```

```
3 Var : aliased Integer;
```

```
4 Ptr : A_Int := Var'Access;
5 begin
6 null;
7 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Access_All
MD5: 520df34083e3517876e10710530380be

[C]

Listing 73: main.c

```
int main(int argc, const char * argv[])
{
    int Var;
    int * Ptr = &Var;
    return 0;
    }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Access_All_C
MD5: a592fcf09dabe15f2aaf12fba047d74f
```

To deallocate objects from the heap in Ada, it is necessary to use a deallocation subprogram that accepts a specific access type. A generic procedure is provided that can be customized to fit your needs, it's called Ada.Unchecked_Deallocation. To create your customized deallocator (that is, to instantiate this generic), you must provide the object type as well as the access type as follows:

[Ada]

Listing 74: main.adb

```
with Ada.Unchecked Deallocation;
1
2
   procedure Main is
3
      type Integer Access is access all Integer;
4
      procedure Free is new Ada.Unchecked_Deallocation (Integer, Integer_Access);
5
      My_Pointer : Integer_Access := new Integer;
6
  begin
7
      Free (My_Pointer);
8
  end Main;
9
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Unchecked_Deallocation
MD5: ef6ee170fea1f6c6c01037a09809916f
```

[C]

Listing 75: main.c

```
1 #include <stdlib.h>
2
3 int main(int argc, const char * argv[])
4 {
5 int * my_pointer = malloc (sizeof(int));
```

```
6 free (my_pointer);
7
8 return 0;
9 }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Free
MD5: 066046816dd1c4f9106b5e822cfe5e44
```

We'll discuss generics later in this section (page 155).

2.12 Functions and Procedures

2.12.1 General Form

Subroutines in C are always expressed as functions which may or may not return a value. Ada explicitly differentiates between functions and procedures. Functions must return a value and procedures must not. Ada uses the more general term *subprogram* to refer to both functions and procedures.

Parameters can be passed in three distinct modes:

- **in**, which is the default, is for input parameters, whose value is provided by the caller and cannot be changed by the subprogram.
- **out** is for output parameters, with no initial value, to be assigned by the subprogram and returned to the caller.
- **in out** is a parameter with an initial value provided by the caller, which can be modified by the subprogram and returned to the caller (more or less the equivalent of a non-constant pointer in C).

Ada also provides **access** and **aliased** parameters, which are in effect explicit pass-byreference indicators.

In Ada, the programmer specifies how the parameter will be used and in general the compiler decides how it will be passed (i.e., by copy or by reference). C has the programmer specify how to pass the parameter.

Important

There are some exceptions to the "general" rule in Ada. For example, parameters of scalar types are always passed by copy, for all three modes.

Here's a first example:

[Ada]

Listing 76: proc.ads

```
procedure Proc
(Var1 : Integer;
)
```

```
3 Var2 : out Integer;
4 Var3 : in out Integer);
```

Listing 77: func.ads

1 function Func (Var : Integer) return Integer;

Listing 78: proc.adb

```
with Func;
2
  procedure Proc
3
   (Var1 : Integer;
4
     Var2 : out Integer;
5
    Var3 : in out Integer)
6
7
   is
8
   begin
      Var2 := Func (Var1);
9
      Var3 := Var3 + 1;
10
  end Proc;
11
```

Listing 79: func.adb

```
1 function Func (Var : Integer) return Integer
2 is
3 begin
4 return Var + 1;
5 end Func;
```

```
Listing 80: main.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
  with Proc;
2
3
  procedure Main is
4
      V1, V2 : Integer;
5
   begin
6
7
      V2 := 2;
      Proc (5, V1, V2);
8
9
      Put_Line ("V1: " & Integer'Image (V1));
10
      Put_Line ("V2: " & Integer'Image (V2));
11
   end Main;
12
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Subroutines_Ada
MD5: a35fb6ae1b37325c3f39b3316e4246a8
```

Runtime output

V1: 6 V2: 3

[C]

Listing 81: proc.h

```
1 void Proc
2 (int Varl,
3 int * Var2,
4 int * Var3);
```

Listing 82: func.h

int Func (int Var);

Listing 83: proc.c

```
#include "func.h"
1
2
   void Proc
3
        (int
               Var1,
4
         int * Var2,
5
         int * Var3)
6
   {
7
        *Var2 = Func (Var1);
8
        *Var3 += 1;
9
   }
10
```

Listing 84: func.c

```
1 int Func (int Var)
2 {
3 return Var + 1;
4 }
```

Listing 85: main.c

```
#include <stdio.h>
1
   #include "proc.h"
2
З
   int main(int argc, const char * argv[])
4
   {
5
        int v1, v2;
6
7
        v^2 = 2;
8
9
        Proc (5, &v1, &v2);
10
        printf("v1: %d\n", v1);
11
        printf("v2: %d\n", v2);
12
13
        return 0;
14
   }
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Subroutines_C MD5: dd5645c832ef00b94061f204852084a3

Runtime output

v1: 6 v2: 3

The first two declarations for Proc and Func are specifications of the subprograms which are being provided later. Although optional here, it's still considered good practice to separately define specifications and implementations in order to make it easier to read the program. In Ada and C, a function that has not yet been seen cannot be used. Here, Proc can call Func because its specification has been declared.

Parameters in Ada subprogram declarations are separated with semicolons, because commas are reserved for listing multiple parameters of the same type. Parameter declaration syntax is the same as variable declaration syntax (except for the modes), including default values for parameters. If there are no parameters, the parentheses must be omitted entirely from both the declaration and invocation of the subprogram.

\rm In Ada 202X

Ada 202X allows for using static expression functions, which are evaluated at compile time. To achieve this, we can use an aspect — we'll discuss aspects *later in this chapter* (page 64).

An expression function is static when the Static aspect is specified. For example:

```
procedure Main is
X1 : constant := (if True then 37 else 42);
function If_Then_Else (Flag : Boolean; X, Y : Integer)
return Integer is
  (if Flag then X else Y) with Static;
X2 : constant := If_Then_Else (True, 37, 42);
begin
null;
end Main;
In this example, we declare X1 using an expression. In the declare
```

In this example, we declare X1 using an expression. In the declaration of X2, we call the static expression function If_Then_Else. Both X1 and X2 have the same constant value.

2.12.2 Overloading

In C, function names must be unique. Ada allows overloading, in which multiple subprograms can share the same name as long as the subprogram signatures (the parameter types, and function return types) are different. The compiler will be able to resolve the calls to the proper routines or it will reject the calls. For example:

[Ada]

Listing 86: machine.ads

```
package Machine is
1
      type Status is (Off, On);
2
      type Code is new Integer range 0 .. 3;
3
      type Threshold is new Float range 0.0 .. 10.0;
4
5
      function Get (S : Status) return Code;
6
      function Get (S : Status) return Threshold;
7
8
  end Machine;
9
```

Listing 87: machine.adb

```
package body Machine is
1
2
3
      function Get (S : Status) return Code is
      begin
4
         case S is
5
            when Off => return 1;
6
            when On => return 3;
7
         end case;
8
      end Get;
9
```

```
10
      function Get (S : Status) return Threshold is
11
      begin
12
          case S is
13
             when Off => return 2.0;
14
             when On => return 10.0;
15
          end case:
16
      end Get;
17
18
   end Machine;
19
```

Listing 88: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   with Machine;
                      use Machine;
2
3
   procedure Main is
4
      S : Status;
5
      C : Code;
6
      T : Threshold;
7
   begin
8
      S := On;
9
      C := Get (S);
10
      T := Get (S);
11
12
      Put_Line ("S: " & Status'Image (S));
13
      Put Line ("C: " & Code'Image (C));
14
      Put Line ("T: " & Threshold'Image (T));
15
16
   end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Overloading_Ada
MD5: 909cdf00b629917f7131489702cc26f1

Runtime output

S: ON C: 3 T: 1.00000E+01

The Ada compiler knows that an assignment to C requires a Code value. So, it chooses the Get function that returns a Code to satisfy this requirement.

Operators in Ada are functions too. This allows you to define local operators that override operators defined at an outer scope, and provide overloaded operators that operate on and compare different types. To declare an operator as a function, enclose its "name" in quotes:

[Ada]

Listing 89: machine_2.ads

```
package Machine_2 is
type Status is (Off, Waiting, On);
type Input is new Float range 0.0 .. 10.0;
function Get (I : Input) return Status;
function "=" (Left : Input; Right : Status) return Boolean;
end Machine_2;
```

Listing 90: machine_2.adb

```
package body Machine_2 is
1
2
       function Get (I : Input) return Status is
3
      begin
4
          if I >= 0.0 and I < 3.0 then
5
             return Off;
6
          elsif I >= 3.0 and I < 6.5 then
7
             return Waiting;
8
          else
9
             return On;
10
          end if;
11
      end Get;
12
13
       function "=" (Left : Input; Right : Status) return Boolean is
14
      begin
15
          return Get (Left) = Right;
16
       end "=";
17
18
   end Machine_2;
19
```

Listing 91: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
   with Machine_2;
                     use Machine_2;
2
3
   procedure Main is
4
      I : Input;
5
   begin
6
      I := 3.0;
7
      if I = Off then
8
          Put Line ("Machine is off.");
9
      else
10
          Put_Line ("Machine is not off.");
11
      end if;
12
   end Main;
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Overloading_Eq
MD5: c5580f15c1b93f73fff3afc147cd15a1

Runtime output

Machine is not off.

2.12.3 Aspects

Aspect specifications allow you to define certain characteristics of a declaration using the **with** keyword after the declaration:

```
procedure Some_Procedure is <procedure_definition>
   with Some_Aspect => <aspect_specification>;
function Some_Function is <function_definition>
   with Some_Aspect => <aspect_specification>;
type Some_Type is <type_definition>
   with Some_Aspect => <aspect_specification>;
```

Obj : Some_Type with Some_Aspect => <aspect_specification>;

For example, you can inline a subprogram by specifying the Inline aspect: [Ada]

Listing 92: float_arrays.ads

```
package Float_Arrays is
type Float_Array is array (Positive range <>) of Float;
function Average (Data : Float_Array) return Float
with Inline;
end Float Arrays;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Inline_Aspect
MD5: 6e25e81e4015d907d50aa9cf4a0a3fab
```

We'll discuss inlining later in this course (page 204).

Aspect specifications were introduced in Ada 2012. In previous versions of Ada, you had to use a **pragma** instead. The previous example would be written as follows:

[Ada]

Listing 93: float arrays.ads

```
package Float_Arrays is
    type Float_Array is array (Positive range <>) of Float;
    function Average (Data : Float_Array) return Float;
    pragma Inline (Average);
    end Float_Arrays;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Inline_Aspect
MD5: bd5df14dce9577a054f0ec612d5bbe40
```

Aspects and attributes might refer to the same kind of information. For example, we can use the Size aspect to define the expected minimum size of objects of a certain type:

[Ada]

Listing 94: my_device_types.ads

```
1 package My_Device_Types is
2
3 type UInt10 is mod 2 ** 10
4 with Size => 10;
5
6 end My_Device_Types;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Size_Aspect
MD5: 049be992b876dba42cf091afc256db35

In the same way, we can use the size attribute to retrieve the size of a type or of an object: [Ada]

Listing 95: show device types.adb

```
1
  with Ada.Text_I0;
                         use Ada.Text_I0;
2
  with My_Device_Types; use My_Device_Types;
3
4
   procedure Show_Device_Types is
5
      UInt10_Obj : constant UInt10 := 0;
6
   begin
7
      Put_Line ("Size of UInt10 type: " & Positive'Image (UInt10'Size));
8
      Put_Line ("Size of UInt10 object: " & Positive'Image (UInt10_Obj'Size));
9
  end Show_Device_Types;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Size_Aspect
MD5: 4e46ad9cf54276b381b960672daa03b9

Runtime output

Size of UInt10 type: 10 Size of UInt10 object: 16

We'll explain both Size aspect and Size attribute later in this course (page 95).

CONCURRENCY AND REAL-TIME

3.1 Understanding the various options

Concurrent and real-time programming are standard parts of the Ada language. As such, they have the same semantics, whether executing on a native target with an OS such as Linux, on a real-time operating system (RTOS) such as VxWorks, or on a bare metal target with no OS or RTOS at all.

For resource-constrained systems, two subsets of the Ada concurrency facilities are defined, known as the Ravenscar and Jorvik profiles. Though restricted, these subsets have highly desirable properties, including: efficiency, predictability, analyzability, absence of dead-lock, bounded blocking, absence of priority inversion, a real-time scheduler, and a small memory footprint. On bare metal systems, this means in effect that Ada comes with its own real-time kernel.

1 For further information

We'll discuss the Ravenscar profile *later in this chapter* (page 77). Details about the Jorvik profile can be found elsewhere [Jorvik].

Enhanced portability and expressive power are the primary advantages of using the standard concurrency facilities, potentially resulting in considerable cost savings. For example, with little effort, it is possible to migrate from Windows to Linux to a bare machine without requiring any changes to the code. Thread management and synchronization is all done by the implementation, transparently. However, in some situations, it's critical to be able to access directly the services provided by the platform. In this case, it's always possible to make direct system calls from Ada code. Several targets of the GNAT compiler provide this sort of API by default, for example win32ada for Windows and Florist for POSIX systems.

On native and RTOS-based platforms GNAT typically provides the full concurrency facilities. In contrast, on bare metal platforms GNAT typically provides the two standard subsets: Ravenscar and Jorvik.

3.2 Tasks

Ada offers a high level construct called a *task* which is an independent thread of execution. In GNAT, tasks are either mapped to the underlying OS threads, or use a dedicated kernel when not available.

The following example will display the 26 letters of the alphabet twice, using two concurrent tasks. Since there is no synchronization between the two threads of control in any of the examples, the output may be interspersed.

[Ada]

Listing 1: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is -- implicitly called by the environment task
3
       subtype A To Z is Character range 'A' ... 'Z';
4
5
      task My_Task;
6
7
      task body My_Task is
8
       begin
9
          for I in A To Z'Range loop
10
             Put (I);
11
          end loop;
12
          New Line;
13
      end My_Task;
14
15
   beain
       for I in A_To_Z'Range loop
16
          Put (I);
17
      end loop:
18
      New Line;
19
   end Main;
20
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.My_Task
MD5: 154702197f0c02f5750838e51a99f548
```

Runtime output

ABCDEFGHIJABCDEFGHIJKLMNOPQRSTUVWXYZ KLMNOPQRSTUVWXYZ

Any number of Ada tasks may be declared in any declarative region. A task declaration is very similar to a procedure or package declaration. They all start automatically when control reaches the begin. A block will not exit until all sequences of statements defined within that scope, including those in tasks, have been completed.

A task type is a generalization of a task object; each object of a task type has the same behavior. A declared object of a task type is started within the scope where it is declared, and control does not leave that scope until the task has terminated.

Task types can be parameterized; the parameter serves the same purpose as an argument to a constructor in Java. The following example creates 10 tasks, each of which displays a subset of the alphabet contained between the parameter and the 'Z' Character. As with the earlier example, since there is no synchronization among the tasks, the output may be interspersed depending on the underlying implementation of the task scheduling algorithm.

[Ada]

Listing 2: my_tasks.ads

```
package My_Tasks is
task type My_Task (First : Character);
end My_Tasks;
```

Listing 3: my_tasks.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   package body My Tasks is
3
4
      task body My_Task is
5
      begin
6
          for I in First .. 'Z' loop
7
             Put (I);
8
          end loop;
9
          New_Line;
10
      end My_Task;
11
12
   end My_Tasks;
13
```

Listing 4: main.adb

```
with My_Tasks; use My_Tasks;
procedure Main is
Dummy_Tab : array (0 .. 3) of My_Task ('W');
begin
null;
r end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.My_Task_Type
MD5: 81d88397b0548fdcc1ba31549a8de4fd

Runtime output

WXYZ			
WXYZ			
WXYZ WXYZ			
WXYZ			

In Ada, a task may be dynamically allocated rather than declared statically. The task will then start as soon as it has been allocated, and terminates when its work is completed.

[Ada]

Listing 5: main.adb

```
with My_Tasks; use My_Tasks;
1
2
   procedure Main is
3
      type Ptr_Task is access My_Task;
4
5
      T : Ptr_Task;
6
  begin
7
      T := new My_Task ('W');
8
  end Main;
9
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.My_Task_Type
MD5: d88a96eecf50ebbcdfe9cb870f232a09
```

Runtime output

WXYZ

3.3 Rendezvous

A rendezvous is a synchronization between two tasks, allowing them to exchange data and coordinate execution. Let's consider the following example:

[Ada]

Listing 6: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
4
       task After is
5
          entry Go;
6
7
       end After;
8
       task body After is
9
       begin
10
          accept Go;
11
          Put Line ("After");
12
       end After;
13
14
   begin
15
       Put Line ("Before");
16
       After.Go;
17
   end Main;
18
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Rendezvous
MD5: b0a595bleecac793e40b6d1d41171766

Runtime output

Before After

The Go entry declared in After is the client interface to the task. In the task body, the **accept** statement causes the task to wait for a call on the entry. This particular **entry** and **accept** pair simply causes the task to wait until Main calls After.Go. So, even though the two tasks start simultaneously and execute independently, they can coordinate via Go. Then, they both continue execution independently after the rendezvous.

The **entry**/accept pair can take/pass parameters, and the **accept** statement can contain a sequence of statements; while these statements are executed, the caller is blocked.

Let's look at a more ambitious example. The rendezvous below accepts parameters and executes some code:

[Ada]

Listing 7: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Main is
4
```

```
task After is
5
          entry Go (Text : String);
6
      end After;
7
8
      task body After is
9
      begin
10
          accept Go (Text : String) do
11
             Put_Line ("After: " & Text);
12
          end Go;
13
      end After;
14
15
   begin
16
       Put Line ("Before");
17
      After.Go ("Main");
18
   end Main;
19
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Rendezvous_Params
MD5: 6430e88f5ae349128bb1f1d53f36251e
```

Runtime output

Before After: Main

In the above example, the Put_Line is placed in the accept statement. Here's a possible execution trace, assuming a uniprocessor:

- 1. At the begin of Main, task After is started and the main procedure is suspended.
- 2. After reaches the **accept** statement and is suspended, since there is no pending call on the Go entry.
- 3. The main procedure is awakened and executes the Put_Line invocation, displaying the string "Before".
- 4. The main procedure calls the Go entry. Since After is suspended on its **accept** statement for this entry, the call succeeds.
- 5. The main procedure is suspended, and the task After is awakened to execute the body of the accept statement. The actual parameter "Main" is passed to the accept statement, and the Put_Line invocation is executed. As a result, the string "After: Main" is displayed.
- 6. When the **accept** statement is completed, both the After task and the main procedure are ready to run. Suppose that the Main procedure is given the processor. It reaches its end, but the local task After has not yet terminated. The main procedure is suspended.
- 7. The After task continues, and terminates since it is at its end. The main procedure is resumed, and it too can terminate since its dependent task has terminated.

The above description is a conceptual model; in practice the implementation can perform various optimizations to avoid unnecessary context switches.

3.4 Selective Rendezvous

The **accept** statement by itself can only wait for a single event (call) at a time. The **select** statement allows a task to listen for multiple events simultaneously, and then to deal with the first event to occur. This feature is illustrated by the task below, which maintains an integer value that is modified by other tasks that call Increment, Decrement, and Get:

[Ada]

```
Listing 8: counters.ads
```

```
package Counters is
1
2
      task Counter is
3
         entry Get (Result : out Integer);
4
         entry Increment;
5
         entry Decrement;
6
      end Counter;
7
8
   end Counters;
9
```

```
Listing 9: counters.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   package body Counters is
3
4
       task body Counter is
5
          Value : Integer := 0;
6
       begin
7
          loop
8
             select
9
                 accept Increment do
10
                    Value := Value + 1;
11
                 end Increment;
12
             or
13
                 accept Decrement do
14
                    Value := Value - 1;
15
                 end Decrement;
16
             or
17
                 accept Get (Result : out Integer) do
18
                    Result := Value;
19
                 end Get;
20
             or
21
                 delay 5.0;
22
                 Put_Line ("Exiting Counter task...");
23
                 exit;
24
             end select;
25
          end loop;
26
       end Counter;
27
28
   end Counters;
29
```

```
Listing 10: main.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
   with Counters;
2
                      use Counters;
3
   procedure Main is
4
      V : Integer;
5
   begin
6
      Put_Line ("Main started.");
7
8
      Counter.Get (V);
9
      Put_Line ("Got value. Value = " & Integer'Image (V));
10
11
      Counter.Increment;
12
      Put_Line ("Incremented value.");
13
14
```

```
Counter.Increment;
15
      Put_Line ("Incremented value.");
16
17
      Counter.Get (V);
18
      Put_Line ("Got value. Value = " & Integer'Image (V));
19
20
      Counter.Decrement;
21
      Put_Line ("Decremented value.");
22
23
      Counter.Get (V);
24
      Put Line ("Got value. Value = " & Integer'Image (V));
25
26
      Put Line ("Main finished.");
27
   end Main;
28
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Selective_Rendezvous
MD5: 619d009bcfcd8053bc132b2e32a29249

Runtime output

Main started. Got value. Value = 0 Incremented value. Incremented value. Got value. Value = 2 Decremented value. Got value. Value = 1 Main finished. Exiting Counter task...

When the task's statement flow reaches the select, it will wait for all four events — three entries and a delay — in parallel. If the delay of five seconds is exceeded, the task will execute the statements following the **delay** statement (and in this case will exit the loop, in effect terminating the task). The **accept** bodies for the Increment, Decrement, or Get entries will be otherwise executed as they're called. These four sections of the select statement are mutually exclusive: at each iteration of the loop, only one will be invoked. This is a critical point; if the task had been written as a package, with procedures for the various operations, then a *race condition* could occur where multiple tasks simultaneously calling, say, Increment, cause the value to only get incremented once. In the tasking version, if multiple tasks simultaneously call Increment then only one at a time will be accepted, and the value will be incremented by each of the tasks when it is accepted.

More specifically, each entry has an associated queue of pending callers. If a task calls one of the entries and Counter is not ready to accept the call (i.e., if Counter is not suspended at the **select** statement) then the calling task is suspended, and placed in the queue of the entry that it is calling. From the perspective of the Counter task, at any iteration of the loop there are several possibilities:

- There is no call pending on any of the entries. In this case Counter is suspended. It will be awakened by the first of two events: a call on one of its entries (which will then be immediately accepted), or the expiration of the five second delay (whose effect was noted above).
- There is a call pending on exactly one of the entries. In this case control passes to the select branch with an accept statement for that entry.
- There are calls pending on more than one entry. In this case one of the entries with pending callers is chosen, and then one of the callers is chosen to be de-queued. The choice of which caller to accept depends on the queuing policy, which can be specified

via a **pragma** defined in the Real-Time Systems Annex of the Ada standard; the default is *First-In First-Out*.

3.5 Protected Objects

Although the rendezvous may be used to implement mutually exclusive access to a shared data object, an alternative (and generally preferable) style is through a protected object, an efficiently implementable mechanism that makes the effect more explicit. A protected object has a public interface (its protected operations) for accessing and manipulating the object's components (its private part). Mutual exclusion is enforced through a conceptual lock on the object, and encapsulation ensures that the only external access to the components are through the protected operations.

Two kinds of operations can be performed on such objects: read-write operations by procedures or entries, and read-only operations by functions. The lock mechanism is implemented so that it's possible to perform concurrent read operations but not concurrent write or read/write operations.

Let's reimplement our earlier tasking example with a protected object called Counter:

[Ada]

Listing 11: counters.ads

```
package Counters is
1
2
      protected Counter is
3
          function Get return Integer;
4
          procedure Increment;
5
          procedure Decrement;
6
      private
7
          Value : Integer := 0;
8
      end Counter;
9
10
   end Counters;
11
```

Listing 12: counters.adb

```
package body Counters is
1
2
       protected body Counter is
3
          function Get return Integer is
4
          begin
5
             return Value;
6
          end Get;
7
8
          procedure Increment is
9
          begin
10
              Value := Value + 1;
11
          end Increment;
12
13
          procedure Decrement is
14
          begin
15
              Value := Value - 1;
16
          end Decrement;
17
       end Counter;
18
19
   end Counters;
20
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Protected_Counter MD5: f29f21621dfcf092580f6a130101788e

Having two completely different ways to implement the same paradigm might seem complicated. However, in practice the actual problem to solve usually drives the choice between an active structure (a task) or a passive structure (a protected object).

A protected object can be accessed through prefix notation:

[Ada]

Listing 13: main.adb

```
with Ada.Text IO; use Ada.Text IO;
  with Counters;
                    use Counters;
2
3
  procedure Main is
4
   begin
5
      Counter.Increment;
6
      Counter.Decrement;
7
      Put Line (Integer'Image (Counter.Get));
8
  end Main;
9
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Protected_Counter MD5: 704e3a382fe38caa11ecd3d46fcd2beb

Runtime output

0

A protected object may look like a package syntactically, since it contains declarations that can be accessed externally using prefix notation. However, the declaration of a protected object is extremely restricted; for example, no public data is allowed, no types can be declared inside, etc. And besides the syntactic differences, there is a critical semantic distinction: a protected object has a conceptual lock that guarantees mutual exclusion; there is no such lock for a package.

Like tasks, it's possible to declare protected types that can be instantiated several times:

```
declare
    protected type Counter is
        -- as above
    end Counter;

    protected body Counter is
        -- as above
    end Counter;
    C1 : Counter;
    C1 : Counter;
    C2 : Counter;
    begin
        C1.Increment;
        C2.Decrement;
        ...
end;
```

Protected objects and types can declare a procedure-like operation known as an *entry*. An entry is somewhat similar to a procedure but includes a so-called barrier condition that must be true in order for the entry invocation to succeed. Calling a protected entry is thus a two step process: first, acquire the lock on the object, and then evaluate the barrier condition. If the condition is true then the caller will execute the entry body. If the condition

is false, then the caller is placed in the queue for the entry, and relinquishes the lock. Barrier conditions (for entries with non-empty queues) are reevaluated upon completion of protected procedures and protected entries.

Here's an example illustrating protected entries: a protected type that models a binary semaphore / persistent signal.

[Ada]

Listing 14: binary_semaphores.ads

```
package Binary_Semaphores is
1
2
      protected type Binary Semaphore is
3
          entry Wait;
4
         procedure Signal;
5
      private
6
         Signaled : Boolean := False;
7
8
      end Binary Semaphore;
9
   end Binary_Semaphores;
10
```

Listing 15: binary_semaphores.adb

```
package body Binary_Semaphores is
1
2
      protected body Binary_Semaphore is
3
          entry Wait when Signaled is
4
          begin
5
             Signaled := False;
6
          end Wait;
7
8
9
          procedure Signal is
          begin
10
11
             Signaled := True;
12
          end Signal;
      end Binary_Semaphore;
13
14
   end Binary_Semaphores;
15
```

Listing 16: main.adb

```
with Ada.Text_I0;
                              use Ada.Text_I0;
1
   with Binary_Semaphores; use Binary_Semaphores;
2
3
   procedure Main is
4
      B : Binary_Semaphore;
5
6
      task T1;
7
      task T2;
8
9
      task body T1 is
10
      begin
11
          Put_Line ("Task T1 waiting...");
12
          B.Wait;
13
14
          Put_Line ("Task T1.");
15
          delay 1.0;
16
17
          Put_Line ("Task T1 will signal...");
18
19
          B.Signal;
20
```

```
Put_Line ("Task T1 finished.");
21
       end T1;
22
23
       task body T2 is
24
       begin
25
          Put_Line ("Task T2 waiting...");
26
          B.Wait;
27
28
          Put_Line ("Task T2");
29
          delay 1.0;
30
31
          Put_Line ("Task T2 will signal...");
32
          B.Signal;
33
34
          Put_Line ("Task T2 finished.");
35
       end T2;
36
37
   begin
38
       Put Line ("Main started.");
39
       B.Signal;
40
       Put Line ("Main finished.");
41
   end Main;
42
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Protected_Binary_Semaphore
MD5: aa064a9ec056d44c4217e64cd05726a4

Runtime output

Task T2 waiting... Main started. Main finished. Task T1 waiting... Task T2 Task T2 Task T2 will signal... Task T1. Task T2 finished. Task T1 will signal... Task T1 finished.

Ada concurrency features provide much further generality than what's been presented here. For additional information please consult one of the works cited in the *References* section.

3.6 Ravenscar

The Ravenscar profile is a subset of the Ada concurrency facilities that supports determinism, schedulability analysis, constrained memory utilization, and certification to the highest integrity levels. Four distinct application domains are intended:

- · hard real-time applications requiring predictability,
- · safety-critical systems requiring formal, stringent certification,
- · high-integrity applications requiring formal static analysis and verification,
- embedded applications requiring both a small memory footprint and low execution overhead.

Tasking constructs that preclude analysis, either technically or economically, are disallowed. You can use the **pragma** *Profile* (Ravenscar) to indicate that the Ravenscar restrictions must be observed in your program.

Some of the examples we've seen above will be rejected by the compiler when using the Ravenscar profile. For example:

[Ada]

Listing 17: my_tasks.ads

```
1 package My_Tasks is
2
3 task type My_Task (First : Character);
4
5 end My_Tasks;
```

Listing 18: my_tasks.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   package body My_Tasks is
3
4
      task body My_Task is
5
      begin
6
          for C in First .. 'Z' loop
7
             Put (C);
8
9
          end loop;
          New Line;
10
11
      end My_Task;
12
   end My_Tasks;
13
```

Listing 19: main.adb

```
pragma Profile (Ravenscar);
with My_Tasks; use My_Tasks;
procedure Main is
Tab : array (0 .. 3) of My_Task ('W');
begin
null;
end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Ravenscar
MD5: b7518a039c2b4cecece1de63eeaa208f
```

Build output

```
main.adb:6:04: error: violation of restriction "No_Task_Hierarchy"
main.adb:6:04: error: from profile "Ravenscar" at line 1
gprbuild: *** compilation phase failed
```

This code violates the *No_Task_Hierarchy* restriction of the Ravenscar profile. This is due to the declaration of Tab in the Main procedure. Ravenscar requires task declarations to be done at the library level. Therefore, a simple solution is to create a separate package and reference it in the main application:

[Ada]

Listing 20: my_task_inst.ads

```
with My_Tasks; use My_Tasks;
package My_Task_Inst is
Tab : array (0 .. 3) of My_Task ('W');
end My_Task_Inst;
```

Listing 21: main.adb

```
pragma Profile (Ravenscar);
with My_Task_Inst;
procedure Main is
begin
null;
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Concurrency.Ravenscar MD5: b38943dc1c962b5e691f2b6d9933a3ec

Runtime output

WXYZ WXYZ WXYZ WXYZ

Also, Ravenscar prohibits entries for tasks. For example, we're not allowed to write this declaration:

```
task type My_Task (First : Character) is
    entry Start;
end My_Task;
```

You can use, however, one entry per protected object. As an example, the declaration of the Binary_Semaphore type that we've discussed before compiles fine with Ravenscar:

```
protected type Binary_Semaphore is
    entry Wait;
    procedure Signal;
private
    Signaled : Boolean := False;
end Binary_Semaphore;
```

We could add more procedures and functions to the declaration of Binary_Semaphore, but we wouldn't be able to add another entry when using Ravenscar.

Similar to the previous example with the task array declaration, objects of Binary_Semaphore cannot be declared in the main application:

```
procedure Main is
    B : Binary_Semaphore;
begin
    null;
end Main;
```

This violates the *No_Local_Protected_Objects* restriction. Again, Ravenscar expects this declaration to be done on a library level, so a solution to make this code compile is to have this declaration in a separate package and reference it in the Main procedure.

Ravenscar offers many additional restrictions. Covering those would exceed the scope of this chapter. You can find more examples using the Ravenscar profile on this blog post⁹.

⁹ https://blog.adacore.com/theres-a-mini-rtos-in-my-language

WRITING ADA ON EMBEDDED SYSTEMS

4.1 Understanding the Ada Run-Time

Ada supports a high level of abstractness and expressiveness. In some cases, the compiler translates those constructs directly into machine code. However, there are many high-level constructs for which a direct compilation would be difficult. In those cases, the compiler links to a library containing an implementation of those high-level constructs: this is the so-called run-time library.

One typical example of high-level constructs that can be cumbersome for direct machine code generation is Ada source-code using tasking. In this case, linking to a low-level implementation of multithreading support — for example, an implementation using POSIX threads — is more straightforward than trying to make the compiler generate all the machine code.

In the case of GNAT, the run-time library is implemented using both C and Ada sourcecode. Also, depending on the operating system, the library will interface with low-level functionality from the target operating system.

There are basically two types of run-time libraries:

- the **standard** run-time library: in many cases, this is the run-time library available on desktop operating systems or on some embedded platforms (such as ARM-Linux on a Raspberry-Pi).
- the **configurable** run-time library: this is a capability that is used to create custom run-time libraries for specific target devices.

Configurable run-time libraries are usually used for constrained target devices where support for the full library would be difficult or even impossible. In this case, configurable run-time libraries may support just a subset of the full Ada language. There are many reasons that speak for this approach:

- Some aspects of the Ada language may not translate well to limited operating systems.
- Memory constraints may require reducing the size of the run-time library, so that developers may need to replace or even remove parts of the library.
- When certification is required, those parts of the library that would require too much certification effort can be removed.

When using a configurable run-time library, the compiler checks whether the library supports certain features of the language. If a feature isn't supported, the compiler will give an error message.

You can find further information about the run-time library on this chapter of the GNAT User's Guide Supplement for Cross Platforms¹⁰

¹⁰ https://docs.adacore.com/gnat_ugx-docs/html/gnat_ugx/gnat_ugx/the_gnat_configurable_run_time_facility. html

4.2 Low Level Programming

4.2.1 Representation Clauses

We've seen in the previous chapters how Ada can be used to describe high level semantics and architecture. The beauty of the language, however, is that it can be used all the way down to the lowest levels of the development, including embedded assembly code or bitlevel data management.

One very interesting feature of the language is that, unlike C, for example, there are no data representation constraints unless specified by the developer. This means that the compiler is free to choose the best trade-off in terms of representation vs. performance. Let's start with the following example:

[Ada]

```
type R is record
V : Integer range 0 .. 255;
B1 : Boolean;
B2 : Boolean;
end record
with Pack;
```

[C]

```
struct R {
    unsigned int v:8;
    bool b1;
    bool b2;
};
```

The Ada and the C code above both represent efforts to create an object that's as small as possible. Controlling data size is not possible in Java, but the language does specify the size of values for the primitive types.

Although the C and Ada code are equivalent in this particular example, there's an interesting semantic difference. In C, the number of bits required by each field needs to be specified. Here, we're stating that v is only 8 bits, effectively representing values from 0 to 255. In Ada, it's the other way around: the developer specifies the range of values required and the compiler decides how to represent things, optimizing for speed or size. The Pack aspect declared at the end of the record specifies that the compiler should optimize for size even at the expense of decreased speed in accessing record components. We'll see more details about the Pack aspect in the sections about *bitwise operations* (page 135) and *mapping structures to bit-fields* (page 138) in chapter 6.

Other representation clauses can be specified as well, along with compile-time consistency checks between requirements in terms of available values and specified sizes. This is particularly useful when a specific layout is necessary; for example when interfacing with hardware, a driver, or a communication protocol. Here's how to specify a specific data layout based on the previous example:

[Ada]

```
type R is record
V : Integer range 0 .. 255;
B1 : Boolean;
B2 : Boolean;
end record;
for R use record
-- Occupy the first bit of the first byte.
B1 at 0 range 0 .. 0;
```

```
Occupy the last 7 bits of the first byte,
as well as the first bit of the second byte.
V at 0 range 1 ... 8;
Occupy the second bit of the second byte.
B2 at 1 range 1 ... 1;
end record;
```

We omit the **with** Pack directive and instead use a record representation clause following the record declaration. The compiler is directed to spread objects of type R across two bytes. The layout we're specifying here is fairly inefficient to work with on any machine, but you can have the compiler construct the most efficient methods for access, rather than coding your own machine-dependent bit-level methods manually.

4.2.2 Embedded Assembly Code

When performing low-level development, such as at the kernel or hardware driver level, there can be times when it is necessary to implement functionality with assembly code.

Every Ada compiler has its own conventions for embedding assembly code, based on the hardware platform and the supported assembler(s). Our examples here will work with GNAT and GCC on the x86 architecture.

All x86 processors since the Intel Pentium offer the rdtsc instruction, which tells us the number of cycles since the last processor reset. It takes no inputs and places an unsigned 64-bit value split between the edx and eax registers.

GNAT provides a subprogram called System.Machine_Code.Asm that can be used for assembly code insertion. You can specify a string to pass to the assembler as well as source-level variables to be used for input and output:

[Ada]

Listing 1: get_processor_cycles.adb

```
with System.Machine Code; use System.Machine Code;
1
   with Interfaces;
                               use Interfaces;
2
3
   function Get Processor Cycles return Unsigned 64 is
4
      Low, High : Unsigned 32;
5
      Counter : Unsigned 64;
6
   begin
7
      Asm ("rdtsc",
8
            Outputs =>
9
              (Unsigned 32'Asm Output ("=a", High),
10
               Unsigned 32'Asm Output ("=d", Low)),
11
            Volatile => True);
12
13
      Counter :=
14
         Unsigned 64 (High) * 2 ** 32 +
15
         Unsigned 64 (Low);
16
17
       return Counter;
18
   end Get Processor Cycles;
19
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Assembly_Code
MD5: 092be19e223946ebb9fb9f4786003b94

The Unsigned_32'Asm_Output clauses above provide associations between machine registers and source-level variables to be updated. =a and =d refer to the eax and edx machine registers, respectively. The use of the Unsigned_32 and Unsigned_64 types from package Interfaces ensures correct representation of the data. We assemble the two 32-bit values to form a single 64-bit value.

We set the Volatile parameter to **True** to tell the compiler that invoking this instruction multiple times with the same inputs can result in different outputs. This eliminates the possibility that the compiler will optimize multiple invocations into a single call.

With optimization turned on, the GNAT compiler is smart enough to use the eax and edx registers to implement the High and Low variables, resulting in zero overhead for the assembly interface.

The machine code insertion interface provides many features beyond what was shown here. More information can be found in the GNAT User's Guide, and the GNAT Reference manual.

4.3 Interrupt Handling

Handling interrupts is an important aspect when programming embedded devices. Interrupts are used, for example, to indicate that a hardware or software event has happened. Therefore, by handling interrupts, an application can react to external events.

Ada provides built-in support for handling interrupts. We can process interrupts by attaching a handler — which must be a protected procedure — to it. In the declaration of the protected procedure, we use the Attach_Handler aspect and indicate which interrupt we want to handle.

Let's look into a code example that *traps* the quit interrupt (SIGQUIT) on Linux:

[Ada]

```
with System.OS_Interface;
1
2
   package Signal Handlers is
3
4
      protected type Quit Handler is
5
          function Requested return Boolean;
6
      private
7
          Quit Request : Boolean := False;
8
9
10
          - -
          -- Declaration of an interrupt handler for the "quit" interrupt:
11
12
          procedure Handle_Quit_Signal
13
           with Attach_Handler => System.OS_Interface.SIGQUIT;
14
      end Quit Handler;
15
16
   end Signal Handlers;
17
```

Listing 3: signal handlers.adb

```
with Ada.Text_I0; use Ada.Text_I0;
package body Signal_Handlers is
protected body Quit_Handler is
function Requested return Boolean is
```

```
(Quit_Request);
8
9
          procedure Handle Quit Signal is
10
          begin
11
             Put Line ("Quit request detected!");
12
             Quit_Request := True;
13
          end Handle_Quit_Signal;
14
15
       end Quit_Handler;
16
17
   end Signal Handlers;
18
```

Listing 4: test_quit_handler.adb

```
with Ada.Text IO;
                           use Ada.Text IO;
1
   with Signal Handlers;
2
3
   procedure Test Quit Handler is
4
      Quit : Signal Handlers.Quit Handler;
5
6
   begin
7
      while True loop
8
          delay 1.0;
9
          exit when Quit.Requested;
10
      end loop;
11
12
      Put Line ("Exiting application...");
13
   end Test Quit Handler;
14
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Quit_Handler MD5: d272c5bc59576444e09007a04a615ccf

The specification of the Signal_Handlers package from this example contains the declaration of Quit_Handler, which is a protected type. In the private part of this protected type, we declare the Handle_Quit_Signal procedure. By using the Attach_Handler aspect in the declaration of Handle_Quit_Signal and indicating the quit interrupt (System. OS_Interface.SIGQUIT), we're instructing the operating system to call this procedure for any quit request. So when the user presses CTRL+\ on their keyboard, for example, the application will behave as follows:

- the operating system calls the Handle_Quit_Signal procedure, which displays a message to the user ("Quit request detected!") and sets a Boolean variable — Quit_Request, which is declared in the Quit_Handler type;
- the main application checks the status of the quit handler by calling the Requested function as part of the **while True** loop;
 - This call is in the exit when Quit.Requested line.
 - The Requested function returns **True** in this case because the Quit_Request flag was set by the Handle_Quit_Signal procedure.
- the main applications exits the loop, displays a message and finishes.

Note that the code example above isn't portable because it makes use of interrupts from the Linux operating system. When programming embedded devices, we would use instead the interrupts available on those specific devices.

Also note that, in the example above, we're declaring a static handler at compilation time. If you need to make use of dynamic handlers, which can be configured at runtime, you can

use the subprograms from the Ada. Interrupts package. This package includes not only a version of Attach_Handler as a procedure, but also other procedures such as:

- Exchange_Handler, which lets us exchange, at runtime, the current handler associated with a specific interrupt by a different handler;
- Detach_Handler, which we can use to remove the handler currently associated with a given interrupt.

Details about the Ada. Interrupts package are out of scope for this course. We'll discuss them in a separate, more advanced course in the future. You can find some information about it in the Interrupts appendix of the Ada Reference Manual¹¹.

4.4 Dealing with Absence of FPU with Fixed Point

Many numerical applications typically use floating-point types to compute values. However, in some platforms, a floating-point unit may not be available. Other platforms may have a floating-point unit, but using it in certain numerical algorithms can be prohibitive in terms of performance. For those cases, fixed-point arithmetic can be a good alternative.

The difference between fixed-point and floating-point types might not be so obvious when looking at this code snippet:

[Ada]

Listing 5: fixed_definitions.ads

```
1 package Fixed_Definitions is
2
3 D : constant := 2.0 ** (-31);
4
5 type Fixed is delta D range -1.0 .. 1.0 - D;
6
7 end Fixed_Definitions;
```

Listing 6: show_float_and_fixed_point.adb

```
with Ada.Text_I0;
                            use Ada.Text_I0;
1
2
   with Fixed_Definitions; use Fixed_Definitions;
3
4
   procedure Show Float And Fixed Point is
5
      Float_Value : Float := 0.25;
6
      Fixed_Value : Fixed := 0.25;
7
8
   begin
9
      Float Value := Float Value + 0.25;
10
      Fixed_Value := Fixed_Value + 0.25;
11
12
      Put Line ("Float Value = " & Float'Image (Float Value));
13
      Put Line ("Fixed Value = " & Fixed'Image (Fixed Value));
14
   end Show Float And Fixed Point;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Fixed_Point MD5: 881817bb310304bc285f01454ab446f7

Runtime output

¹¹ http://www.ada-auth.org/standards/12aarm/html/AA-C-3-2.html

Float_Value = 5.00000E-01 Fixed_Value = 0.500000000

In this example, the application will show the value 0.5 for both Float_Value and Fixed Value.

The major difference between floating-point and fixed-point types is in the way the values are stored. Values of ordinary fixed-point types are, in effect, scaled integers. The scaling used for ordinary fixed-point types is defined by the type's small, which is derived from the specified **delta** and, by default, is a power of two. Therefore, ordinary fixed-point types are sometimes called binary fixed-point types. In that sense, ordinary fixed-point types can be thought of being close to the actual representation on the machine. In fact, ordinary fixed-point types make use of the available integer shift instructions, for example.

Another difference between floating-point and fixed-point types is that Ada doesn't provide standard fixed-point types — except for the **Duration** type, which is used to represent an interval of time in seconds. While the Ada standard specifies floating-point types such as **Float** and **Long_Float**, we have to declare our own fixed-point types. Note that, in the previous example, we have used a fixed-point type named Fixed: this type isn't part of the standard, but must be declared somewhere in the source-code of our application.

The syntax for an ordinary fixed-point type is

type <type_name> is delta <delta_value> range <lower_bound> .. <upper_bound>;

By default, the compiler will choose a scale factor, or small, that is a power of 2 no greater than <delta_value>.

For example, we may define a normalized range between -1.0 and 1.0 as following: [Ada]

Listing 7: normalized_fixed_point_type.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Normalized_Fixed_Point_Type is
3
      D : constant := 2.0 ** (-31);
4
      type TQ31 is delta D range -1.0 .. 1.0 - D;
5
   begin
6
      Put Line ("TQ31 requires " & Integer'Image (TQ31'Size) & " bits");
7
      Put Line ("The delta value of TQ31 is " & TQ31'Image (TQ31'Delta));
8
      Put_Line ("The minimum value of TQ31 is " & TQ31'Image (TQ31'First));
9
      Put Line ("The maximum value of TQ31 is " & TQ31'Image (TQ31'Last));
10
   end Normalized Fixed Point Type;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Normalized_Fixed_Point_Type
MD5: 2fe6e9f9bd20d2cfab959d1c0273280b

Runtime output

TQ31 requires 32 bits The delta value of TQ31 is 0.0000000005 The minimum value of TQ31 is -1.0000000000 The maximum value of TQ31 is 0.9999999995

In this example, we are defining a 32-bit fixed-point data type for our normalized range. When running the application, we notice that the upper bound is close to one, but not exactly one. This is a typical effect of fixed-point data types — you can find more details in this discussion about the Q format¹². We may also rewrite this code with an exact type definition:

[Ada]

```
Listing 8: normalized_adapted_fixed_point_type.ads
```

```
package Normalized_Adapted_Fixed_Point_Type is
type TQ31 is delta 2.0 ** (-31) range -1.0 .. 1.0 - 2.0 ** (-31);
end Normalized_Adapted_Fixed_Point_Type;
```

Code block metadata

We may also use any other range. For example:

[Ada]

Listing 9: custom fixed point range.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   with Ada.Numerics; use Ada.Numerics;
2
3
   procedure Custom_Fixed_Point_Range is
4
       type Inv_Trig is delta 2.0 ** (-15) * Pi range -Pi / 2.0 .. Pi / 2.0;
5
   begin
6
       Put_Line ("Inv_Trig requires " & Integer'Image (Inv_Trig'Size)
7
                   & " bits");
8
       Put Line ("The delta
                                   value of Inv Trig is "
9
       & Inv_Trig'Image (Inv_Trig'Delta));
Put_Line ("The minimum value of Inv_Trig is "
10
11
       & Inv_Trig'Image (Inv_Trig'First));
Put_Line ("The maximum value of Inv_Trig is
12
13
                   & Inv_Trig'Image (Inv_Trig'Last));
14
   end Custom_Fixed_Point_Range;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Custom_Fixed_Point_Range
MD5: 0d9a4bc96191d1341bbb1c081555b613

Runtime output

Inv_Trig requires 16 bits The delta value of Inv_Trig is 0.00006 The minimum value of Inv_Trig is -1.57080 The maximum value of Inv_Trig is 1.57080

In this example, we are defining a 16-bit type called Inv_Trig, which has a range from - $\pi/2$ to $\pi/2$.

All standard operations are available for fixed-point types. For example:

[Ada]

¹² https://en.wikipedia.org/wiki/Q_(number_format)

Listing 10: fixed_point_op.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Fixed Point Op is
3
      type TQ31 is delta 2.0 ** (-31) range -1.0 .. 1.0 - 2.0 ** (-31);
4
5
      A, B, R : TQ31;
6
   begin
7
      A := 0.25;
8
      B := 0.50;
9
      R := A + B;
10
      Put Line ("R is " & TQ31'Image (R));
11
   end Fixed_Point_Op;
12
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Fixed_Point_Op
MD5: 78bafd93b25da898c00cc38c9d518e2a
```

Runtime output

R is 0.750000000

As expected, R contains 0.75 after the addition of A and B.

In the case of C, since the language doesn't support fixed-point arithmetic, we need to emulate it using integer types and custom operations via functions. Let's look at this very rudimentary example:

[C]

Listing 11: main.c

```
#include <stdio.h>
1
   #include <math.h>
2
3
   #define SHIFT FACTOR 32
4
5
   #define TO FIXED(x)
                             ((int) ((x) * pow (2.0, SHIFT FACTOR - 1)))
6
   #define TO FLOAT(x)
                             ((float) ((double)(x) * (double)pow (2.0, -(SHIFT FACTOR -
7
    →1))))
8
   typedef int fixed;
9
10
   fixed add (fixed a, fixed b)
11
   {
12
        return a + b;
13
   }
14
15
   fixed mult (fixed a, fixed b)
16
17
   {
        return (fixed)(((long)a * (long)b) >> (SHIFT_FACTOR - 1));
18
   }
19
20
   void display_fixed (fixed x)
21
   {
22
        printf("value (integer) = %d\n",
                                             x);
23
        printf("value (float) = %3.5f\n\n", T0_FLOAT (x));
24
   }
25
26
   int main(int argc, const char * argv[])
27
```

```
{
28
        int fixed_value = T0_FIXED(0.25);
29
30
        printf("Original value\n");
31
        display_fixed(fixed_value);
32
33
        printf("... + 0.25\n");
34
        fixed value = add(fixed value, TO FIXED(0.25));
35
        display_fixed(fixed_value);
36
37
        printf("... * 0.5\n");
38
        fixed_value = mult(fixed_value, T0_FIXED(0.5));
39
        display_fixed(fixed_value);
40
41
        return 0;
42
   }
43
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Fixed_Point_C
MD5: 61016e8fc0dbc4d0eefd2c86915489e5

Runtime output

Original value value (integer) = 536870912 value (float) = 0.25000 ... + 0.25 value (integer) = 1073741824 value (float) = 0.50000 ... * 0.5 value (integer) = 536870912 value (float) = 0.25000

Here, we declare the fixed-point type fixed based on **int** and two operations for it: addition (via the add function) and multiplication (via the mult function). Note that, while fixed-point addition is quite straightforward, multiplication requires right-shifting to match the correct internal representation. In Ada, since fixed-point operations are part of the language specification, they don't need to be emulated. Therefore, no extra effort is required from the programmer.

Also note that the example above is very rudimentary, so it doesn't take some of the sideeffects of fixed-point arithmetic into account. In C, you have to manually take all side-effects deriving from fixed-point arithmetic into account, while in Ada, the compiler takes care of selecting the right operations for you.

4.5 Volatile and Atomic data

Ada has built-in support for handling both volatile and atomic data. Let's start by discussing volatile objects.

4.5.1 Volatile

A volatile¹³ object can be described as an object in memory whose value may change between two consecutive memory accesses of a process A — even if process A itself hasn't changed the value. This situation may arise when an object in memory is being shared by multiple threads. For example, a thread *B* may modify the value of that object between two read accesses of a thread *A*. Another typical example is the one of memory-mapped I/O¹⁴, where the hardware might be constantly changing the value of an object in memory.

Because the value of a volatile object may be constantly changing, a compiler cannot generate code that stores the value of that object into a register and use the value from the register in subsequent operations. Storing into a register is avoided because, if the value is stored there, it would be outdated if another process had changed the volatile object in the meantime. Instead, the compiler generates code in such a way that the process must read the value of the volatile object from memory for each access.

Let's look at a simple example of a volatile variable in C:

[C]

Listing 12: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
        volatile double val = 0.0;
5
        int i;
6
7
        for (i = 0; i < 1000; i++)
8
9
        ł
            val += i * 2.0;
10
        }
11
        printf ("val: %5.3f\n", val);
12
13
        return 0;
14
   }
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Volatile_Object_C
MD5: 863c7dda4acb3286976a1edab29bab08

Runtime output

```
val: 999000.000
```

In this example, val has the modifier **volatile**, which indicates that the compiler must handle val as a volatile object. Therefore, each read and write access in the loop is performed by accessing the value of val in then memory.

This is the corresponding implementation in Ada:

[Ada]

Listing 13: show_volatile_object.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Show_Volatile_Object is
Val : Long_Float with Volatile;
```

 ¹³ https://en.wikipedia.org/wiki/Volatile_(computer_programming)
 ¹⁴ https://en.wikipedia.org/wiki/Memory-mapped_I/O

```
5 begin
6 Val := 0.0;
7 for I in 0 .. 999 loop
8 Val := Val + 2.0 * Long_Float (I);
9 end loop;
10
11 Put_Line ("Val: " & Long_Float'Image (Val));
12 end Show_Volatile_Object;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Volatile_Object_Ada
MD5: aa1e276e64e69813bfc3e3ef39f3dd47
```

Runtime output

Val: 9.990000000000E+05

In this example, Val has the Volatile aspect, which makes the object volatile. We can also use the Volatile aspect in type declarations. For example:

[Ada]

Listing 14: show_volatile_type.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
   procedure Show_Volatile_Type is
3
      type Volatile_Long_Float is new Long_Float with Volatile;
4
5
      Val : Volatile_Long_Float;
6
   begin
7
      Val := 0.0;
8
      for I in 0 .. 999 loop
9
         Val := Val + 2.0 * Volatile_Long_Float (I);
10
      end loop;
11
12
      Put_Line ("Val: " & Volatile_Long_Float'Image (Val));
13
   end Show_Volatile_Type;
14
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Volatile_Type
MD5: 41ecf028803a58ce244c421eaeb118e4

Runtime output

```
Val: 9.990000000000E+05
```

Here, we're declaring a new type Volatile_Long_Float based on the Long_Float type and using the Volatile aspect. Any object of this type is automatically volatile.

In addition to that, we can declare components of an array to be volatile. In this case, we can use the Volatile_Components aspect in the array declaration. For example:

[Ada]

Listing 15: show_volatile_array_components.adb

```
with Ada.Text_I0; use Ada.Text_I0;
```

```
procedure Show_Volatile_Array_Components is
```

(continues on next page)

2

```
Arr : array (1 .. 2) of Long_Float with Volatile_Components;
4
    begin
5
       Arr := (others => 0.0);
6
7
       for I in 0 .. 999 loop
8
           Arr (1) := Arr (1) + 2.0 * Long_Float (I);
9
           Arr (2) := Arr (2) + 10.0 * Long_Float (I);
10
       end loop;
11
12
       Put_Line ("Arr (1): " & Long_Float'Image (Arr (1)));
Put_Line ("Arr (2): " & Long_Float'Image (Arr (2)));
13
14
   end Show_Volatile_Array_Components;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Volatile_Array_Components
MD5: 601d61dd01888c60ae1a51ec513138d5

Runtime output

```
Arr (1): 9.9900000000000E+05
Arr (2): 4.995000000000E+06
```

Note that it's possible to use the Volatile aspect for the array declaration as well:

[Ada]

Arr : array (1 .. 2) of Long_Float with Volatile;

4.5.2 Atomic

An atomic object is an object that only accepts atomic reads and updates. The Ada standard specifies that "for an atomic object (including an atomic component), all reads and updates of the object as a whole are indivisible." In this case, the compiler must generate Assembly code in such a way that reads and updates of an atomic object must be done in a single instruction, so that no other instruction could execute on that same object before the read or update completes.

In other contexts

Generally, we can say that operations are said to be atomic when they can be completed without interruptions. This is an important requirement when we're performing operations on objects in memory that are shared between multiple processes.

This definition of atomicity above is used, for example, when implementing databases. However, for this section, we're using the term "atomic" differently. Here, it really means that reads and updates must be performed with a single Assembly instruction.

For example, if we have a 32-bit object composed of four 8-bit bytes, the compiler cannot generate code to read or update the object using four 8-bit store / load instructions, or even two 16-bit store / load instructions. In this case, in order to maintain atomicity, the compiler must generate code using one 32-bit store / load instruction.

Because of this strict definition, we might have objects for which the Atomic aspect cannot be specified. Lots of machines support integer types that are larger than the native word-sized integer. For example, a 16-bit machine probably supports both 16-bit and 32-bit integers, but only 16-bit integer objects can be marked as atomic — or, more generally, only objects that fit into at most 16 bits.

Atomicity may be important, for example, when dealing with shared hardware registers. In fact, for certain architectures, the hardware may require that memory-mapped registers are handled atomically. In Ada, we can use the Atomic aspect to indicate that an object is atomic. This is how we can use the aspect to declare a shared hardware register:

[Ada]

Listing 16: show shared hw register.adb

```
with System;
1
2
   procedure Show Shared HW Register is
3
      R : Integer
4
        with Atomic, Address => System'To Address (16#FFFF00A0#);
5
  begin
6
      null:
7
  end Show Shared HW Register;
8
```

Code block metadata

```
Project: Courses.Ada For Embedded C Dev.Embedded.Atomic Object
MD5: 7ef148adf393819fc3fbc25eb45afe46
```

Note that the Address aspect allows for assigning a variable to a specific location in the memory. In this example, we're using this aspect to specify the address of the memorymapped register. We'll discuss more about the Address aspect later in the section about mapping structures to bit-fields (page 138) (in chapter 6).

In addition to atomic objects, we can declare atomic types and atomic array components - similarly to what we've seen before for volatile objects. For example:

[Ada]

1

Listing 17: show shared hw register.adb

```
with System;
2
   procedure Show Shared HW Register is
3
      type Atomic Integer is new Integer with Atomic;
4
5
      R : Atomic Integer with Address => System'To Address (16#FFFF00A0#);
6
7
      Arr : array (1 .. 2) of Integer with Atomic Components;
8
   begin
9
      null:
10
   end Show Shared HW Register;
11
```

Code block metadata

Project: Courses.Ada For Embedded C Dev.Embedded.Atomic Types Arrays MD5: 11475b5152087eff7f36abfe2c5ae9a1

In this example, we're declaring the Atomic Integer type, which is an atomic type. Objects of this type — such as R in this example — are automatically atomic. This example also includes the declaration of the Arr array, which has atomic components.

4.6 Interfacing with Devices

Previously, we've seen that we can use representation clauses (page 82) to specify a particular layout for a record type. As mentioned before, this is useful when interfacing with hardware, drivers, or communication protocols. In this section, we'll extend this concept for two specific use-cases: register overlays and data streams. Before we discuss those use-cases, though, we'll first explain the Size aspect and the Size attribute.

4.6.1 Size aspect and attribute

The Size aspect indicates the minimum number of bits required to represent an object. When applied to a type, the Size aspect is telling the compiler to not make record or array components of a type T any smaller than X bits. Therefore, a common usage for this aspect is to just confirm expectations: developers specify 'Size to tell the compiler that T should fit X bits, and the compiler will tell them if they are right (or wrong).

When the specified size value is larger than necessary, it can cause objects to be bigger in memory than they would be otherwise. For example, for some enumeration types, we could say **for type Enum**'Size **use** 32; when the number of literals would otherwise have required only a byte. That's useful for unchecked conversions because the sizes of the two types need to be the same. Likewise, it's useful for interfacing with C, where **enum** types are just mapped to the int type, and thus larger than Ada might otherwise require. We'll discuss unchecked conversions *later in the course* (page 151).

Let's look at an example from an earlier chapter:

[Ada]

Listing 18: my device types.ads

```
1 package My_Device_Types is
2
3 type UInt10 is mod 2 ** 10
4 with Size => 10;
5
6 end My_Device_Types;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Size_Aspect
MD5: 049be992b876dba42cf091afc256db35
```

Here, we're saying that objects of type UInt10 must have at least 10 bits. In this case, if the code compiles, it is a confirmation that such values can be represented in 10 bits when packed into an enclosing record or array type.

If the size specified was larger than what the compiler would use by default, then it could affect the size of objects. For example, for UInt10, anything up to and including 16 would make no difference on a typical machine. However, anything over 16 would then push the compiler to use a larger object representation. That would be important for unchecked conversions, for example.

The Size attribute indicates the number of bits required to represent a type or an object. We can use the size attribute to retrieve the size of a type or of an object:

[Ada]

Listing 19: show_device_types.adb

```
with Ada.Text_I0; use Ada.Text_I0;
with My_Device_Types; use My_Device_Types;
procedure Show_Device_Types is
UInt10_Obj : constant UInt10 := 0;
begin
Put_Line ("Size of UInt10 type: " & Positive'Image (UInt10'Size));
```

```
(continued from previous page)
9 Put_Line ("Size of UInt10 object: " & Positive'Image (UInt10_Obj'Size));
10 end Show_Device_Types;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Perspective.Size_Aspect
MD5: 4e46ad9cf54276b381b960672daa03b9
```

Runtime output

Size of UInt10 type: 10 Size of UInt10 object: 16

Here, we're retrieving the actual sizes of the UInt10 type and an object of that type. Note that the sizes don't necessarily need to match. For example, although the size of UInt10 type is expected to be 10 bits, the size of UInt10_0bj may be 16 bits, depending on the platform. Also, components of this type within composite types (arrays, records) will probably be 16 bits as well unless they are packed.

4.6.2 Register overlays

Register overlays make use of representation clauses to create a structure that facilitates manipulating bits from registers. Let's look at a simplified example of a power management controller containing registers such as a system clock enable register. Note that this example is based on an actual architecture:

[Ada]

Listing 20: registers.ads

```
with System;
1
2
   package Registers is
3
4
                   is mod 2 ** 1
      type Bit
5
        with Size => 1:
6
      type UInt5 is mod 2 ** 5
7
        with Size => 5;
8
      type UInt10 is mod 2 ** 10
9
        with Size => 10;
10
11
      subtype USB Clock Enable is Bit;
12
13
      -- System Clock Enable Register
14
      type PMC SCER Register is record
15
         -- Reserved bits
16
         Reserved 0 4 : UInt5
                                              := 16\#0\#;
17
          -- Write-only. Enable USB FS Clock
18
         USBCLK
                        : USB Clock Enable := 16#0#;
19
          -- Reserved bits
20
         Reserved 6 15 : UInt10
                                            := 16#0#;
21
      end record
22
        with
23
          Volatile,
24
          Size
                     => 16.
25
          Bit_Order => System.Low_Order_First;
26
27
      for PMC_SCER_Register use record
28
          Reserved 0 4 at 0 range 0 ... 4;
29
         USBCLK
                         at 0 range 5 .. 5;
30
```

```
Reserved_6_15 at 0 range 6 .. 15;
31
      end record;
32
33
      -- Power Management Controller
34
      type PMC_Peripheral is record
35
         -- System Clock Enable Register
36
         PMC_SCER
                       : aliased PMC_SCER_Register;
37
             System Clock Disable Register
         - -
38
         PMC_SCDR : aliased PMC_SCER_Register;
39
      end record
40
        with Volatile;
41
42
      for PMC Peripheral use record
43
          -- 16-bit register at byte 0
44
         PMC_SCER
                        at 16#0# range 0 .. 15;
45
             16-bit register at byte 2
46
         - -
         PMC_SCDR
                       at 16#2# range 0 .. 15;
47
      end record;
48
49
      -- Power Management Controller
50
      PMC Periph : aliased PMC Peripheral
51
        with Import, Address => System'To_Address (16#400E0600#);
52
53
   end Registers;
54
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.PMC_Peripheral MD5: d6f37976ca653d65d71ee5ea463df81c

First, we declare the system clock enable register — this is PMC_SCER_Register type in the code example. Most of the bits in that register are reserved. However, we're interested in bit #5, which is used to activate or deactivate the system clock. To achieve a correct representation of this bit, we do the following:

- We declare the USBCLK component of this record using the USB_Clock_Enable type, which has a size of one bit; and
- we use a representation clause to indicate that the USBCLK component is specifically at bit #5 of byte #0.

After declaring the system clock enable register and specifying its individual bits as components of a record type, we declare the power management controller type — PMC_Peripheral record type in the code example. Here, we declare two 16-bit registers as record components of PMC_Peripheral. These registers are used to enable or disable the system clock. The strategy we use in the declaration is similar to the one we've just seen above:

- We declare these registers as components of the PMC_Peripheral record type;
- we use a representation clause to specify that the PMC_SCER register is at byte #0 and the PMC_SCDR register is at byte #2.
 - Since these registers have 16 bits, we use a range of bits from 0 to 15.

The actual power management controller becomes accessible by the declaration of the PMC_Periph object of PMC_Peripheral type. Here, we specify the actual address of the memory-mapped registers (400E0600 in hexadecimal) using the Address aspect in the declaration. When we use the Address aspect in an object declaration, we're indicating the address in memory of that object.

Because we specify the address of the memory-mapped registers in the declaration of PMC_Periph, this object is now an overlay for those registers. This also means that any

operation on this object corresponds to an actual operation on the registers of the power management controller. We'll discuss more details about overlays in the section about *mapping structures to bit-fields* (page 138) (in chapter 6).

Finally, in a test application, we can access any bit of any register of the power management controller with simple record component selection. For example, we can set the USBCLK bit of the PMC_SCER register by using PMC_Periph.PMC_SCER.USBCLK:

[Ada]

Listing 21: enable usb clock.adb

```
with Registers;
procedure Enable_USB_Clock is
begin
Registers.PMC_Periph.PMC_SCER.USBCLK := 1;
end Enable_USB_Clock;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.PMC_Peripheral MD5: b8f35a80d5f04cd362e5309aef33a100

This code example makes use of many aspects and keywords of the Ada language. One of them is the Volatile aspect, which we've discussed in the section about *volatile and atomic objects* (page 90). Using the Volatile aspect for the PMC_SCER_Register type ensures that objects of this type won't be stored in a register.

In the declaration of the PMC_SCER_Register record type of the example, we use the Bit_Order aspect to specify the bit ordering of the record type. Here, we can select one of these options:

- High_Order_First: first bit of the record is the most significant bit;
- Low Order First: first bit of the record is the least significant bit.

The declarations from the Registers package also makes use of the Import, which is sometimes necessary when creating overlays. When used in the context of object declarations, it avoids default initialization (for data types that have it.). Aspect Import will be discussed in the section that explains how to *map structures to bit-fields* (page 138) in chapter 6. Please refer to that chapter for more details.

Details about 'Size

In the example above, we're using the Size aspect in the declaration of the PMC_SCER_Register type. In this case, the effect is that it has the compiler confirm that the record type will fit into the expected 16 bits.

That's what the aspect does for type PMC_SCER_Register in the example above, as well as for the types Bit, UInt5 and UInt10. For example, we may declare a stand-alone object of type Bit:

Listing 22: show_bit_declaration.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Show Bit Declaration is
3
4
      type Bit is mod 2 ** 1
5
        with Size => 1;
6
7
      B : constant Bit := 0;
8
           `Although Bit'Size is 1, B'Size is almost certainly 8
9
   begin
10
     Put Line ("Bit'Size = " & Positive'Image (Bit'Size));
11
12 98 Put_Line ("B'Size = " & Positivapiter 4.(BWriting; Ada on Embedded Systems
  end Show Bit Declaration;
13
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Bit_Declaration
MD5: 1778bb96b4bf77292885bdedfee7c596
```

Runtime output

Bit'Size = 1 B'Size = 8

In this case, B is almost certainly going to be 8-bits wide on a typical machine, even though the language requires that Bit'Size is 1 by default.

In the declaration of the components of the PMC_Peripheral record type, we use the **aliased** keyword to specify that those record components are accessible via other paths besides the component name. Therefore, the compiler won't store them in registers. This makes sense because we want to ensure that we're accessing specific memory-mapped registers, and not registers assigned by the compiler. Note that, for the same reason, we also use the **aliased** keyword in the declaration of the PMC_Periph object.

4.6.3 Data streams

Creating data streams — in the context of interfacing with devices — means the serialization of arbitrary information and its transmission over a communication channel. For example, we might want to transmit the content of memory-mapped registers as byte streams using a serial port. To do this, we first need to get a serialized representation of those registers as an array of bytes, which we can then transmit over the serial port.

Serialization of arbitrary record types — including register overlays — can be achieved by declaring an array of bytes as an overlay. By doing this, we're basically interpreting the information from those record types as bytes while ignoring their actual structure — i.e. their components and representation clause. We'll discuss details about overlays in the section about *mapping structures to bit-fields* (page 138) (in chapter 6).

Let's look at a simple example of serialization of an arbitrary record type:

[Ada]

Listing 23: arbitrary_types.ads

```
package Arbitrary_Types is
1
2
      type Arbitrary Record is record
3
4
         A : Integer;
         B : Integer;
5
         C : Integer;
6
      end record;
7
8
   end Arbitrary_Types;
9
```

Listing 24: serialize data.ads

```
with Arbitrary_Types;
procedure Serialize_Data (Some_Object : Arbitrary_Types.Arbitrary_Record);
```

Listing 25: serialize_data.adb

```
type UByte is new Natural range 0 .. 255
4
        with Size => 8;
5
6
      type UByte_Array is array (Positive range <>) of UByte;
7
8
9
      -- We can access the serialized data in Raw_TX, which is our overlay
10
11
      Raw_TX : UByte_Array (1 .. Some_Object'Size / 8)
12
        with Address => Some_Object'Address;
13
   begin
14
      null;
15
16
          Now, we could stream the data from Some_Object.
17
       - -
18
       - -
       -- For example, we could send the bytes (from Raw_TX) via the
19
       -- serial port.
20
21
   end Serialize_Data;
22
```

Listing 26: data_stream_declaration.adb

```
with Arbitrary_Types;
with Serialize_Data;
procedure Data_Stream_Declaration is
Dummy_Object : Arbitrary_Types.Arbitrary_Record;
begin
Serialize_Data (Dummy_Object);
end Data Stream Declaration;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Data_Stream_Declaration
MD5: 1de6f518520010c28fd8deb29a2bf209

The most important part of this example is the implementation of the Serialize_Data procedure, where we declare Raw_TX as an overlay for our arbitrary object (Some_Object of Arbitrary_Record type). In simple terms, by writing with Address => Some_Object'Address; in the declaration of Raw_TX, we're specifying that Raw_TX and Some_Object have the same address in memory. Here, we are:

- taking the address of Some_Object using the Address attribute —, and then
- using it as the address of Raw TX which is specified with the Address aspect.

By doing this, we're essentially saying that both Raw_TX and Some_Object are different representations of the same object in memory.

Because the Raw_TX overlay is completely agnostic about the actual structure of the record type, the Arbitrary_Record type could really be anything. By declaring Raw_TX, we create an array of bytes that we can use to stream the information from Some_Object.

We can use this approach and create a data stream for the register overlay example that we've seen before. This is the corresponding implementation:

[Ada]

```
Listing 27: registers.ads
```

```
with System;
1
2
   package Registers is
3
4
      type Bit is mod 2 ** 1
5
        with Size => 1;
6
      type UInt5 is mod 2 ** 5
7
        with Size => 5;
8
      type UInt10 is mod 2 ** 10
9
        with Size => 10;
10
11
      subtype USB_Clock_Enable is Bit;
12
13
       -- System Clock Register
14
       type PMC_SCER_Register is record
15
         -- Reserved bits
16
         Reserved_0_4 : UInt5 := 16#0#;
17
          -- Write-only. Enable USB FS Clock
18
          USBCLK
                        : USB_Clock_Enable := 16#0#;
19
          -- Reserved bits
20
         Reserved_6_15 : UInt10 := 16#0#;
21
      end record
22
        with
23
           Volatile,
24
           Size
                     => 16,
25
           Bit_Order => System.Low_Order_First;
26
27
      for PMC_SCER_Register use record
28
          Reserved_0_4 at 0 range 0 .. 4;
29
          USBCLK
                         at 0 range 5 .. 5;
30
          Reserved_6_15 at 0 range 6 .. 15;
31
      end record;
32
33
       -- Power Management Controller
34
      type PMC_Peripheral is record
35
          -- System Clock Enable Register
36
          PMC_SCER
                     : aliased PMC_SCER_Register;
37
              System Clock Disable Register
38
          - -
         PMC SCDR
                         : aliased PMC_SCER_Register;
39
      end record
40
        with Volatile;
41
42
      for PMC_Peripheral use record
43
          -- 16-bit register at byte 0
44
          PMC_SCER
                         at 16#0# range 0 .. 15;
45
          -- 16-bit register at byte 2
46
         PMC_SCDR
                         at 16#2# range 0 .. 15;
47
      end record;
48
49
       -- Power Management Controller
50
      PMC_Periph : aliased PMC_Peripheral;
51
           with Import, Address => System'To_Address (16#400E0600#);
52
53
   end Registers;
54
```

Listing 28: serial ports.ads

package Serial_Ports is

```
2
```

```
type UByte is new Natural range 0 .. 255
3
        with Size => 8;
4
5
      type UByte_Array is array (Positive range <>) of UByte;
6
7
      type Serial_Port is null record;
8
9
      procedure Read (Port : in out Serial_Port;
10
                       Data : out UByte Array);
11
12
      procedure Write (Port : in out Serial_Port;
13
                        Data :
                                       UByte_Array);
14
15
   end Serial_Ports;
16
```

Listing 29: serial_ports.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   package body Serial Ports is
3
4
      procedure Display (Data : UByte_Array) is
5
      begin
6
          Put_Line ("---- Data ----");
7
          for E of Data loop
8
            Put_Line (UByte'Image (E));
9
          end loop;
10
          Put_Line ("-----");
11
12
      end Display;
13
      procedure Read (Port : in out Serial_Port;
14
                       Data : out UByte Array) is
15
          pragma Unreferenced (Port);
16
      begin
17
          Put_Line ("Reading data...");
18
          Data := (0, 0, 32, 0);
19
      end Read;
20
21
      procedure Write (Port : in out Serial Port;
22
                        Data :
                                       UByte_Array) is
23
          pragma Unreferenced (Port);
24
25
      begin
         Put_Line ("Writing data...");
26
          Display (Data);
27
      end Write;
28
29
   end Serial Ports;
30
```

Listing 30: data stream.ads

```
with Serial_Ports; use Serial_Ports;
1
   with Registers;
                      use Registers;
2
3
   package Data_Stream is
4
5
6
      procedure Send (Port : in out Serial_Port;
7
                      PMC :
                                    PMC_Peripheral);
8
      procedure Receive (Port : in out Serial_Port;
9
                          PMC : out PMC_Peripheral);
10
```

```
12 end Data_Stream;
```

11

Listing 31: data_stream.adb

```
package body Data Stream is
1
2
      procedure Send (Port : in out Serial_Port;
3
                        PMC :
                                       PMC Peripheral)
4
      is
5
          Raw_TX : UByte_Array (1 .. PMC'Size / 8)
6
            with Address => PMC'Address;
7
      beain
8
         Write (Port => Port,
9
                 Data => Raw TX);
10
      end Send;
11
12
      procedure Receive (Port : in out Serial Port;
13
                           PMC :
                                     out PMC Peripheral
14
      is
15
          Raw_TX : UByte_Array (1 .. PMC'Size / 8)
16
            with Address => PMC'Address;
17
      begin
18
         Read (Port => Port,
19
                Data => Raw TX);
20
      end Receive;
21
22
   end Data Stream;
23
```

Listing 32: test data stream.adb

```
with Ada.Text_I0;
1
2
   with Registers;
3
   with Data_Stream;
4
   with Serial_Ports;
5
6
   procedure Test_Data_Stream is
7
8
      procedure Display_Registers is
9
         use Ada.Text_I0;
10
      begin
11
         Put_Line ("---- Registers ----");
12
         Put_Line ("PMC_SCER.USBCLK: "
13
                    & Registers.PMC_Periph.PMC_SCER.USBCLK'Image);
14
         Put_Line ("PMC_SCDR.USBCLK: "
15
                    & Registers.PMC_Periph.PMC_SCDR.USBCLK'Image);
16
         Put_Line ("-----");
17
      end Display_Registers;
18
19
      Port : Serial_Ports.Serial_Port;
20
   begin
21
      Registers.PMC Periph.PMC SCER.USBCLK := 1;
22
      Registers.PMC_Periph.PMC_SCDR.USBCLK := 1;
23
24
25
      Display_Registers;
26
      Data_Stream.Send (Port => Port,
27
                         PMC => Registers.PMC_Periph);
28
29
```

```
30 Data_Stream.Receive (Port => Port,
31 PMC => Registers.PMC_Periph);
32 Display_Registers;
34 end Test_Data_Stream;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Embedded.Data_Stream
MD5: 3f4e1a184e52a83b1b9de9e3d5cb43bf

Runtime output

---- Registers ---PMC_SCER.USBCLK: 1
PMC_SCDR.USBCLK: 1
---- Data ---32
0
32
0
Reading data...
---- Registers --PMC_SCER.USBCLK: 0
PMC_SCDR.USBCLK: 1

In this example, we can find the overlay in the implementation of the Send and Receive procedures from the Data_Stream package. Because the overlay doesn't need to know the internals of the PMC_Peripheral type, we're declaring it in the same way as in the previous example (where we created an overlay for Some_Object). In this case, we're creating an overlay for the PMC parameter.

Note that, for this section, we're not really interested in the details about the serial port. Thus, package Serial_Ports in this example is just a stub. However, because the Serial_Port type in that package only *sees* arrays of bytes, after implementing an actual serial port interface for a specific device, we could create data streams for any type.

4.7 ARM and svd2ada

As we've seen in the previous section about *interfacing with devices* (page 94), Ada offers powerful features to describe low-level details about the hardware architecture without giving up its strong typing capabilities. However, it can be cumbersome to create a specification for all those low-level details when you have a complex architecture. Fortunately, for ARM Cortex-M devices, the GNAT toolchain offers an Ada binding generator called **svd2ada**, which takes CMSIS-SVD descriptions for those devices and creates Ada specifications that match the architecture. CMSIS-SVD description files are based on the Cortex Microcontroller Software Interface Standard (CMSIS), which is a hardware abstraction layer for ARM Cortex microcontrollers.

Please refer to the svd2ada project page¹⁵ for details about this tool.

¹⁵ https://github.com/AdaCore/svd2ada

ENHANCING VERIFICATION WITH SPARK AND ADA

5.1 Understanding Exceptions and Dynamic Checks

In Ada, several common programming errors that are not already detected at compile-time are detected instead at run-time, triggering "exceptions" that interrupt the normal flow of execution. For example, an exception is raised by an attempt to access an array component via an index that is out of bounds. This simple check precludes exploits based on buffer overflow. Several other cases also raise language-defined exceptions, such as scalar range constraint violations and null pointer dereferences. Developers may declare and raise their own application-specific exceptions too. (Exceptions are software artifacts, although an implementation may map hardware events to exceptions.)

Exceptions are raised during execution of what we will loosely define as a "frame." A frame is a language construct that has a call stack entry when called, for example a procedure or function body. There are a few other constructs that are also pertinent but this definition will suffice for now.

Frames have a sequence of statements implementing their functionality. They can also have optional "exception handlers" that specify the response when exceptions are "raised" by those statements. These exceptions could be raised directly within the statements, or indirectly via calls to other procedures and functions.

For example, the frame below is a procedure including three exceptions handlers:

Listing 1: p.adb

```
procedure P is
1
   begin
2
      Statements_That_Might_Raise_Exceptions;
3
4
   exception
      when A =>
5
          Handle_A;
6
      when B =>
7
          Handle_B;
8
      when C =>
9
          Handle C;
10
  end P;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Exceptions
MD5: bf7a8740dfca9f3da993f054e22ca97d

The three exception handlers each start with the word **when** (lines 5, 7, and 9). Next comes one or more exception identifiers, followed by the so-called "arrow." In Ada, the arrow always associates something on the left side with something on the right side. In this case, the left side is the exception name and the right side is the handler's code for that exception.

Each handler's code consists of an arbitrary sequence of statements, in this case specific procedures called in response to those specific exceptions. If exception A is raised we call procedure Handle_A (line 6), dedicated to doing the actual work of handling that exception. The other two exceptions are dealt with similarly, on lines 8 and 10.

Structurally, the exception handlers are grouped together and textually separated from the rest of the code in a frame. As a result, the sequence of statements representing the normal flow of execution is distinct from the section representing the error handling. The reserved word **exception** separates these two sections (line 4 above). This separation helps simplify the overall flow, increasing understandability. In particular, status result codes are not required so there is no mixture of error checking and normal processing. If no exception is raised the exception handler section is automatically skipped when the frame exits.

Note how the syntactic structure of the exception handling section resembles that of an Ada case statement. The resemblance is intentional, to suggest similar behavior. When something in the statements of the normal execution raises an exception, the corresponding exception handler for that specific exception is executed. After that, the routine completes. The handlers do not "fall through" to the handlers below. For example, if exception B is raised, procedure Handle_B is called but Handle_C is not called. There's no need for a **break** statement, just as there is no need for it in a case statement. (There's no break statement in Ada anyway.)

So far, we've seen a frame with three specific exceptions handled. What happens if a frame has no handler for the actual exception raised? In that case the run-time library code goes "looking" for one.

Specifically, the active exception is propagated up the dynamic call chain. At each point in the chain, normal execution in that caller is abandoned and the handlers are examined. If that caller has a handler for the exception, the handler is executed. That caller then returns normally to its caller and execution continues from there. Otherwise, propagation goes up one level in the call chain and the process repeats. The search continues until a matching handler is found or no callers remain. If a handler is never found the application terminates abnormally. If the search reaches the main procedure and it has a matching handler it will execute the handler, but, as always, the routine completes so once again the application terminates.

For a concrete example, consider the following:

Listing 2: arrays.ads

```
package Arrays is
type List is array (Natural range <>) of Integer;
function Value (A : List; X, Y : Integer) return Integer;
end Arrays;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Exceptions
MD5: a2dfa05b56144e21d5796d39c88ceac2

Listing 3: arrays.adb

```
package body Arrays is
function Value (A : List; X, Y : Integer) return Integer is
begin
return A (X + Y * 10);
```

```
6 end Value;
7
8 end Arrays;
```

Listing 4: some_process.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   with Arrays;
                      use Arrays;
2
3
   procedure Some Process is
4
      L : constant List (1 .. 100) := (others => 42);
5
   begin
6
      Put Line (Integer'Image (Value (L, 1, 10)));
7
   exception
8
      when Constraint Error =>
9
         Put Line ("Constraint Error caught in Some Process");
10
         Put_Line ("Some_Process completes normally");
11
   end Some Process;
12
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Exceptions
MD5: 7733854601db37eb53f4c4094fe5ca0d

Listing 5: main.adb

```
with Some_Process;
with Ada.Text_I0;
procedure Main is
begin
Some_Process;
Put_Line ("Main completes normally");
end Main;
```

Procedure Main calls Some_Process, which in turn calls function Value (line 7). Some_Process declares the array object L of type List on line 5, with bounds 1 through 100. The call to Value has arguments, including variable L, leading to an attempt to access an array component via an out-of-bounds index (1 + 10 * 10 = 101, beyond the last index of L). This attempt will trigger an exception in Value prior to actually accessing the array object's memory. Function Value doesn't have any exception handlers so the exception is propagated up to the caller Some_Process. Procedure Some_Process has an exception handler for Constraint_Error and it so happens that Constraint_Error is the exception raised in this case. As a result, the code for that handler will be executed, printing some messages on the screen. Then procedure Some_Process will return to Main normally. Main then continues to execute normally after the call to Some_Process and prints its completion message.

If procedure Some_Process had also not had a handler for Constraint_Error, that procedure call would also have returned abnormally and the exception would have been propagated further up the call chain to procedure Main. Normal execution in Main would likewise be abandoned in search of a handler. But Main does not have any handlers so Main would have completed abnormally, immediately, without printing its closing message.

This semantic model is the same as with many other programming languages, in which the execution of a frame's sequence of statements is unavoidably abandoned when an exception becomes active. The model is a direct reaction to the use of status codes returned from functions as in C, where it is all too easy to forget (intentionally or otherwise) to check the status values returned. With the exception model errors cannot be ignored. However, full exception propagation as described above is not the norm for embedded applications when the highest levels of integrity are required. The run-time library code implementing exception propagation can be rather complex and expensive to certify. Those problems apply to the application code too, because exception propagation is a form of control flow without any explicit construct in the source. Instead of the full exception model, designers of high-integrity applications often take alternative approaches.

One alternative consists of deactivating exceptions altogether, or more precisely, deactivating language-defined checks, which means that the compiler will not generate code checking for conditions giving rise to exceptions. Of course, this makes the code vulnerable to attacks, such as buffer overflow, unless otherwise verified (e.g. through static analysis). Deactivation can be applied at the unit level, through the -gnatp compiler switch, or locally within a unit via the pragma Suppress. (Refer to the GNAT User's Guide for Native Platforms¹⁶ for more details about the switch.)

For example, we can write the following. Note the pragma on line 4 of arrays.adb within function Value:

Listing 6: arrays.ads

```
package Arrays is
type List is array (Natural range <>) of Integer;
function Value (A : List; X, Y : Integer) return Integer;
end Arrays;
```

Listing 7: arrays.adb

```
package body Arrays is
1
2
      function Value (A : List; X, Y : Integer) return Integer is
3
         pragma Suppress (All Checks);
4
      begin
5
         return A (X + Y * 10);
6
      end Value;
7
8
  end Arrays;
a
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Exception_Suppress
MD5: 62c37774cbcd5f167858d3b5268006aa

Listing 8: some_process.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
   with Arrays;
                     use Arrays;
2
3
   procedure Some Process is
4
      L : constant List (1 .. 100) := (others => 42);
5
   begin
6
      Put Line (Integer'Image (Value (L, 1, 10)));
7
   exception
8
9
      when Constraint Error =>
         Put_Line ("FAILURE");
10
   end Some_Process;
11
```

This placement of the pragma will only suppress checks in the function body. However,

¹⁶ https://docs.adacore.com/gnat_ugn-docs/html/gnat_ugn/gnat_ugn/building_executable_programs_with_ gnat.html that is where the exception would otherwise have been raised, leading to incorrect and unpredictable execution. (Run the program more than once. If it prints the right answer (42), or even the same value each time, it's just a coincidence.) As you can see, suppressing checks negates the guarantee of errors being detected and addressed at run-time.

Another alternative is to leave checks enabled but not retain the dynamic call-chain propagation. There are a couple of approaches available in this alternative.

The first approach is for the run-time library to invoke a global "last chance handler" (LCH) when any exception is raised. Instead of the sequence of statements of an ordinary exception handler, the LCH is actually a procedure intended to perform "last-wishes" before the program terminates. No exception handlers are allowed. In this scheme "propagation" is simply a direct call to the LCH procedure. The default LCH implementation provided by GNAT does nothing other than loop infinitely. Users may define their own replacement implementation.

The availability of this approach depends on the run-time library. Typically, *Zero Footprint* and *Ravenscar SFP* run-times will provide this mechanism because they are intended for certification.

A user-defined LCH handler can be provided either in C or in Ada, with the following profiles:

[Ada]

```
procedure Last_Chance_Handler (Source_Location : System.Address; Line : Integer);
pragma Export (C,
        Last_Chance_Handler,
        "__gnat_last_chance_handler");
```

[C]

We'll go into the details of the pragma Export in a further section on language interfacing. For now, just know that the symbol __gnat_last_chance_handler is what the run-time uses to branch immediately to the last-chance handler. Pragma Export associates that symbol with this replacement procedure so it will be invoked instead of the default routine. As a consequence, the actual procedure name in Ada is immaterial.

Here is an example implementation that simply blinks an LED forever on the target:

```
procedure Last_Chance_Handler (Msg : System.Address; Line : Integer) is
    pragma Unreferenced (Msg, Line);

    Next_Release : Time := Clock;
    Period : constant Time_Span := Milliseconds (500);
begin
    Initialize_LEDs;
    All_LEDs_Off;

    loop
        Toggle (LCH_LED);
        Next_Release := Next_Release + Period;
        delay until Next_Release;
    end loop;
end Last_Chance_Handler;
```

The LCH_LED is a constant referencing the LED used by the last-chance handler, declared elsewhere. The infinite loop is necessary because a last-chance handler must never return to the caller (hence the term "last-chance"). The LED changes state every half-second.

Unlike the approach in which there is only the last-chance handler routine, the other approach allows exception handlers, but in a specific, restricted manner. Whenever an ex-

ception is raised, the only handler that can apply is a matching handler located in the same frame in which the exception is raised. Propagation in this context is simply an immediate branch instruction issued by the compiler, going directly to the matching handler's sequence of statements. If there is no matching local handler the last chance handler is invoked. For example consider the body of function Value in the body of package Arrays:

```
Listing 9: arrays.ads
```

```
package Arrays is
type List is array (Natural range <>) of Integer;
function Value (A : List; X, Y : Integer) return Integer;
end Arrays;
```

Listing 10: arrays.adb

```
package body Arrays is
1
2
      function Value (A : List; X, Y : Integer) return Integer is
3
      beain
4
         return A (X + Y * 10);
5
      exception
6
7
         when Constraint Error =>
8
             return 0;
      end Value;
9
10
  end Arrays;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Exception_Return
MD5: 1f63b92739deb03529884ab0d25dadb8

Listing 11: some_process.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
   with Arrays;
                     use Arrays;
2
3
   procedure Some Process is
4
     L : constant List (1 .. 100) := (others => 42);
5
   begin
6
7
      Put_Line (Integer'Image (Value (L, 1, 10)));
8
   exception
      when Constraint Error =>
9
         Put_Line ("FAILURE");
10
   end Some_Process;
11
```

In both procedure Some_Process and function Value we have an exception handler for Constraint_Error. In this example the exception is raised in Value because the index check fails there. A local handler for that exception is present so the handler applies and the function returns zero, normally. Because the call to the function returns normally, the execution of Some_Process prints zero and then completes normally.

Let's imagine, however, that function Value did *not* have a handler for Constraint_Error. In the context of full exception propagation, the function call would return to the caller, i.e., Some_Process, and would be handled in that procedure's handler. But only local handlers are allowed under the second alternative so the lack of a local handler in Value would result in the last-chance handler being invoked. The handler for Constraint_Error in Some_Process under this alternative approach.

So far we've only illustrated handling the Constraint_Error exception. It's possible to handle other language-defined and user-defined exceptions as well, of course. It is even possible to define a single handler for all other exceptions that might be encountered in the handled sequence of statements, beyond those explicitly named. The "name" for this otherwise anonymous exception is the Ada reserved word **others**. As in case statements, it covers all other choices not explicitly mentioned, and so must come last. For example:

```
Listing 12: arrays.ads
```

```
1 package Arrays is
2
3 type List is array (Natural range <>) of Integer;
4
5 function Value (A : List; X, Y : Integer) return Integer;
6
7 end Arrays;
```

Listing 13: arrays.adb

```
package body Arrays is
1
2
      function Value (A : List; X, Y : Integer) return Integer is
3
      beain
4
          return A (X + Y * 10);
5
      exception
6
         when Constraint Error =>
7
             return 0;
8
         when others =>
9
             return -1;
10
      end Value;
11
12
   end Arrays;
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Exception_Return_Others
MD5: 7c2ed7efa23242f502a6cf4767da0192

Listing 14: some_process.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
  with Arrays;
                    use Arrays;
2
3
   procedure Some Process is
4
     L : constant List (1 .. 100) := (others => 42);
5
   begin
6
      Put Line (Integer'Image (Value (L, 1, 10)));
7
   exception
8
      when Constraint Error =>
9
         Put_Line ("FAILURE");
10
   end Some_Process;
11
```

In the code above, the Value function has a handler specifically for Constraint_Error as before, but also now has a handler for all other exceptions. For any exception other than Constraint_Error, function Value returns -1. If you remove the function's handler for Constraint_Error (lines 7 and 8) then the other "anonymous" handler will catch the exception and -1 will be returned instead of zero.

There are additional capabilities for exceptions, but for now you have a good basic understanding of how exceptions work, especially their dynamic nature at run-time.

5.2 Understanding Dynamic Checks versus Formal Proof

So far, we have discussed language-defined checks inserted by the compiler for verification at run-time, leading to exceptions being raised. We saw that these dynamic checks verified semantic conditions ensuring proper execution, such as preventing writing past the end of a buffer, or exceeding an application-specific integer range constraint, and so on. These checks are defined by the language because they apply generally and can be expressed in language-defined terms.

Developers can also define dynamic checks. These checks specify component-specific or application-specific conditions, expressed in terms defined by the component or application. We will refer to these checks as "user-defined" for convenience. (Be sure you understand that we are not talking about user-defined *exceptions* here.)

Like the language-defined checks, user-defined checks must be true at run-time. All checks consist of Boolean conditions, which is why we can refer to them as assertions: their conditions are asserted to be true by the compiler or developer.

Assertions come in several forms, some relatively low-level, such as a simple pragma Assert, and some high-level, such as type invariants and contracts. These forms will be presented in detail in a later section, but we will illustrate some of them here.

User-defined checks can be enabled at run-time in GNAT with the -gnata switch, as well as with pragma Assertion_Policy. The switch enables all forms of these assertions, whereas the pragma can be used to control specific forms. The switch is typically used but there are reasonable use-cases in which some user-defined checks are enabled, and others, although defined, are disabled.

By default in GNAT, language-defined checks are enabled but user-defined checks are disabled. Here's an example of a simple program employing a low-level assertion. We can use it to show the effects of the switches, including the defaults:

Listing 15: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      X : Positive := 10;
4
   begin
5
      X := X * 5;
6
      pragma Assert (X > 99);
7
      X := X - 99;
8
      Put Line (Integer'Image (X));
9
   end Main;
10
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Low_Level_Assertion
MD5: 2eb5e1879740cc3914acb8a362995b31
```

If we compiled this code we would get a warning about the assignment on line 8 after the pragma Assert, but not one about the Assert itself on line 7.

gprbuild -q -P main.gpr main.adb:8:11: warning: value not in range of type "Standard.Positive" main.adb:8:11: warning: "Constraint_Error" will be raised at run time

No code is generated for the user-defined check expressed via pragma Assert but the language-defined check is emitted. In this case the range constraint on X excludes zero and negative numbers, but X * 5 = 50, X - 99 = -49. As a result, the check for the last assignment would fail, raising Constraint_Error when the program runs. These results are the expected behavior for the default switch settings.

But now let's enable user-defined checks and build it. Different compiler output will appear.

```
Listing 16: main.adb
```

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
      X : Positive := 10;
4
   begin
5
      X := X * 5;
6
      pragma Assert (X > 99);
7
      X := X - 99;
8
      Put_Line (Integer'Image (X));
9
   end Main;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Assert
MD5: 2eb5e1879740cc3914acb8a362995b31

Build output

```
main.adb:7:19: warning: assertion will fail at run time [-gnatw.a]
main.adb:8:11: warning: value not in range of type "Standard.Positive" [enabled by_
default]
main.adb:8:11: warning: Constraint_Error will be raised at run time [enabled by_
default]
```

Runtime output

raised ADA.ASSERTIONS.ASSERTION_ERROR : main.adb:7

Now we also get the compiler warning about the pragma Assert condition. When run, the failure of pragma Assert on line 7 raises the exception Ada.Assertions. Assertion_Error. According to the expression in the assertion, X is expected (incorrectly) to be above 99 after the multiplication. (The exception name in the error message, SYSTEM.ASSERTIONS.ASSERT_FAILURE, is a GNAT-specific alias for Ada.Assertions. Assertion_Error.)

It's interesting to see in the output that the compiler can detect some violations at compiletime:

main.adb:7:19: warning: assertion will fail at run time main.adb:7:21: warning: condition can only be True if invalid values present main.adb:8:11: warning: value not in range of type "Standard.Positive"

Generally speaking, a complete analysis is beyond the scope of compilers and they may not find all errors prior to execution, even those we might detect ourselves by inspection. More errors can be found by tools dedicated to that purpose, known as static analyzers. But even an automated static analysis tool cannot guarantee it will find all potential problems.

A much more powerful alternative is formal proof, a form of static analysis that can (when possible) give strong guarantees about the checks, for all possible conditions and all possible inputs. Proof can be applied to both language-defined and user-defined checks.

Be sure you understand that formal proof, as a form of static analysis, verifies conditions prior to execution, even prior to compilation. That earliness provides significant cost benefits. Removing bugs earlier is far less expensive than doing so later because the cost to fix bugs increases exponentially over the phases of the project life cycle, especially after deployment. Preventing bug introduction into the deployed system is the least expensive approach of all. Furthermore, cost savings during the initial development will be possible as well, for reasons specific to proof. We will revisit this topic later in this section. Formal analysis for proof can be achieved through the SPARK subset of the Ada language combined with the **gnatprove** verification tool. SPARK is a subset encompassing most of the Ada language, except for features that preclude proof. As a disclaimer, this course is not aimed at providing a full introduction to proof and the SPARK language, but rather to present in a few examples what it is about and what it can do for us.

As it turns out, our procedure Main is already SPARK compliant so we can start verifying it.

Listing 17: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
    procedure Main is
3
       X : Positive := 10;
4
    begin
5
       X := X * 5;
6
       pragma Assert (X > 99);
7
       X := X - 99;
8
       Put_Line (Integer'Image (X));
9
    end Main;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Assert
MD5: 98cad2c7e7b7a12740db013727f01d45

Build output

Prover output

```
Phase 1 of 3: generation of data representation information ...
generation of data representation information failed
continuing analysis with partial data representation
for details, see log file gnatprove/data_representation_generation.log
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: flow analysis and proof ...
main.adb:7:20: medium: assertion might fail
gnatprove: unproved check messages considered as errors
```

Runtime output

raised ADA.ASSERTIONS.ASSERTION_ERROR : main.adb:7

The "Prove" button invokes **gnatprove** on main.adb. You can ignore the parameters to the invocation. For the purpose of this demonstration, the interesting output is this message:

main.adb:7:19: medium: assertion might fail, cannot prove X > 99 (e.g. when X = 50)

gnatprove can tell that the assertion X > 99 may have a problem. There's indeed a bug here, and **gnatprove** even gives us the counterexample (when X is 50). As a result the code is not proven and we know we have an error to correct.

Notice that the message says the assertion "might fail" even though clearly **gnatprove** has an example for when failure is certain. That wording is a reflection of the fact that SPARK gives strong guarantees when the assertions are proven to hold, but does not guarantee that flagged problems are indeed problems. In other words, **gnatprove** does not give false positives but false negatives are possible. The result is that if **gnatprove** does not indicate a problem for the code under analysis we can be sure there is no problem, but if **gnatprove** does indicate a problem the tool may be wrong.

5.3 Initialization and Correct Data Flow

An immediate benefit from having our code compatible with the SPARK subset is that we can ask **gnatprove** to verify initialization and correct data flow, as indicated by the absence of messages during SPARK "flow analysis." Flow analysis detects programming errors such as reading uninitialized data, problematic aliasing between formal parameters, and data races between concurrent tasks.

In addition, **gnatprove** checks unit specifications for the actual data read or written, and the flow of information from inputs to outputs. As you can imagine, this verification provides significant benefits, and it can be reached with comparatively low cost.

For example, the following illustrates an initialization failure:

Listing 18: main.adb

```
with Increment;
1
  with Ada.Text IO; use Ada.Text IO;
2
З
  procedure Main is
4
      B : Integer;
5
  begin
6
7
      Increment (B);
      Put Line (B'Image);
8
  end Main;
a
```

Listing 19: increment.adb

```
1 procedure Increment (Value : in out Integer) is
2 begin
3 Value := Value + 1;
4 end Increment;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_0
MD5: 06d432a84d94635bb7bddafd9574a748
```

Prover output

```
Phase 1 of 3: generation of data representation information ...
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: analysis of data and information flow ...
main.adb:7:15: high: "B" is not initialized
gnatprove: unproved check messages considered as errors
```

Granted, Increment is a silly procedure as-is, but imagine it did useful things, and, as part of that, incremented the argument. **gnatprove** tells us that the caller has not assigned a value to the argument passed to Increment.

Consider this next routine, which contains a serious coding error. Flow analysis will find it for us.

Listing 20: compute_offset.adb

```
with Ada.Numerics.Elementary Functions; use Ada.Numerics.Elementary Functions;
1
2
   procedure Compute Offset (K : Float; Z : out Integer; Flag : out Boolean) is
3
      X : constant Float := Sin (K);
4
   begin
5
      if X < 0.0 then
6
         Z := 0;
7
         Flag := True;
8
      elsif X > 0.0 then
9
         Z := 1;
10
         Flag := True;
11
      else
12
         Flag := False;
13
      end if;
14
   end Compute_Offset;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_1
MD5: af7f16a9c83359c49fde44ed4796c8ec

Prover output

Phase 1 of 3: generation of data representation information ... Phase 2 of 3: generation of Global contracts ... Phase 3 of 3: analysis of data and information flow ... compute_offset.adb:3:38: medium: "Z" might not be initialized in "Compute_Offset" □ □[reason for check: OUT parameter should be initialized on return] [possible fix: □ □ □initialize "Z" on all paths or make "Z" an IN OUT parameter] gnatprove: unproved check messages considered as errors

gnatprove tells us that Z might not be initialized (assigned a value) in Compute_Offset, and indeed that is correct. Z is a mode **out** parameter so the routine should assign a value to it: Z is an output, after all. The fact that Compute_Offset does not do so is a significant and nasty bug. Why is it so nasty? In this case, formal parameter Z is of the scalar type **Integer**, and scalar parameters are always passed by copy in Ada and SPARK. That means that, when returning to the caller, an integer value is copied to the caller's argument passed to Z. But this procedure doesn't always assign the value to be copied back, and in that case an arbitrary value — whatever is on the stack — is copied to the caller's argument. The poor programmer must debug the code to find the problem, yet the effect could appear well downstream from the call to Compute_Offset. That's not only painful, it is expensive. Better to find the problem before we even compile the code.

5.4 Contract-Based Programming

So far, we've seen assertions in a routine's sequence of statements, either through implicit language-defined checks (is the index in the right range?) or explicit user-defined checks. These checks are already useful by themselves but they have an important limitation: the assertions are in the implementation, hidden from the callers of the routine. For example, a call's success or failure may depend upon certain input values but the caller doesn't have that information.

Generally speaking, Ada and SPARK put a lot of emphasis on strong, complete specifications for the sake of abstraction and analysis. Callers need not examine the implementations to determine whether the arguments passed to it are changed, for example. It is possible to go beyond that, however, to specify implementation constraints and functional requirements. We use contracts to do so. At the language level, contracts are higher-level forms of assertions associated with specifications and declarations rather than sequences of statements. Like other assertions they can be activated or deactivated at run-time, and can be statically proven. We'll concentrate here on two kinds of contracts, both associated especially (but not exclusively) with procedures and functions:

- *Preconditions*, those Boolean conditions required to be true *prior* to a call of the corresponding subprogram
- *Postconditions*, those Boolean conditions required to be true *after* a call, as a result of the corresponding subprogram's execution

In particular, preconditions specify the initial conditions, if any, required for the called routine to correctly execute. Postconditions, on the other hand, specify what the called routine's execution must have done, at least, on normal completion. Therefore, preconditions are obligations on callers (referred to as "clients") and postconditions are obligations on implementers. By the same token, preconditions are guarantees to the implementers, and postconditions are guarantees to clients.

Contract-based programming, then, is the specification and rigorous enforcement of these obligations and guarantees. Enforcement is rigorous because it is not manual, but tool-based: dynamically at run-time with exceptions, or, with SPARK, statically, prior to build.

Preconditions are specified via the "Pre" aspect. Postconditions are specified via the "Post" aspect. Usually subprograms have separate declarations and these aspects appear with those declarations, even though they are *about* the bodies. Placement on the declarations allows the obligations and guarantees to be visible to all parties. For example:

Listing 21: mid.ads

```
1 function Mid (X, Y : Integer) return Integer with
2 Pre => X + Y /= 0,
3 Post => Mid'Result > X;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_2
MD5: 0fb78847a167d9318b00667c59a7038d
```

The precondition on line 2 specifies that, for any given call, the sum of the values passed to parameters X and Y must not be zero. (Perhaps we're dividing by X + Y in the body.) The declaration also provides a guarantee about the function call's result, via the postcondition on line 3: for any given call, the value returned will be greater than the value passed to X.

Consider a client calling this function:

Listing 22: demo.adb

```
with Mid:
1
   with Ada.Text IO; use Ada.Text IO;
2
3
   procedure Demo is
4
      A, B, C : Integer;
5
   begin
6
      A := Mid (1, 2);
7
      B := Mid (1, -1);
8
      C := Mid (A, B);
9
      Put_Line (C'Image);
10
   end Demo:
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_2
MD5: 3e0617d4b1c14b37a81377456bf73eb5

Prover output

Phase 1 of 3: generation of data representation information ... generation of data representation information failed continuing analysis with partial data representation for details, see log file gnatprove/data_representation_generation.log Phase 2 of 3: generation of Global contracts ... Phase 3 of 3: flow analysis and proof ... demo.adb:8:09: medium: precondition might fail gnatprove: unproved check messages considered as errors

gnatprove indicates that the assignment to B (line 8) might fail because of the precondition, i.e., the sum of the inputs shouldn't be 0, yet -1 + 1 = 0. (We will address the other output message elsewhere.)

Let's change the argument passed to Y in the second call (line 8). Instead of -1 we will pass -2:

Listing 23: demo.adb

```
with Mid;
1
  with Ada.Text_IO; use Ada.Text_IO;
2
3
  procedure Demo is
4
      A, B, C : Integer;
5
  begin
6
      A := Mid (1, 2);
7
      B := Mid (1, -2);
8
      C := Mid (A, B);
9
      Put Line (C'Image);
10
  end Demo;
11
```

Listing 24: mid.ads

```
1 function Mid (X, Y : Integer) return Integer with
2 Pre => X + Y /= 0,
3 Post => Mid'Result > X;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_3
MD5: 496937d76e16ba524f98f5a94398e929

Prover output

```
Phase 1 of 3: generation of data representation information ...
generation of data representation information failed
continuing analysis with partial data representation
for details, see log file gnatprove/data_representation_generation.log
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: flow analysis and proof ...
```

The second call will no longer be flagged for the precondition. In addition, **gnatprove** will know from the postcondition that A has to be greater than 1, as does B, because in both calls 1 was passed to X. Therefore, **gnatprove** can deduce that the precondition will hold for the third call C := Mid (A, B); because the sum of two numbers greater than 1 will never be zero.

Postconditions can also compare the state prior to a call with the state after a call, using

the 'Old attribute. For example:

Listing 25: increment.ads

```
procedure Increment (Value : in out Integer) with
Pre => Value < Integer'Last,
Post => Value = Value'Old + 1;
```

```
Listing 26: increment.adb
```

```
procedure Increment (Value : in out Integer) is
begin
Value := Value + 1;
end Increment;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_4
MD5: b879dcff91cb4fbce5501474b7f2e732
```

Prover output

```
Phase 1 of 3: generation of data representation information ...
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: flow analysis and proof ...
```

The postcondition specifies that, on return, the argument passed to the parameter Value will be one greater than it was immediately prior to the call (Value '0ld).

5.5 Replacing Defensive Code

One typical benefit of contract-based programming is the removal of defensive code in subprogram implementations. For example, the *Push* operation for a stack type would need to ensure that the given stack is not already full. The body of the routine would first check that, explicitly, and perhaps raise an exception or set a status code. With preconditions we can make the requirement explicit and **gnatprove** will verify that the requirement holds at all call sites.

This reduction has a number of advantages:

- The implementation is simpler, removing validation code that is often difficult to test, makes the code more complex and leads to behaviors that are difficult to define.
- The precondition documents the conditions under which it's correct to call the subprogram, moving from an implementer responsibility to mitigate invalid input to a user responsibility to fulfill the expected interface.
- Provides the means to verify that this interface is properly respected, through code review, dynamic checking at run-time, or formal static proof.

As an example, consider a procedure Read that returns a component value from an array. Both the Data and Index are objects visible to the procedure so they are not formal parameters.

Listing 27: p.ads

```
1 package P is
2
3 type List is array (Integer range <>) of Character;
4
5 Data : List (1 .. 100);
```

```
6 Index : Integer := Data'First;
7 8 procedure Read (V : out Character);
9 end P;
```

Listing 28: p.adb

```
package body P is
1
2
      procedure Read (V : out Character) is
3
      begin
4
          if Index not in Data'Range then
5
             V := Character'First:
6
             return;
7
          end if;
8
9
          V := Data (Index);
10
          Index := Index + 1;
11
      end Read;
12
   end P;
13
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Defensive
MD5: 4b4767100079b228f4f3c630d267ec53
```

Prover output

```
Phase 1 of 3: generation of data representation information ...
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: flow analysis and proof ...
```

In addition to procedure Read we would also have a way to load the array components in the first place, but we can ignore that for the purpose of this discussion.

Procedure Read is responsible for reading an element of the array and then incrementing the index. What should it do in case of an invalid index? In this implementation there is defensive code that returns a value arbitrarily chosen. We could also redesign the code to return a status in this case, or — better — raise an exception.

An even more robust approach would be instead to ensure that this subprogram is only called when Index is within the indexing boundaries of Data. We can express that requirement with a precondition (line 9).

Listing 29: p.ads

```
package P is
1
2
      type List is array (Integer range <>) of Character;
3
4
      Data : List (1 .. 100);
5
      Index : Integer := 1;
6
7
      procedure Read (V : out Character)
8
        with Pre => Index in Data'Range;
9
10
   end P;
11
```

Listing 30: p.adb

```
package body P is
procedure Read (V : out Character) is
begin
V := Data (Index);
Index := Index + 1;
end Read;
end P;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Defensive
MD5: 9646614c34d191be51b4522c972538aa
```

Prover output

```
Phase 1 of 3: generation of data representation information ...
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: flow analysis and proof ...
```

Now we don't need the defensive code in the procedure body. That's safe because SPARK will attempt to prove statically that the check will not fail at the point of each call.

Assuming that procedure Read is intended to be the only way to get values from the array, in a real application (where the principles of software engineering apply) we would take advantage of the compile-time visibility controls that packages offer. Specifically, we would move all the variables' declarations to the private part of the package, or even the package body, so that client code could not possibly access the array directly. Only procedure Read would remain visible to clients, thus remaining the only means of accessing the array. However, that change would entail others, and in this chapter we are only concerned with introducing the capabilities of SPARK. Therefore, we keep the examples as simple as possible.

5.6 Proving Absence of Run-Time Errors

Earlier we said that **gnatprove** will verify both language-defined and user-defined checks. Proving that the language-defined checks will not raise exceptions at run-time is known as proving "Absence of Run-Time Errors" or AoRTE for short. Successful proof of these checks is highly significant in itself.

One of the major resulting benefits is that we can deploy the final executable with checks disabled. That has obvious performance benefits, but it is also a safety issue. If we disable the checks we also disable the run-time library support for them, but in that case the language does not define what happens if indeed an exception is raised. Formally speaking, anything could happen. We must have good reason for thinking that exceptions cannot be raised.

This is such an important issue that proof of AoRTE can be used to comply with the objectives of certification standards in various high-integrity domains (for example, DO-178B/C in avionics, EN 50128 in railway, IEC 61508 in many safety-related industries, ECSS-Q-ST-80C in space, IEC 60880 in nuclear, IEC 62304 in medical, and ISO 26262 in automotive).

As a result, the quality of the program can be guaranteed to achieve higher levels of integrity than would be possible in other programming languages.

However, successful proof of AoRTE may require additional assertions, especially preconditions. We can see that with procedure Increment, the procedure that takes an Integer

argument and increments it by one. But of course, if the incoming value of the argument is the largest possible positive value, the attempt to increment it would overflow, raising Constraint_Error. (As you have likely already concluded, Constraint_Error is the most common exception you will have to deal with.) We added a precondition to allow only the integer values up to, but not including, the largest positive value:

Listing 31: increment.ads

```
procedure Increment (Value : in out Integer) with
Pre => Value < Integer'Last,
Post => Value = Value'Old + 1;
```

Listing 32: increment.adb

```
procedure Increment (Value : in out Integer) is
begin
Value := Value + 1;
end Increment;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.SPARK.Contracts_5
MD5: b879dcff91cb4fbce5501474b7f2e732
```

Prover output

```
Phase 1 of 3: generation of data representation information ...
Phase 2 of 3: generation of Global contracts ...
Phase 3 of 3: flow analysis and proof ...
```

Prove it, then comment-out the precondition and try proving it again. Not only will **gnat-prove** tell us what is wrong, it will suggest a solution as well.

Without the precondition the check it provides would have to be implemented as defensive code in the body. One or the other is critical here, but note that we should never need both.

5.7 Proving Abstract Properties

The postcondition on Increment expresses what is, in fact, a unit-level requirement. Successfully proving such requirements is another significant robustness and cost benefit. Together with the proofs for initialization and AoRTE, these proofs ensure program integrity, that is, the program executes within safe boundaries: the control flow of the program is correctly programmed and cannot be circumvented through run-time errors, and data cannot be corrupted.

We can go even further. We can use contracts to express arbitrary abstract properties when such exist. Safety and security properties, for instance, could be expressed as postconditions and then proven by **gnatprove**.

For example, imagine we have a procedure to move a train to a new position on the track, and we want to do so safely, without leading to a collision with another train. Procedure Move, therefore, takes two inputs: a train identifier specifying which train to move, and the intended new position. The procedure's output is a value indicating a motion command to be given to the train in order to go to that new position. If the train cannot go to that new position safely the output command is to stop the train. Otherwise the command is for the train to continue at an indicated speed:

type Move_Result is (Full_Speed, Slow_Down, Keep_Going, Stop);

procedure Move

```
(Train : in Train_Id;
    New_Position : in Train_Position;
    Result : out Move_Result)
with
    Pre => Valid_Id (Train) and
        Valid_Move (Trains (Train), New_Position) and
        At_Most_One_Train_Per_Track and
        Safe_Signaling,
    Post => At_Most_One_Train_Per_Track and
        Safe_Signaling;
function At_Most_One_Train_Per_Track return Boolean;
function Safe_Signaling return Boolean;
```

The preconditions specify that, given a safe initial state and a valid move, the result of the call will also be a safe state: there will be at most one train per track section and the track signaling system will not allow any unsafe movements.

5.8 Final Comments

Make sure you understand that **gnatprove** does not attempt to prove the program correct as a whole. It attempts to prove language-defined and user-defined assertions about parts of the program, especially individual routines and calls to those routines. Furthermore, **gnatprove** proves the routines correct only to the extent that the user-defined assertions correctly and sufficiently describe and constrain the implementation of the corresponding routines.

Although we are not proving whole program correctness, as you will have seen — and done — we can prove properties than make our software far more robust and bug-free than is possible otherwise. But in addition, consider what proving the unit-level requirements for your procedures and functions would do for the cost of unit testing and system integration. The tests would pass the first time.

However, within the scope of what SPARK can do, not everything can be proven. In some cases that is because the software behavior is not amenable to expression as boolean conditions (for example, a mouse driver). In other cases the source code is beyond the capabilities of the analyzers that actually do the mathematical proof. In these cases the combination of proof and actual test is appropriate, and still less expensive that testing alone.

There is, of course, much more to be said about what can be done with SPARK and **gnat**-**prove**. Those topics are reserved for the Introduction to SPARK course.

C TO ADA TRANSLATION PATTERNS

6.1 Naming conventions and casing considerations

One question that may arise relatively soon when converting from C to Ada is the style of source code presentation. The Ada language doesn't impose any particular style and for many reasons, it may seem attractive to keep a C-like style — for example, camel casing — to the Ada program.

However, the code in the Ada language standard, most third-party code, and the libraries provided by GNAT follow a specific style for identifiers and reserved words. Using a different style for the rest of the program leads to inconsistencies, thereby decreasing readability and confusing automatic style checkers. For those reasons, it's usually advisable to adopt the Ada style — in which each identifier starts with an upper case letter, followed by lower case letters (or digits), with an underscore separating two "distinct" words within the identifier. Acronyms within identifiers are in upper case. For example, there is a language-defined package named Ada.Text_I0. Reserved words are all lower case.

Following this scheme doesn't preclude adding additional, project-specific rules.

6.2 Manually interfacing C and Ada

Before even considering translating code from C to Ada, it's worthwhile to evaluate the possibility of keeping a portion of the C code intact, and only translating selected modules to Ada. This is a necessary evil when introducing Ada to an existing large C codebase, where re-writing the entire code upfront is not practical nor cost-effective.

Fortunately, Ada has a dedicated set of features for interfacing with other languages. The Interfaces package hierarchy and the pragmas Convention, Import, and Export allow you to make inter-language calls while observing proper data representation for each language.

Let's start with the following C code:

[C]

Listing 1: call.c

```
#include <stdio.h>
1
2
   struct my struct {
3
       int A, B;
4
  };
5
6
   void call (struct my struct *p) {
7
       printf ("%d", p->A);
8
   }
9
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.My_Struct_C
MD5: 67053ec329fa4dfcbd8d6125589b9fcb

To call that function from Ada, the Ada compiler requires a description of the data structure to pass as well as a description of the function itself. To capture how the C **struct my_struct** is represented, we can use the following record along with a **pragma** *Convention*. The pragma directs the compiler to lay out the data in memory the way a C compiler would.

[Ada]

Listing 2: use_my_struct.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   with Interfaces.C;
2
3
   procedure Use My Struct is
4
5
      type my_struct is record
6
         A : Interfaces.C.int;
7
         B : Interfaces.C.int;
8
      end record;
9
      pragma Convention (C, my struct);
10
11
      V : my_struct := (A => 1, B => 2);
12
13
   begin
      Put Line ("V = ("
14
                 & Interfaces.C.int'Image (V.A)
15
                 & Interfaces.C.int'Image (V.B)
16
                 & ")");
17
   end Use_My_Struct;
18
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.My_Struct_Ada
MD5: d19942018679df6fbab99f1c6bfdebc8

Runtime output

V = (1 2)

Describing a foreign subprogram call to Ada code is called *binding* and it is performed in two stages. First, an Ada subprogram specification equivalent to the C function is coded. A C function returning a value maps to an Ada function, and a void function maps to an Ada procedure. Then, rather than implementing the subprogram using Ada code, we use a **pragma** *Import*:

```
procedure Call (V : my_struct);
pragma Import (C, Call, "call"); -- Third argument optional
```

The Import pragma specifies that whenever Call is invoked by Ada code, it should invoke the Call function with the C calling convention.

And that's all that's necessary. Here's an example of a call to Call:

[Ada]

Listing 3: use_my_struct.adb

```
with Interfaces.C;
```

```
procedure Use My Struct is
```

(continues on next page)

2

```
4
      type my_struct is record
5
         A : Interfaces.C.int;
6
         B : Interfaces.C.int;
7
      end record;
8
      pragma Convention (C, my_struct);
9
10
      procedure Call (V : my_struct);
11
      pragma Import (C, Call, "call"); -- Third argument optional
12
13
      V : my struct := (A => 1, B => 2);
14
   begin
15
      Call (V);
16
   end Use_My_Struct;
17
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.My_Struct
MD5: 9b54edadd406c7f5a2b9f8b8f82a4a88
```

6.3 Building and Debugging mixed language code

The easiest way to build an application using mixed C / Ada code is to create a simple project file for **gprbuild** and specify C as an additional language. By default, when using **gprbuild** we only compile Ada source files. To compile C code files as well, we use the Languages attribute and specify c as an option, as in the following example of a project file named *default.gpr*:

```
project Default is
    for Languages use ("ada", "c");
    for Main use ("main.adb");
```

end Default;

Then, we use this project file to build the application by simply calling gprbuild. Alternatively, we can specify the project file on the command-line with the -P option — for example, gprbuild -P default.gpr. In both cases, gprbuild compiles all C source-code file found in the directory and links the corresponding object files to build the executable.

In order to include debug information, you can use gprbuild -cargs -g. This option adds debug information based on both C and Ada code to the executable. Alternatively, you can specify a Builder package in the project file and include global compilation switches for each language using the Global_Compilation_Switches attribute. For example:

```
project Default is
for Languages use ("ada", "c");
for Main use ("main.adb");
package Builder is
for Global_Compilation_Switches ("Ada") use ("-g");
for Global_Compilation_Switches ("C") use ("-g");
end Builder;
```

end Default;

In this case, you can simply run gprbuild -P default.gpr to build the executable.

To debug the executable, you can use programs such as **gdb** or **ddd**, which are suitable for debugging both C and Ada source-code. If you prefer a complete IDE, you may want to look into **GNAT Studio**, which supports building and debugging an application within a single environment, and remotely running applications loaded to various embedded devices. You can find more information about **gprbuild** and **GNAT Studio** in the Introduction to GNAT Toolchain course.

6.4 Automatic interfacing

It may be useful to start interfacing Ada and C by using automatic binding generators. These can be done either by invoking **gcc** - fdump-ada-spec option (to generate an Ada binding to a C header file) or -gnatceg option (to generate a C binding to an Ada specification file). For example:

gcc -c -fdump-ada-spec my_header.h
gcc -c -gnatceg spec.ads

The level of interfacing is very low level and typically requires either massaging (changing the generated files) or wrapping (calling the generated files from a higher level interface). For example, numbers bound from C to Ada are only standard numbers where user-defined types may be desirable. C uses a lot of by-pointer parameters which may be better replaced by other parameter modes, etc.

However, the automatic binding generator helps having a starting point which ensures compatibility of the Ada and the C code.

6.5 Using Arrays in C interfaces

It is relatively straightforward to pass an array from Ada to C. In particular, with the GNAT compiler, passing an array is equivalent to passing a pointer to its first element. Of course, as there's no notion of boundaries in C, the length of the array needs to be passed explicitly. For example:

[C]

Listing 4: p.h

void p (int * a, int length);

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Arr_1
MD5: 123353e301a3d43016d2799855e6732a
```

[Ada]

Listing 5: main.adb

```
procedure Main is
1
      type Arr is array (Integer range <>) of Integer;
2
3
      procedure P (V : Arr; Length : Integer);
4
      pragma Import (C, P);
5
6
      X : Arr (5 .. 15);
7
   begin
8
      P (X, X'Length);
9
   end Main;
10
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Arr_1
MD5: 9bfbc0f31da4554a1e1dea1ba2b1d305
```

The other way around — that is, retrieving an array that has been creating on the C side — is more difficult. Because C doesn't explicitly carry boundaries, they need to be recreated in some way.

The first option is to actually create an Ada array without boundaries. This is the most flexible, but also the least safe option. It involves creating an array with indices over the full range of **Integer** without ever creating it from Ada, but instead retrieving it as an access from C. For example:

[C]

Listing 6: f.h

1 **int** * f ();

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Arr_2
MD5: 19e33efb6d7d46778b88baa2709111e5
```

[Ada]

Listing 7: main.adb

```
procedure Main is
1
      type Arr is array (Integer) of Integer;
2
      type Arr A is access all Arr;
3
4
      function F return Arr A;
5
      pragma Import (C, F);
6
  begin
7
      null:
8
  end Main:
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Arr_2
MD5: b52213bcdd8db5e8abfcb8effabb84df

Note that Arr is a constrained type (it doesn't have the **range** <> notation for indices). For that reason, as it would be for C, it's possible to iterate over the whole range of integer, beyond the memory actually allocated for the array.

A somewhat safer way is to overlay an Ada array over the C one. This requires having access to the length of the array. This time, let's consider two cases, one with an array and its size accessible through functions, another one on global variables. This time, as we're using an overlay, the function will be directly mapped to an Ada function returning an address:

[C]

Listing 8: fg.h

```
int * f_arr (void);
int f_size (void);
int * g_arr;
int g_size;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Arr_3
MD5: b315ec2e5d9fdd297ba295ccbae910bc
```

[Ada]

Listing 9: fg.ads

```
with System;
1
2
   package Fg is
3
4
      type Arr is array (Integer range <>) of Integer;
5
6
      function F_Arr return System.Address;
7
      pragma Import (C, F_Arr, "f_arr");
8
9
      function F_Size return Integer;
10
      pragma Import (C, F_Size, "f_size");
11
12
      F : Arr (0 .. F_Size - 1) with Address => F_Arr;
13
14
      G Size : Integer;
15
      pragma Import (C, G_Size, "g_size");
16
17
      G Arr : Arr (0 .. G Size - 1);
18
      pragma Import (C, G_Arr, "g_arr");
19
20
   end Fg;
21
```

Listing 10: main.adb

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Arr_3
MD5: 5c74f9bca93520ecf85a2010760cc2f8
```

With all solutions though, importing an array from C is a relatively unsafe pattern, as there's only so much information on the array as there would be on the C side in the first place. These are good places for careful peer reviews.

6.6 By-value vs. by-reference types

When interfacing Ada and C, the rules of parameter passing are a bit different with regards to what's a reference and what's a copy. Scalar types and pointers are passed by value, whereas record and arrays are (almost) always passed by reference. However, there may be cases where the C interface also passes values and not pointers to objects. Here's a slightly modified version of a previous example to illustrate this point:

[C]

```
Listing 11: call.c
```

```
#include <stdio.h>
1
2
   struct my_struct {
3
       int A, B;
4
  };
5
6
   void call (struct my_struct p) {
7
       printf ("%d", p.A);
8
   }
9
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Param_By_Value_C
MD5: 42b6e329c5dbfcae368078ca7635341f
```

In Ada, a type can be modified so that parameters of this type can always be passed by copy.

[Ada]

Listing 12: main.adb

```
with Interfaces.C;
1
2
   procedure Main is
3
      type my_struct is record
4
         A : Interfaces.C.int;
5
          B : Interfaces.C.int;
6
      end record
7
        with Convention => C_Pass_By_Copy;
8
9
      procedure Call (V : my_struct);
10
      pragma Import (C, Call, "call");
11
   begin
12
      null;
13
  end Main;
14
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Param_By_Value_Ada
MD5: 16e97033bdffb2bacc0cf3322c019a94
```

Note that this cannot be done at the subprogram declaration level, so if there is a mix of by-copy and by-reference calls, two different types need to be used on the Ada side.

6.7 Naming and prefixes

Because of the absence of namespaces, any global name in C tends to be very long. And because of the absence of overloading, they can even encode type names in their type.

In Ada, the package is a namespace — two entities declared in two different packages are clearly identified and can always be specifically designated. The C names are usually a good indication of the names of the future packages and should be stripped — it is possible to use the full name if useful. For example, here's how the following declaration and call could be translated:

[C]

Listing 13: reg_interface.h

```
void registerInterface_Initialize (int size);
```

Listing 14: reg_interface_test.c

```
1 #include "reg_interface.h"
2
3 int main(int argc, const char * argv[])
4 {
5 registerInterface_Initialize(15);
6
7 return 0;
8 }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Namespaces
MD5: e8c25da648a2e8662d97a9a5b863a5bc
```

[Ada]

Listing 15: register_interface.ads

```
1 package Register_Interface is
2 procedure Initialize (Size : Integer)
3 with Import => True,
4 Convention => C,
5 External_Name => "registerInterface_Initialize";
6
7 end Register_Interface;
```

Listing 16: main.adb

```
with Register_Interface;
procedure Main is
begin
Register_Interface.Initialize (15);
end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Namespaces
MD5: 934edd7d3c74d058f862a786582a32c0
```

Note that in the above example, a **use** clause on Register_Interface could allow us to omit the prefix.

6.8 Pointers

The first thing to ask when translating pointers from C to Ada is: are they needed in the first place? In Ada, pointers (or access types) should only be used with complex structures that cannot be allocated at run-time — think of a linked list or a graph for example. There are many other situations that would need a pointer in C, but do not in Ada, in particular:

- Arrays, even when dynamically allocated
- Results of functions
- Passing large structures as parameters

- Access to registers
- ... others

This is not to say that pointers aren't used in these cases but, more often than not, the pointer is hidden from the user and automatically handled by the code generated by the compiler; thus avoiding possible mistakes from being made. Generally speaking, when looking at C code, it's good practice to start by analyzing how many pointers are used and to translate as many as possible into *pointerless* Ada structures.

Here are a few examples of such patterns — additional examples can be found throughout this document.

Dynamically allocated arrays can be directly allocated on the stack:

[C]

Listing 17: array_decl.c

```
1 #include <stdlib.h>
2
3 int main() {
4 int *a = malloc(sizeof(int) * 10);
5
6 return 0;
7 }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Array_Stack_Alloc_C
MD5: a922c3e163494339d6773c6ab1256549
```

[Ada]

Listing 18: main.adb

```
1 procedure Main is
2 type Arr is array (Integer range <>) of Integer;
3 A : Arr (0 .. 9);
4 begin
5 null;
6 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Array_Stack_Alloc_Ada
MD5: 2e4196c2a2016244a48de153beaa2b49

It's even possible to create a such an array within a structure, provided that the size of the array is known when instantiating this object, using a type discriminant:

[C]

Listing 19: array_decl.c

```
#include <stdlib.h>
1
2
  typedef struct {
3
       int * a;
4
  } S:
5
6
   int main(int argc, const char * argv[])
7
   {
8
       Sv;
9
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Struct_Array_Stack_Alloc_C MD5: f8e5a877977387986b3e2353834a2989

[Ada]

Listing 20: main.adb

```
procedure Main is
1
      type Arr is array (Integer range <>) of Integer;
2
3
       type S (Last : Integer) is record
4
         A : Arr (0 \dots Last);
5
      end record;
6
7
      V : S (9);
8
   begin
9
      null;
10
  end Main;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Struct_Array_Stack_Alloc_Ada MD5: 955c704bdbe4b2b788e4a790ade12df7

With regards to parameter passing, usage mode (input / output) should be preferred to implementation mode (by copy or by reference). The Ada compiler will automatically pass a reference when needed. This works also for smaller objects, so that the compiler will copy in an out when needed. One of the advantages of this approach is that it clarifies the nature of the object: in particular, it differentiates between arrays and scalars. For example:

[C]

Listing 21: p.h

void p (int * a, int * b);

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Array_In_Out_C
MD5: c2c936dd3afc4850c5869e4db73bb36b

[Ada]

Listing 22: array_types.ads

```
1 package Array_Types is
2 type Arr is array (Integer range <>) of Integer;
3 
4 procedure P (A : in out Integer; B : in out Arr);
5 end Array_Types;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Array_In_Out_Ada
MD5: cf8e51391c9fd8608183c9dae2aa2802

Most of the time, access to registers end up in some specific structures being mapped onto a specific location in memory. In Ada, this can be achieved through an **Address** clause associated to a variable, for example:

[C]

Listing 23: test c.c

```
int main(int argc, const char * argv[])
{
    int * r = (int *)0xFFFF00A0;
    return 0;
    }
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Address_C
MD5: e810538d72d835a04736fcaf732f1930
```

[Ada]

Listing 24: test.adb

```
with System;
procedure Test is
R : Integer with Address => System'To_Address (16#FFFF00A0#);
begin
null;
r end Test;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Address_Ada
MD5: 1263f7289cec6673f19d88bffbeead48

These are some of the most common misuse of pointers in Ada. Previous sections of the document deal with specifically using access types if absolutely necessary.

6.9 Bitwise Operations

Bitwise operations such as masks and shifts in Ada should be relatively rarely needed, and, when translating C code, it's good practice to consider alternatives. In a lot of cases, these operations are used to insert several pieces of data into a larger structure. In Ada, this can be done by describing the structure layout at the type level through representation clauses, and then accessing this structure as any other.

Consider the case of using a C primitive type as a container for single bit boolean flags. In C, this would be done through masks, e.g.:

[C]

Listing 25: flags.c

```
#define FLAG_1 0b0001
```

```
<sup>2</sup> #define FLAG_2 0b0010
```

```
#define FLAG_3 0b0100
3
   #define FLAG_4 0b1000
4
   int main(int argc, const char * argv[])
6
7
   {
        int value = 0;
8
9
        value |= FLAG_2 | FLAG_4;
10
11
        return 0;
12
   }
13
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Flags_C
MD5: cf903dee1fb1d78d74dc42b66adcdbd5
```

In Ada, the above can be represented through a Boolean array of enumerate values: [Ada]

Listing 26: main.adb

```
procedure Main is
1
      type Values is (Flag_1, Flag_2, Flag_3, Flag_4);
2
      type Value_Array is array (Values) of Boolean
3
        with Pack;
4
5
      Value : Value_Array :=
6
          (Flag_2 => True,
7
           Flag 4 => True,
8
           others => False);
9
   begin
10
11
      null;
   end Main;
12
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Flags_Ada
MD5: c92c8532763469f5e4d1027df2bd6a6b
```

Note the Pack directive for the array, which requests that the array takes as little space as possible.

It is also possible to map records on memory when additional control over the representation is needed or more complex data are used:

[C]

Listing 27: struct_map.c

```
int main(int argc, const char * argv[])
{
    int value = 0;
    value = (2 << 1) | 1;
    return 0;
    }
</pre>
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Rec_Map_C
MD5: 16606f11ab3e9c86d3e1d88ac9c3f37f
```

[Ada]

Listing 28: main.adb

```
procedure Main is
1
       type Value Rec is record
2
         V1 : Boolean:
З
         V2 : Integer range 0 ... 3;
4
       end record;
5
6
       for Value_Rec use record
7
          V1 at \overline{0} range 0 .. 0;
8
          V2 at 0 range 1 .. 2;
9
       end record;
10
11
       Value : Value_Rec := (V1 => True, V2 => 2);
12
   beain
13
       null;
14
   end Main;
15
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Rec_Map_Ada
MD5: 52078824814b0d83789dd837ac2e86bf
```

The benefit of using Ada structure instead of bitwise operations is threefold:

- · The code is simpler to read / write and less error-prone
- Individual fields are named
- The compiler can run consistency checks (for example, check that the value indeed fit in the expected size).

Note that, in cases where bitwise operators are needed, Ada provides modular types with **and**, **or** and **xor** operators. Further shift operators can also be provided upon request through a **pragma**. So the above could also be literally translated to:

[Ada]

Listing 29: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
    procedure Main is
3
       type Value_Type is mod 2 ** 32;
4
       pragma Provide_Shift_Operators (Value_Type);
5
6
       Value : Value_Type;
7
    begin
8
       Value := Shift_Left (2, 1) or 1;
9
       Put_Line ("Value = " & Value_Type'Image (Value));
10
    end Main;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitwise_Ops_Ada
MD5: 22cb824a0c99bd1a9092dc5f90e9d7fc

Runtime output

Value = 5

6.10 Mapping Structures to Bit-Fields

In the previous section, we've seen how to perform bitwise operations. In this section, we look at how to interpret a data type as a bit-field and perform low-level operations on it.

In general, you can create a bit-field from any arbitrary data type. First, we declare a bitfield type like this:

[Ada]

type Bit_Field is array (Natural range <>) of Boolean with Pack;

As we've seen previously, the Pack aspect declared at the end of the type declaration indicates that the compiler should optimize for size. We must use this aspect to be able to interpret data types as a bit-field.

Then, we can use the Size and the Address attributes of an object of any type to declare a bit-field for this object. We've discussed the Size attribute *earlier in this course* (page 95).

The **Address** attribute indicates the address in memory of that object. For example, assuming we've declare a variable V, we can declare an actual bit-field object by referring to the **Address** attribute of V and using it in the declaration of the bit-field, as shown here:

[Ada]

B : Bit_Field (0 .. V'Size - 1) with Address => V'Address;

Note that, in this declaration, we're using the **Address** attribute of V for the **Address** aspect of B.

This technique is called overlays for serialization. Now, any operation that we perform on B will have a direct impact on V, since both are using the same memory location.

The approach that we use in this section relies on the **Address** aspect. Another approach would be to use unchecked conversions, which we'll discuss in the *next section* (page 151).

We should add the Volatile aspect to the declaration to cover the case when both objects can still be changed independently — they need to be volatile, otherwise one change might be missed. This is the updated declaration:

[Ada]

B : Bit_Field (0 .. V'Size - 1) with Address => V'Address, Volatile;

Using the Volatile aspect is important at high level of optimizations. You can find further details about this aspect in the section about the *Volatile and Atomic aspects* (page 90).

Another important aspect that should be added is Import. When used in the context of object declarations, it'll avoid default initialization which could overwrite the existing content while creating the overlay — see an example in the admonition below. The declaration now becomes:

```
B : Bit_Field (0 .. V'Size - 1)
with
Address => V'Address, Import, Volatile;
```

Let's look at a simple example:

[Ada]

Listing 30: simple_bitfield.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Simple Bitfield is
3
      type Bit_Field is array (Natural range <>) of Boolean with Pack;
4
5
      V : Integer := 0;
6
      B : Bit_Field (0 .. V'Size - 1)
7
        with Address => V'Address, Import, Volatile;
8
   begin
9
      B (2) := True;
10
      Put Line ("V = " & Integer'Image (V));
11
   end Simple_Bitfield;
12
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Ada
MD5: 193a2db91619426a145cd267f873145f
```

Runtime output

V = 4

In this example, we first initialize V with zero. Then, we use the bit-field B and set the third element (B (2)) to **True**. This automatically sets bit #3 of V to 1. Therefore, as expected, the application displays the message V = 4, which corresponds to $2^2 = 4$.

Note that, in the declaration of the bit-field type above, we could also have used a positive range. For example:

```
type Bit_Field is array (Positive range <>) of Boolean with Pack;
```

```
B : Bit_Field (1 .. V'Size)
with Address => V'Address, Import, Volatile;
```

The only difference in this case is that the first bit is B (1) instead of B (0).

In C, we would rely on bit-shifting and masking to set that specific bit:

[C]

Listing 31: bitfield.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
        int v = 0;
5
6
        v = v | (1 << 2);
7
8
        printf("v = %d\n", v);
9
10
        return 0;
11
   }
12
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_C
MD5: 98557f80ea3bc1b081ae2688f844cbe1
```

Runtime output

v = 4

1 Important

Ada has the concept of default initialization. For example, you may set the default value of record components:

[Ada]

Listing 32: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
4
      type Rec is record
5
         X : Integer := 10;
6
          Y : Integer := 11;
7
      end record;
8
9
10
      R : Rec;
   begin
11
      Put_Line ("R.X = " & Integer'Image (R.X));
12
      Put_Line ("R.Y = " & Integer'Image (R.Y));
13
   end Main;
14
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Default_Record_Type
MD5: 010877f4d20302a1abcb9562c9e36a38

Runtime output

R.X = 10R.Y = 11

In the code above, we don't explicitly initialize the components of R, so they still have the default values 10 and 11, which are displayed by the application.

Likewise, the Default_Value aspect can be used to specify the default value in other kinds of type declarations. For example:

[Ada]

1 2

3 4

5

6 7

8

9

10

11

Listing 33: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
```

```
procedure Main is
```

```
type Percentage is range 0 .. 100
with Default_Value => 10;
```

```
P : Percentage;
```

```
begin
   Put_Line ("P = " & Percentage'Image (P));
```

```
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Default_Value_Type
MD5: b3715f7cba0cbefa433bac529d95e395

Runtime output

P = 10

When declaring an object whose type has a default value, the object will automatically be initialized with the default value. In the example above, P is automatically initialized with 10, which is the default value of the Percentage type.

Some types have an implicit default value. For example, access types have a default value of **null**.

As we've just seen, when declaring objects for types with associated default values, automatic initialization will happen. This can also happens when creating an overlay with the Address aspect. The default value is then used to overwrite the content at the memory location indicated by the address. However, in most situations, this isn't the behavior we expect, since overlays are usually created to analyze and manipulate existing values. Let's look at an example where this happens:

[Ada]

1 2

3 4

5 6

7

8

Listing 34: p.ads

```
package P is
```

```
type Unsigned_8 is mod 2 ** 8 with Default_Value => 0;
```

```
type Byte_Field is array (Natural range <>) of Unsigned_8;
```

```
procedure Display_Bytes_Increment (V : in out Integer);
end D:
```

end P;

```
Listing 35: p.adb
```

```
with Ada.Text IO; use Ada.Text IO;
1
2
   package body P is
3
4
      procedure Display_Bytes_Increment (V : in out Integer) is
5
          BF : Byte Field (1 .. V'Size / 8)
6
            with Address => V'Address, Volatile;
7
      begin
8
          for B of BF loop
9
             Put_Line ("Byte = " & Unsigned_8'Image (B));
10
          end loop;
11
          Put Line ("Now incrementing...");
12
          V := V + 1;
13
      end Display_Bytes_Increment;
14
```

```
16 end P;
```

15

Listing 36: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   with P; use P;
3
4
   procedure Main is
5
      V : Integer := 10;
6
   begin
7
      Put Line ("V = " & Integer'Image (V));
8
      Display_Bytes_Increment (V);
9
      Put_Line ("V = " & Integer'Image (V));
10
   end Main;
11
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Overlay_Default_Init_
    overwrite
   MD5: 04994b2b4c98e9232a155515dc0c365a
   Build output
   p.adb:7:14: warning: default initialization of "Bf" may modify "V" [-gnatwo]
   p.adb:7:14: warning: use pragma Import for "Bf" to suppress initialization (RM,
    →B.1(24)) [-gnatwo]
   Runtime output
   V = 10
   Byte = 0
   Byte = 0
   Byte = 0
   Byte = 0
   Now incrementing...
   V = 1
   In this example, we expect Display_Bytes_Increment to display each byte of the V
   parameter and then increment it by one. Initially, V is set to 10, and the call to Dis-
   play Bytes Increment should change it to 11. However, due to the default value asso-
   ciated to the Unsigned 8 type — which is set to 0 — the value of V is overwritten in the
   declaration of BF (in Display Bytes Increment). Therefore, the value of V is 1 after the
   call to Display Bytes Increment. Of course, this is not the behavior that we originally
   intended.
   Using the Import aspect solves this problem. This aspect tells the compiler to not apply
   default initialization in the declaration because the object is imported. Let's look at the
   corrected example:
   [Ada]
                                      Listing 37: p.ads
   package P is
1
2
      type Unsigned_8 is mod 2 ** 8 with Default_Value => 0;
3
4
      type Byte Field is array (Natural range <>) of Unsigned 8;
5
6
      procedure Display Bytes Increment (V : in out Integer);
7
   end P;
8
                                      Listing 38: p.adb
   with Ada.Text IO; use Ada.Text IO;
1
2
   package body P is
3
4
      procedure Display Bytes Increment (V : in out Integer) is
5
         BF : Byte_Field (1 .. V'Size / 8)
6
           with Address => V'Address, Import, Volatile;
7
      begin
8
         for B of BF loop
9
            Put Line ("Byte = " & Unsigned 8'Image (B));
10
         end loop:
11
         Put Line ("Now incrementing...");
12
         V := V + 1;
13
      end Display Bytes Increment;
14
15
   end P;
16
```

```
Listing 39: main.adb
```

```
with Ada.Text IO; use Ada.Text IO;
1
2
   with P; use P;
3
4
   procedure Main is
5
      V : Integer := 10;
6
   begin
7
      Put Line ("V = " & Integer'Image (V));
8
      Display Bytes Increment (V);
9
      Put Line ("V = " & Integer'Image (V));
10
   end Main;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Overlay_Default_Init_Import MD5: e269d9d3c06c0f6c69ead16e7d2ba70b

Runtime output

```
V = 10
Byte = 10
Byte = 0
Byte = 0
Now incrementing...
V = 11
```

This unwanted side-effect of the initialization by the Default_Value aspect that we've just seen can also happen in these cases:

- when we set a default value for components of a record type declaration,
- when we use the Default_Component_Value aspect for array types, or
- when we set use the Initialize_Scalars pragma for a package.

Again, using the Import aspect when declaring the overlay eliminates this side-effect.

We can use this pattern for objects of more complex data types like arrays or records. For example:

[Ada]

Listing 40: int_array_bitfield.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Int_Array_Bitfield is
3
      type Bit_Field is array (Natural range <>) of Boolean with Pack;
4
5
      A : array (1 .. 2) of Integer := (others => 0);
6
      B : Bit_Field (0 .. A'Size - 1)
7
        with Address => A'Address, Import, Volatile;
8
   begin
9
      B (2) := True;
10
      for I in A'Range loop
11
         Put_Line ("A (" & Integer'Image (I)
12
                    & ")= " & Integer'Image (A (I)));
13
      end loop;
14
  end Int_Array_Bitfield;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Int_Array_Ada
MD5: 478ba4ce4f5886566556bddb58245eb9

Runtime output

 $\begin{array}{rrrr} A & (1) = & 4 \\ A & (2) = & 0 \end{array}$

In the Ada example above, we're using the bit-field to set bit #3 of the first element of the array (A (1)). We could set bit #4 of the second element by using the size of the data type (in this case, **Integer**'Size):

[Ada]

B (Integer'Size + 3) := True;

In C, we would select the specific array position and, again, rely on bit-shifting and masking to set that specific bit:

[C]

Listing 41: bitfield_int_array.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        int i;
5
        int a[2] = {0, 0};
6
7
        a[0] = a[0] | (1 << 2);
8
9
        for (i = 0; i < 2; i++)
10
11
        Ł
            printf("a[%d] = %d\n", i, a[i]);
12
        }
13
14
        return 0;
15
   }
16
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Int_Array_C MD5: 4dc3fe77e8260ff3b449c8779745a63c

Runtime output

a[0] = 4a[1] = 0

Since we can use this pattern for any arbitrary data type, this allows us to easily create a subprogram to serialize data types and, for example, transmit complex data structures as a bitstream. For example:

[Ada]

Listing 42: serializer.ads

```
1 package Serializer is
2
3 type Bit_Field is array (Natural range <>) of Boolean with Pack;
4
```

```
s procedure Transmit (B : Bit_Field);
7 end Serializer;
```

Listing 43: serializer.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   package body Serializer is
3
4
       procedure Transmit (B : Bit_Field) is
5
6
          procedure Show_Bit (V : Boolean) is
7
          begin
8
             case V is
9
                when False => Put ("0");
10
                when True => Put ("1");
11
             end case;
12
          end Show_Bit;
13
14
       begin
15
          Put ("Bits: ");
16
          for E of B loop
17
             Show_Bit (E);
18
          end loop;
19
          New Line;
20
       end Transmit;
21
22
23
   end Serializer;
```

Listing 44: my recs.ads

```
type Rec is record
V : Integer;
S S : String (1 .. 3);
end record;
end My_Recs;
```

package My_Recs is

1

Listing 45: main.adb

```
with Serializer; use Serializer;
1
   with My_Recs;
                      use My_Recs;
2
3
   procedure Main is
4
      R : Rec := (5, "abc");
5
      B : Bit Field (0 .. R'Size - 1)
6
        with Address => R'Address, Import, Volatile;
7
   begin
8
      Transmit (B);
9
  end Main;
10
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Serialization_ada
MD5: 5c9c2d18bab7c78456d1d795c6334cd9

Build output

main.adb:9:14: warning: volatile actual passed by copy (RM C.6(19)) [enabled by ⊸default]

Runtime output

In this example, the Transmit procedure from Serializer package displays the individual bits of a bit-field. We could have used this strategy to actually transmit the information as a bitstream. In the main application, we call Transmit for the object R of record type Rec. Since Transmit has the bit-field type as a parameter, we can use it for any type, as long as we have a corresponding bit-field representation.

In C, we interpret the input pointer as an array of bytes, and then use shifting and masking to access the bits of that byte. Here, we use the **char** type because it has a size of one byte in most platforms.

[C]

Listing 46: my_recs.h

```
1 typedef struct {
2     int v;
3     char s[4];
4 } rec;
```

Listing 47: serializer.h

```
void transmit (void *bits, int len);
```

Listing 48: serializer.c

```
#include "serializer.h"
1
2
   #include <stdio.h>
3
   #include <assert.h>
4
5
   void transmit (void *bits, int len)
6
   {
7
        int i, j;
8
        char *c = (char *)bits;
9
10
        assert(sizeof(char) == 1);
11
12
        printf("Bits: ");
13
        for (i = 0; i < len / (sizeof(char) * 8); i++)</pre>
14
        ł
15
             for (j = 0; j < sizeof(char) * 8; j++)</pre>
16
             {
17
                 printf("%d", c[i] >> j & 1);
18
             }
19
        }
20
        printf("\n");
21
   }
22
```

Listing 49: bitfield_serialization.c

```
1 #include <stdio.h>
2
3 #include "my_recs.h"
4 #include "serializer.h"
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Serialization_C MD5: 47f0a4efcbec9303f44d535064e5d6ce

Runtime output

Similarly, we can write a subprogram that converts a bit-field — which may have been received as a bitstream — to a specific type. We can add a To_Rec subprogram to the My_Recs package to convert a bit-field to the Rec type. This can be used to convert a bitstream that we received into the actual data type representation.

As you know, we may write the To_Rec subprogram as a procedure or as a function. Since we need to use slightly different strategies for the implementation, the following example has both versions of To_Rec.

This is the updated code for the My_Recs package and the Main procedure:

[Ada]

Listing 50: serializer.ads

```
package Serializer is
type Bit_Field is array (Natural range <>) of Boolean with Pack;
procedure Transmit (B : Bit_Field);
end Serializer;
```

Listing 51: serializer.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   package body Serializer is
3
4
      procedure Transmit (B : Bit Field) is
5
6
          procedure Show_Bit (V : Boolean) is
7
          begin
8
             case V is
9
                when False => Put ("0");
10
                when True => Put ("1");
11
             end case;
12
         end Show_Bit;
13
14
      begin
15
         Put ("Bits: ");
16
          for E of B loop
17
```

```
18 Show_Bit (E);
19 end loop;
20 New_Line;
21 end Transmit;
22
23 end Serializer;
```

Listing 52: my_recs.ads

```
with Serializer; use Serializer;
1
2
   package My_Recs is
3
4
      type Rec is record
5
         V : Integer;
6
         S : String (1 .. 3);
7
      end record;
8
9
      procedure To_Rec (B : Bit_Field;
10
11
                          R : out Rec);
12
      function To_Rec (B : Bit_Field) return Rec;
13
14
      procedure Display (R : Rec);
15
16
   end My_Recs;
17
```

Listing 53: my_recs.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   package body My_Recs is
3
4
5
      procedure To_Rec (B : Bit_Field;
6
                          R : out Rec) is
          B_R : Rec
7
            with Address => B'Address, Import, Volatile;
8
      begin
9
          -- Assigning data from overlayed record B_R to output parameter R.
10
          R := B R;
11
      end To_Rec;
12
13
       function To_Rec (B : Bit_Field) return Rec is
14
15
          R : Rec;
          B_R : Rec
16
           with Address => B'Address, Import, Volatile;
17
      begin
18
             Assigning data from overlayed record B_R to local record R.
19
          R := B_R;
20
21
          return R;
22
      end To_Rec;
23
24
      procedure Display (R : Rec) is
25
26
       begin
          Put ("(" & Integer'Image (R.V) & ", "
27
               & (R.S) & ")");
28
      end Display;
29
30
   end My_Recs;
31
```

```
Listing 54: main.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
   with Serializer; use Serializer;
2
   with My_Recs;
                      use My_Recs;
3
4
   procedure Main is
5
      R1 : Rec := (5, "abc");
6
      R2 : Rec := (0, "zzz");
7
8
      B1 : Bit_Field (0 .. R1'Size - 1)
9
        with Address => R1'Address, Import, Volatile;
10
   beain
11
      Put ("R2 = ");
12
      Display (R2);
13
      New_Line;
14
15
       -- Getting Rec type using data from B1, which is a bit-field
16
       - -
          representation of R1.
17
       To_Rec (B1, R2);
18
19
       -- We could use the function version of To_Rec:
20
       -- R2 := To_Rec (B1);
21
22
      Put_Line ("New bitstream received!");
23
      Put ("R2 = ");
24
      Display (R2);
25
      New Line;
26
   end Main;
27
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Deserialization_Ada
MD5: bf5cb5ef048ed1f95dba8e85275f6e32

Build output

```
main.adb:18:12: warning: volatile actual passed by copy (RM C.6(19)) [enabled by 

⊸default]
```

Runtime output

```
R2 = ( 0, zzz)
New bitstream received!
R2 = ( 5, abc)
```

In both versions of To_Rec, we declare the record object B_R as an overlay of the input bit-field. In the procedure version of To_Rec, we then simply copy the data from B_R to the output parameter R. In the function version of To_Rec, however, we need to declare a local record object R, which we return after the assignment.

In C, we can interpret the input pointer as an array of bytes, and copy the individual bytes. For example:

[C]

Listing 55: my recs.h

```
1 typedef struct {
2     int v;
3     char s[3];
4 } rec;
```

```
5
6 void to_r (void *bits, int len, rec *r);
7
8 void display_r (rec *r);
```

```
Listing 56: my_recs.c
```

```
#include "my_recs.h"
1
2
   #include <stdio.h>
3
   #include <assert.h>
4
5
   void to_r (void *bits, int len, rec *r)
6
   {
7
        int i;
8
        char *c1 = (char *)bits;
9
        char *c2 = (char *)r;
10
11
        assert(len == sizeof(rec) * 8);
12
13
        for (i = 0; i < len / (sizeof(char) * 8); i++)</pre>
14
15
        {
            c2[i] = c1[i];
16
        }
17
   }
18
19
   void display_r (rec *r)
20
21
   {
        printf("{%d, %c%c%c}", r->v, r->s[0], r->s[1], r->s[2]);
22
   }
23
```

Listing 57: bitfield_serialization.c

```
#include <stdio.h>
1
   #include "my_recs.h"
2
3
4
   int main(int argc, const char * argv[])
5
    {
        rec r1 = {5, "abc"};
6
        rec r2 = {0, "zzz"};
7
8
9
        printf("r2 = ");
        display_r (&r2);
printf("\n");
10
11
12
        to_r(&r1, sizeof(r1) * 8, &r2);
13
14
        printf("New bitstream received!\n");
15
        printf("r2 = ");
16
        display_r (&r2);
17
        printf("\n");
18
19
        return 0;
20
   }
21
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Deserialization_C MD5: 1c0fda773b0b681d0a4e9a57cf67d997

Runtime output

```
r2 = {0, zzz}
New bitstream received!
r2 = {5, abc}
```

Here, to_r casts both pointer parameters to pointers to **char** to get a byte-aligned pointer. Then, it simply copies the data byte-by-byte.

6.10.1 Overlays vs. Unchecked Conversions

Unchecked conversions are another way of converting between unrelated data types. This conversion is done by instantiating the generic Unchecked_Conversions function for the types you want to convert. Let's look at a simple example:

[Ada]

Listing 58: simple unchecked conversion.adb

```
with Ada.Text IO;
                                    use Ada.Text_I0;
1
   with Ada.Unchecked_Conversion;
2
З
   procedure Simple_Unchecked_Conversion is
4
      type State is (Off, State_1, State_2)
5
        with Size => Integer'Size;
6
7
      for State use (Off => 0, State 1 => 32, State 2 => 64);
8
9
      function As_Integer is new Ada.Unchecked_Conversion (Source => State,
10
                                                               Target => Integer);
11
12
      I : Integer;
13
   beain
14
      I := As_Integer (State_2);
15
      Put Line ("I = " & Integer'Image (I));
16
   end Simple_Unchecked_Conversion;
17
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Simple_Unchecked_Conversion
MD5: 1b6058ef1919879a7d2d86be41f3b269

Runtime output

I = 64

In this example, As_Integer is an instantiation of Unchecked_Conversion to convert between the State enumeration and the **Integer** type. Note that, in order to ensure safe conversion, we're declaring State to have the same size as the **Integer** type we want to convert to.

This is the corresponding implementation using overlays:

[Ada]

Listing 59: simple_overlay.adb

```
with Ada.Text_I0; use Ada.Text_I0;
procedure Simple_Overlay is
type State is (Off, State_1, State_2)
with Size => Integer'Size;
for State use (Off => 0, State_1 => 32, State_2 => 64);
```

```
8
9 S : State;
10 I : Integer
11 with Address => S'Address, Import, Volatile;
12 begin
13 S := State_2;
14 Put_Line ("I = " & Integer'Image (I));
15 end Simple_Overlay;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Translation.Simple_Overlay
MD5: 932135a47c36c406e70b22e075afeaf2
```

Runtime output

I = 64

Let's look at another example of converting between different numeric formats. In this case, we want to convert between a 16-bit fixed-point and a 16-bit integer data type. This is how we can do it using Unchecked_Conversion:

[Ada]

Listing 60: fixed_int_unchecked_conversion.adb

```
with Ada.Text I0;
                                    use Ada.Text_I0;
1
   with Ada.Unchecked Conversion;
2
3
   procedure Fixed_Int_Unchecked_Conversion is
4
      Delta_16 : constant := 1.0 / 2.0 ** (16 - 1);
5
      Max_16 : constant := 2 ** 15;
6
7
      type Fixed_16 is delta Delta_16 range -1.0 .. 1.0 - Delta_16
8
        with Size => 16:
9
      type Int_16 is range -Max_16 .. Max_16 - 1
10
        with Size => 16;
11
12
      function As Int_16 is new Ada.Unchecked Conversion (Source => Fixed_16,
13
                                                             Target => Int_16);
14
      function As_Fixed_16 is new Ada.Unchecked_Conversion (Source => Int_16,
15
                                                               Target => Fixed_16);
16
17
      I : Int_16 := 0;
18
      F : Fixed_16 := 0.0;
19
   begin
20
      F := Fixed_16'Last;
21
      I := As_Int_16 (F);
22
23
      Put_Line ("F = " & Fixed_16'Image (F));
24
      Put_Line ("I = " & Int_16'Image (I));
25
   end Fixed_Int_Unchecked_Conversion;
26
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Fixed_Int_Unchecked_Conversion
MD5: 53b59ca56a5c25408d8b6e5fcb06f37a

Runtime output

F = 0.99997 I = 32767 Here, we instantiate Unchecked_Conversion for the Int_16 and Fixed_16 types, and we call the instantiated functions explicitly. In this case, we call As_Int_16 to get the integer value corresponding to Fixed_16'Last.

This is how we can rewrite the implementation above using overlays:

[Ada]

Listing 61: fixed int overlay.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Fixed Int Overlay is
3
      Delta_16 : constant := 1.0 / 2.0 ** (16 - 1);
4
      Max 16 : constant := 2 ** 15;
5
6
      type Fixed_16 is delta Delta_16 range -1.0 .. 1.0 - Delta_16
7
        with Size => 16;
8
                   is range -Max_16 .. Max_16 - 1
      type Int_16
9
        with Size => 16;
10
11
      I : Int 16
                  := 0;
12
      F : Fixed 16
13
        with Address => I'Address, Import, Volatile;
14
   begin
15
      F := Fixed_16'Last;
16
17
      Put_Line ("F = " & Fixed_16'Image (F));
18
      Put_Line ("I = " & Int_16'Image (I));
19
   end Fixed_Int_Overlay;
20
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Fixed_Int_Overlay
MD5: ee86e3d10266f8c8c96311595b6624ec

Runtime output

F = 0.99997 I = 32767

Here, the conversion to the integer value is implicit, so we don't need to call a conversion function.

Using Unchecked_Conversion has the advantage of making it clear that a conversion is happening, since the conversion is written explicitly in the code. With overlays, that conversion is automatic and therefore implicit. In that sense, using an unchecked conversion is a cleaner and safer approach. On the other hand, an unchecked conversion requires a copy, so it's less efficient than overlays, where no copy is performed — because one change in the source object is automatically reflected in the target object (and vice-versa). In the end, the choice between unchecked conversions and overlays depends on the level of performance that you want to achieve.

Also note that an unchecked conversion only has defined behavior when instantiated for constrained types. For example, we shouldn't use this kind of conversion:

```
Ada.Unchecked_Conversion (Source => String,
Target => Integer);
```

Although this compiles, the behavior will only be well-defined in those cases when Source'Size = Target'Size. Therefore, instead of using an unconstrained type for Source, we should use a subtype that matches this expectation:

Similarly, in order to rewrite the examples using bit-fields that we've seen in the previous section, we cannot simply instantiate Unchecked_Conversion with the Target indicating the *unconstrained* bit-field, such as:

```
Ada.Unchecked_Conversion (Source => Integer,
Target => Bit Field);
```

Instead, we have to declare a subtype for the specific range we're interested in. This is how we can rewrite one of the previous examples:

[Ada]

```
Listing 62: simple bitfield conversion.adb
```

```
with Ada.Text IO;
                                    use Ada.Text I0;
1
   with Ada.Unchecked Conversion;
2
3
   procedure Simple Bitfield Conversion is
4
      type Bit_Field is array (Natural range <>) of Boolean with Pack;
5
6
      V : Integer := 4;
7
8
      -- Declaring subtype that takes the size of V into account.
9
10
      subtype Integer Bit Field is Bit Field (0 .. V'Size - 1);
11
12
      -- NOTE: we could also use the Integer type in the declaration:
13
      - -
14
             subtype Integer Bit Field is Bit Field (0 .. Integer'Size - 1);
15
      - -
      - -
16
17
      -- Using the Integer_Bit_Field subtype as the target
18
      function As Bit Field is new
19
        Ada.Unchecked Conversion (Source => Integer,
20
                                    Target => Integer_Bit_Field);
21
22
      B : Integer_Bit_Field;
23
   beain
24
      B := As Bit Field (V);
25
26
      Put Line ("V = " & Integer'Image (V));
27
   end Simple_Bitfield_Conversion;
28
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Translation.Bitfield_Conversion
MD5: 46ead7e5f3da8f261770811d450453e7

Runtime output

V = 4

In this example, we first declare the subtype Integer_Bit_Field as a bit-field with a length that fits the V variable we want to convert to. Then, we can use that subtype in the instantiation of Unchecked_Conversion.

HANDLING VARIABILITY AND RE-USABILITY

7.1 Understanding static and dynamic variability

It is common to see embedded software being used in a variety of configurations that require small changes to the code for each instance. For example, the same application may need to be portable between two different architectures (ARM and x86), or two different platforms with different set of devices available. Maybe the same application is used for two different generations of the product, so it needs to account for absence or presence of new features, or it's used for different projects which may select different components or configurations. All these cases, and many others, require variability in the software in order to ensure its reusability.

In C, variability is usually achieved through macros and function pointers, the former being tied to static variability (variability in different builds) the latter to dynamic variability (variability within the same build decided at run-time).

Ada offers many alternatives for both techniques, which aim at structuring possible variations of the software. When Ada isn't enough, the GNAT compilation system also provides a layer of capabilities, in particular selection of alternate bodies.

If you're familiar with object-oriented programming (OOP) — supported in languages such as C++ and Java —, you might also be interested in knowing that OOP is supported by Ada and can be used to implement variability. This should, however, be used with care, as OOP brings its own set of problems, such as loss of efficiency — dispatching calls can't be inlined and require one level of indirection — or loss of analyzability — the target of a dispatching call isn't known at run time. As a rule of thumb, OOP should be considered only for cases of dynamic variability, where several versions of the same object need to exist concurrently in the same application.

7.2 Handling variability & reusability statically

7.2.1 Genericity

One usage of C macros involves the creation of functions that works regardless of the type they're being called upon. For example, a swap macro may look like:

[C]

Listing 1: main.c

```
b = tmp; \
7
                                })
8
9
   int main()
10
11
   {
        int a = 10;
12
        int b = 42;
13
14
        printf("a = %d, b = %d\n", a, b);
15
16
        SWAP (int, a, b);
17
18
        printf("a = %d, b = %d\n", a, b);
19
20
        return 0;
21
   }
22
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Swap_C
MD5: 96d0e8ce9ae985e4de9ed64a0f0961f5
```

Runtime output

a = 10, b = 42a = 42, b = 10

Ada offers a way to declare this kind of functions as a generic, that is, a function that is written after static arguments, such as a parameter:

[Ada]

Listing 2: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
4
       generic
5
          type A_Type is private;
6
       procedure Swap (Left, Right : in out A_Type);
7
8
       procedure Swap (Left, Right : in out A_Type) is
9
          Temp : constant A_Type := Left;
10
       begin
11
          Left := Right;
12
          Right := Temp;
13
       end Swap;
14
15
       procedure Swap_I is new Swap (Integer);
16
17
       A : Integer := 10;
18
       B : Integer := 42;
19
20
   begin
21
       Put_Line ("A = "
22
                 & Integer'Image (A)
23
                 & ", B = "
24
                 & Integer'Image (B));
25
26
27
       Swap_I (A, B);
```

```
28
29
Put_Line ("A = "
30
31
& Integer'Image (A)
31
& & ", B = "
32
& Integer'Image (B));
33
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Swap_Ada
MD5: 13f3527b4e3258ebd43be827ad0fcd14

Runtime output

A = 10, B = 42A = 42, B = 10

There are a few key differences between the C and the Ada version here. In C, the macro can be used directly and essentially get expanded by the preprocessor without any kind of checks. In Ada, the generic will first be checked for internal consistency. It then needs to be explicitly instantiated for a concrete type. From there, it's exactly as if there was an actual version of this Swap function, which is going to be called as any other function. All rules for parameter modes and control will apply to this instance.

In many respects, an Ada generic is a way to provide a safe specification and implementation of such macros, through both the validation of the generic itself and its usage.

Subprograms aren't the only entities that can me made generic. As a matter of fact, it's much more common to render an entire package generic. In this case the instantiation creates a new version of all the entities present in the generic, including global variables. For example:

[Ada]

Listing 3: gen.ads

```
generic
1
      type T is private;
2
   package Gen is
3
      type C is tagged record
4
         V : T;
5
      end record;
6
7
      G : Integer;
8
   end Gen:
۵
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Gen_Pkg_1
MD5: 721f9954561b7e0d2964ba0d226c748b

The above can be instantiated and used the following way:

Listing 4: main.adb

```
with Gen;
procedure Main is
package I1 is new Gen (Integer);
package I2 is new Gen (Integer);
subtype Str10 is String (1 .. 10);
```

```
7 package I3 is new Gen (Str10);
8 begin
9 I1.G := 0;
10 I2.G := 1;
11 I3.G := 2;
12 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Gen_Pkg_1
MD5: ab0e99dedf40fff1bced048a96a0fbb6

Here, I1.G, I2.G and I3.G are three distinct variables.

So far, we've only looked at generics with one kind of parameter: a so-called private type. There's actually much more that can be described in this section, such as variables, subprograms or package instantiations with certain properties. For example, the following provides a sort algorithm for any kind of structurally compatible array type:

[Ada]

Listing 5: sort.ads

```
1 generic
2 type Component is private;
3 type Index is (<>);
4 with function "<" (Left, Right : Component) return Boolean;
5 type Array_Type is array (Index range <>) of Component;
6 procedure Sort (A : in out Array_Type);
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Gen_Pkg_2
MD5: 5781f53f4fd4453ecc1313d05ab76f81

The declaration above states that we need a type (Component), a discrete type (Index), a comparison subprogram ("<"), and an array definition (Array_Type). Given these, it's possible to write an algorithm that can sort any Array_Type. Note the usage of the with reserved word in front of the function name: it exists to differentiate between the generic parameter and the beginning of the generic subprogram.

Here is a non-exhaustive overview of the kind of constraints that can be put on types:

```
type T is private; -- T is a constrained type, such as Integer
type T (<>) is private; -- T can be an unconstrained type e.g. String
type T is tagged private; -- T is a tagged type
type T is new T2 with private; -- T is an extension of T2
type T is (<>); -- T is a discrete type
type T is range <>; -- T is an integer type
type T is digits <>; -- T is a floating point type
type T is access T2; -- T is an access type to T2
```

For a more complete list please reference the Generic Formal Types in the Appendix of the Introduction to Ada course.

7.2.2 Simple derivation

Let's take a case where a codebase needs to handle small variations of a given device, or maybe different generations of a device, depending on the platform it's running on. In this example, we're assuming that each platform will lead to a different binary, so the code can statically resolve which set of services are available. However, we want an easy way to implement a new device based on a previous one, saying "this new device is the same as this previous device, with these new services and these changes in existing services".

We can implement such patterns using Ada's simple derivation — as opposed to tagged derivation, which is OOP-related and discussed in a later section.

Let's start from the following example:

[Ada]

Listing 6: drivers 1.ads

```
package Drivers_1 is
1
2
      type Device_1 is null record;
3
      procedure Startup (Device : Device_1);
4
      procedure Send (Device : Device_1; Data : Integer);
5
      procedure Send_Fast (Device : Device_1; Data : Integer);
6
      procedure Receive (Device : Device_1; Data : out Integer);
7
8
   end Drivers_1;
9
```

Listing 7: drivers_1.adb

```
package body Drivers_1 is
1
2
      -- NOTE: unimplemented procedures: Startup, Send, Send_Fast
3
      - -
                 mock-up implementation: Receive
4
5
      procedure Startup (Device : Device_1) is null;
6
7
      procedure Send (Device : Device_1; Data : Integer) is null;
8
9
      procedure Send Fast (Device : Device 1; Data : Integer) is null;
10
11
      procedure Receive (Device : Device_1; Data : out Integer) is
12
      begin
13
         Data := 42;
14
      end Receive;
15
16
   end Drivers_1;
17
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 4f9d7e29b64cda8664438a1d7eed9049

In the above example, Device_1 is an empty record type. It may also have some fields if required, or be a different type such as a scalar. Then the four procedures Startup, Send, Send_Fast and Receive are primitives of this type. A primitive is essentially a subprogram that has a parameter or return type directly referencing this type and declared in the same scope. At this stage, there's nothing special with this type: we're using it as we would use any other type. For example:

[Ada]

Listing 8: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
with Drivers_1; use Drivers_1;

procedure Main is
D : Device 1;
```

```
6 I : Integer;
7 begin
8 Startup (D);
9 Send_Fast (D, 999);
10 Receive (D, I);
11 Put_Line (Integer'Image (I));
12 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 1b28f2c8ca92498cbcda582f092b9912

Runtime output

42

Let's now assume that we need to implement a new generation of device, Device_2. This new device works exactly like the first one, except for the startup code that has to be done differently. We can create a new type that operates exactly like the previous one, but modifies only the behavior of Startup:

[Ada]

Listing 9: drivers_2.ads

```
with Drivers 1; use Drivers 1;
1
2
   package Drivers 2 is
3
4
      type Device_2 is new Device_1;
5
6
      overriding
7
      procedure Startup (Device : Device 2);
8
9
   end Drivers 2;
10
```

Listing 10: drivers 2.adb

```
1 package body Drivers_2 is
2
3 overriding
4 procedure Startup (Device : Device_2) is null;
5
6 end Drivers_2;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 276c9da0b7c9ad61d679531e16fdd9cb

Here, Device_2 is derived from Device_1. It contains all the exact same properties and primitives, in particular, Startup, Send, Send_Fast and Receive. However, here, we decided to change the Startup function and to provide a different implementation. We override this function. The main subprogram doesn't change much, except for the fact that it now relies on a different type:

[Ada]

Listing 11: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
   with Drivers_2;
                      use Drivers_2;
2
3
   procedure Main is
4
      D : Device_2;
5
      I : Integer;
6
   beain
7
      Startup (D);
8
      Send_Fast (D, 999);
9
      Receive (D, I);
10
      Put Line (Integer'Image (I));
11
   end Main;
12
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 31e7105a99771ce6c1602af117e2e8a6
```

Runtime output

42

We can continue with this approach and introduce a new generation of devices. This new device doesn't implement the Send_Fast service so we want to remove it from the list of available services. Furthermore, for the purpose of our example, let's assume that the hardware team went back to the Device_1 way of implementing Startup. We can write this new device the following way:

[Ada]

Listing 12: drivers 3.ads

```
with Drivers_1; use Drivers_1;
1
2
   package Drivers_3 is
3
4
      type Device_3 is new Device_1;
5
6
      overriding
7
      procedure Startup (Device : Device_3);
8
9
      procedure Send_Fast (Device : Device_3; Data : Integer)
10
      is abstract;
11
12
   end Drivers_3;
13
```

Listing 13: drivers 3.adb

```
1 package body Drivers_3 is
2
3 overriding
4 procedure Startup (Device : Device_3) is null;
5
6 end Drivers_3;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 779579532c81b672d8a641c0b8594ed5

The **is abstract** definition makes illegal any call to a function, so calls to Send_Fast on Device_3 will be flagged as being illegal. To then implement Startup of Device_3 as being the same as the Startup of Device_1, we can convert the type in the implementation:

[Ada]

Listing 14: drivers_3.adb

```
package body Drivers 3 is
1
2
      overriding
3
      procedure Startup (Device : Device_3) is
4
      begin
5
         Drivers_1.Startup (Device_1 (Device));
6
      end Startup;
7
8
  end Drivers_3;
9
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 5db9596c276a7a4521914f4108f61d28
```

Our Main now looks like:

[Ada]

Listing 15: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
   with Drivers 3;
                    use Drivers 3;
2
3
   procedure Main is
4
      D : Device 3;
5
      I : Integer;
6
   begin
7
      Startup (D);
8
      Send Fast (D, 999);
9
      Receive (D, I);
10
      Put Line (Integer'Image (I));
11
   end Main;
12
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: 8b6af16d21c2f8a1f0e4866e6ddffd1f

Build output

Here, the call to Send_Fast will get flagged by the compiler.

Note that the fact that the code of Main has to be changed for every implementation isn't necessarily satisfactory. We may want to go one step further, and isolate the selection of the device kind to be used for the whole application in one unique file. One way to do this is to use the same name for all types, and use a renaming to select which package to use. Here's a simplified example to illustrate that:

[Ada]

Listing 16: drivers_1.ads

```
package Drivers 1 is
1
2
      type Transceiver is null record;
3
      procedure Send (Device : Transceiver; Data : Integer);
4
      procedure Receive (Device : Transceiver; Data : out Integer);
5
6
7
```

end Drivers_1;

Listing 17: drivers 1.adb

```
package body Drivers_1 is
1
2
      procedure Send (Device : Transceiver; Data : Integer) is null;
3
4
      procedure Receive (Device : Transceiver; Data : out Integer) is
5
         pragma Unreferenced (Device);
6
      begin
7
         Data := 42;
8
      end Receive;
9
10
   end Drivers_1;
11
```

Listing 18: drivers_2.ads

```
with Drivers_1;
1
2
  package Drivers_2 is
3
4
      type Transceiver is new Drivers 1.Transceiver;
5
      procedure Send (Device : Transceiver; Data : Integer);
6
      procedure Receive (Device : Transceiver; Data : out Integer);
7
8
  end Drivers 2;
9
```

Listing 19: drivers 2.adb

```
package body Drivers 2 is
1
2
      procedure Send (Device : Transceiver; Data : Integer) is null;
3
4
      procedure Receive (Device : Transceiver; Data : out Integer) is
5
         pragma Unreferenced (Device);
6
      begin
7
         Data := 42;
8
      end Receive;
9
10
   end Drivers_2;
11
```

Listing 20: drivers.ads

```
with Drivers 1;
1
2
   package Drivers renames Drivers 1;
3
```

Listing 21: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
                    use Drivers;
  with Drivers;
2
```

```
3
   procedure Main is
4
      D : Transceiver;
5
      I : Integer;
6
   begin
7
      Send (D, 999);
8
      Receive (D, I);
9
      Put_Line (Integer'Image (I));
10
  end Main;
11
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Derived_Drivers
MD5: e92590e4b91fef33f4fec23362a52873
```

Runtime output

42

In the above example, the whole code can rely on drivers.ads, instead of relying on the specific driver. Here, Drivers is another name for Driver_1. In order to switch to Driver_2, the project only has to replace that one drivers.ads file.

In the following section, we'll go one step further and demonstrate that this selection can be done through a configuration switch selected at build time instead of a manual code modification.

7.2.3 Configuration pragma files

Configuration pragmas are a set of pragmas that modify the compilation of source-code files. You may use them to either relax or strengthen requirements. For example:

```
pragma Suppress (Overflow_Check);
```

In this example, we're suppressing the overflow check, thereby relaxing a requirement. Normally, the following program would raise a constraint error due to a failed overflow check:

[Ada]

Listing 22: p.ads

```
1 package P is
2 function Add_Max (A : Integer) return Integer;
3 end P;
```

Listing 23: p.adb

```
1 package body P is
2 function Add_Max (A : Integer) return Integer is
3 begin
4 return A + Integer'Last;
5 end Add_Max;
6 end P;
```

Listing 24: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
with P;
use P;
```

```
4 procedure Main is
5 I : Integer := Integer'Last;
6 begin
7 I := Add_Max (I);
8 Put_Line ("I = " & Integer'Image (I));
9 end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Constraint_Error_Detection
MD5: d6960fe8ae2af1d66b617bb92d3d47b6

Runtime output

raised CONSTRAINT_ERROR : p.adb:4 overflow check failed

When suppressing the overflow check, however, the program doesn't raise an exception, and the value that Add_Max returns is -2, which is a wraparound of the sum of the maximum integer values (Integer'Last + Integer'Last).

We could also strengthen requirements, as in this example:

```
pragma Restrictions (No_Floating_Point);
```

Here, the restriction forbids the use of floating-point types and objects. The following program would violate this restriction, so the compiler isn't able to compile the program when the restriction is used:

```
procedure Main is
    F : Float := 0.0;
    -- Declaration is not possible with No_Floating_Point restriction.
begin
    null;
end Main;
```

Restrictions are especially useful for high-integrity applications. In fact, the Ada Reference Manual has a separate section for them¹⁷.

When creating a project, it is practical to list all configuration pragmas in a separate file. This is called a configuration pragma file, and it usually has an *.adc* file extension. If you use **GPRbuild** for building Ada applications, you can specify the configuration pragma file in the corresponding project file. For example, here we indicate that gnat.adc is the configuration pragma file for our project:

```
project Default is
for Source_Dirs use ("src");
for Object_Dir use "obj";
for Main use ("main.adb");
package Compiler is
   for Local_Configuration_Pragmas use "gnat.adc";
end Compiler;
```

end Default;

¹⁷ http://www.ada-auth.org/standards/12rm/html/RM-H-4.html

7.2.4 Configuration packages

In C, preprocessing flags are used to create blocks of code that are only compiled under certain circumstances. For example, we could have a block that is only used for debugging:

[C]

Listing 25: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   int func(int x)
4
   {
5
        return x % 4;
6
   }
7
8
9
   int main()
   {
10
        int a, b;
11
12
        a = 10;
13
        b = func(a);
14
15
   #ifdef DEBUG
16
        printf("func(%d) => %d\n", a, b);
17
   #endif
18
19
        return 0;
20
   }
21
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Debug_Code_C
MD5: 4daa8123f7112e7487ab54f16f80d34b
```

Here, the block indicated by the DEBUG flag is only included in the build if we define this preprocessing flag, which is what we expect for a debug version of the build. In the release version, however, we want to keep debug information out of the build, so we don't use this flag during the build process.

Ada doesn't define a preprocessor as part of the language. Some Ada toolchains — like the GNAT toolchain — do have a preprocessor that could create code similar to the one we've just seen. When programming in Ada, however, the recommendation is to use configuration packages to select code blocks that are meant to be included in the application.

When using a configuration package, the example above can be written as:

[Ada]

```
Listing 26: config.ads
```

```
package Config is
Debug : constant Boolean := False;
end Config;
```

Listing 27: func.ads

```
1 function Func (X : Integer) return Integer;
```

Listing 28: func.adb

```
1 function Func (X : Integer) return Integer is
2 begin
3 return X mod 4;
4 end Func;
```

Listing 29: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
   with Config;
2
   with Func;
3
4
   procedure Main is
5
      A, B : Integer;
6
7
   begin
      A := 10;
8
      B := Func (A);
9
10
      if Config.Debug then
11
          Put_Line ("Func(" & Integer'Image (A) & ") => "
12
                    & Integer'Image (B));
13
      end if;
14
   end Main;
15
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Debug_Code_Ada
MD5: b643b683098fa7ad5568a69c9f2c000f

In this example, Config is a configuration package. The version of Config we're seeing here is the release version. The debug version of the Config package looks like this:

```
package Config is
   Debug : constant Boolean := True;
end Config;
```

The compiler makes sure to remove dead code. In the case of the release version, since Config.Debug is constant and set to **False**, the compiler is smart enough to remove the call to Put_Line from the build.

As you can see, both versions of Config are very similar to each other. The general idea is to create packages that declare the same constants, but using different values.

In C, we differentiate between the debug and release versions by selecting the appropriate preprocessing flags, but in Ada, we select the appropriate configuration package during the build process. Since the file name is usually the same (config.ads for the example above), we may want to store them in distinct directories. For the example above, we could have:

- src/debug/config.ads for the debug version, and
- src/release/config.ads for the release version.

Then, we simply select the appropriate configuration package for each version of the build by indicating the correct path to it. When using **GPRbuild**, we can select the appropriate directory where the config.ads file is located. We can use scenario variables in our project, which allow for creating different versions of a build. For example:

project Default is

```
type Mode_Type is ("debug", "release");
Mode : Mode_Type := external ("mode", "debug");
for Source_Dirs use ("src", "src/" & Mode);
for Object_Dir use "obj";
for Main use ("main.adb");
```

```
end Default;
```

In this example, we're defining a scenario type called Mode_Type. Then, we're declaring the scenario variable Mode and using it in the Source_Dirs declaration to complete the path to the subdirectory containing the config.ads file. The expression "src/" & Mode concatenates the user-specified mode to select the appropriate subdirectory.

We can then set the mode on the command-line. For example:

```
gprbuild -P default.gpr -Xmode=release
```

In addition to selecting code blocks for the build, we could also specify values that depend on the target build. For our example above, we may want to create two versions of the application, each one having a different version of a MOD_VALUE that is used in the implementation of func(). In C, we can achieve this by using preprocessing flags and defining the corresponding version in APP_VERSION. Then, depending on the value of APP_VERSION, we define the corresponding value of MOD_VALUE.

[C]

Listing 30: defs.h

```
#ifndef APP VERSION
1
  #define APP_VERSION
                            1
2
   #endif
3
4
  #if APP VERSION == 1
5
  #define MOD VALUE
                            Δ
6
  #endif
7
8
  #if APP VERSION == 2
9
  #define MOD VALUE
                            5
10
  #endif
11
```

Listing 31: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   #include "defs.h"
4
5
   int func(int x)
6
7
   {
        return x % MOD VALUE;
8
   }
9
10
   int main()
11
    {
12
        int a, b;
13
14
        a = 10;
15
        b = func(a);
16
17
```

18 return 0; 19 }

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.App_Version_C
MD5: 9f204dcc65b70618324c48be0dbdffbe
```

If not defined outside, the code above will compile version #1 of the application. We can change this by specifying a value for APP_VERSION during the build (e.g. as a Makefile switch).

For the Ada version of this code, we can create two configuration packages for each version of the application. For example:

[Ada]

Listing 32: app_defs.ads

```
1 -- ./src/app_1/app_defs.ads
2
3 package App_Defs is
4
5 Mod_Value : constant Integer := 4;
6
7 end App_Defs;
```

Listing 33: func.ads

```
1 function Func (X : Integer) return Integer;
```

Listing 34: func.adb

```
with App_Defs;
function Func (X : Integer) return Integer is
begin
```

s return X mod App_Defs.Mod_Value;
6 end Func;

Listing 35: main.adb

```
with Func;
procedure Main is
A, B : Integer;
begin
A := 10;
B := Func (A);
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.App_Version_Ada
MD5: 7c8e4280e74c04ab51073b25e8f53995

The code above shows the version #1 of the configuration package. The corresponding implementation for version #2 looks like this:

```
-- ./src/app_2/app_defs.ads
package App_Defs is
Mod_Value : constant Integer := 5;
end App_Defs;
```

Again, we just need to select the appropriate configuration package for each version of the build, which we can easily do when using **GPRbuild**.

7.3 Handling variability & reusability dynamically

7.3.1 Records with discriminants

In basic terms, records with discriminants are records that include "parameters" in their type definitions. This allows for adding more flexibility to the type definition. In the section about *pointers* (page 132), we've seen this example:

[Ada]

Listing 36: main.adb

```
procedure Main is
1
      type Arr is array (Integer range <>) of Integer;
2
3
       type S (Last : Positive) is record
4
         A : Arr (0 \dots Last);
5
      end record;
6
7
      V : S (9);
8
   begin
9
      null:
10
   end Main;
11
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Rec_Disc_Ada
MD5: 02fa8fa7832a262b99aee139a1b5b7a6
```

Here, Last is the discriminant for type S. When declaring the variable V as S (9), we specify the actual index of the last position of the array component A by setting the Last discriminant to 9.

We can create an equivalent implementation in C by declaring a **struct** with a pointer to an array:

[C]

Listing 37: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   typedef struct {
4
               *
       int
                   a;
5
       const int last;
6
   } S;
7
8
   S init_s (int last)
9
   {
10
```

```
S v = { malloc (sizeof(int) * last + 1), last };
11
        return v;
12
   }
13
14
   int main(int argc, const char * argv[])
15
   {
16
        S v = init_s (9);
17
18
        return 0;
19
   }
20
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Rec_Disc_C
MD5: 8f8b53c38c2ef8c1624208a2d8fd13ef
```

Here, we need to explicitly allocate the a array of the S struct via a call to malloc(), which allocates memory space on the heap. In the Ada version, in contrast, the array (V.A) is allocated on the stack and we don't need to explicitly allocate it.

Note that the information that we provide as the discriminant to the record type (in the Ada code) is constant, so we cannot assign a value to it. For example, we cannot write:

[Ada]

```
V.Last := 10; -- COMPILATION ERROR!
```

In the C version, we declare the last field constant to get the same behavior.

[C]

v.last = 10; // COMPILATION ERROR!

Note that the information provided as discriminants is visible. In the example above, we could display Last by writing:

[Ada]

Put_Line ("Last : " & Integer'Image (V.Last));

Also note that, even if a type is private, we can still access the information of the discriminants if they are visible in the *public* part of the type declaration. Let's rewrite the example above:

[Ada]

```
Listing 38: array_definition.ads
```

```
package Array_Definition is
1
      type Arr is array (Integer range <>) of Integer;
2
3
      type S (Last : Integer) is private;
4
5
   private
6
      type S (Last : Integer) is record
7
         A : Arr (0 .. Last);
8
      end record;
9
10
   end Array_Definition;
11
```

Listing 39: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
with Array_Definition; use Array_Definition;

procedure Main is
V : S (9);
begin
Put_Line ("Last : " & Integer'Image (V.Last));
end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Rec_Disc_Ada_Private
MD5: fa0158c3c61dd9ec7e4000416672f9e9
```

Build output

main.adb:5:04: warning: variable "V" is read but never assigned [-gnatwv]

Runtime output

Last : 9

Even though the S type is now private, we can still display Last because this discriminant is visible in the *non-private* part of package Array_Definition.

7.3.2 Variant records

In simple terms, a variant record is a record with discriminants that allows for changing its structure. Basically, it's a record containing a **case**. This is the general structure:

[Ada]

```
type Var_Rec (V : F) is record
case V is
   when Opt_1 => F1 : Type_1;
   when Opt_2 => F2 : Type_2;
end case;
```

end record;

Let's look at this example: [Ada]

Listing 40: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
4
      type Float_Int (Use_Float : Boolean) is record
5
         case Use Float is
6
           when True => F : Float;
7
           when False => I : Integer;
8
         end case;
9
      end record;
10
11
      procedure Display (V : Float_Int) is
12
```

```
begin
13
          if V.Use_Float then
14
                                         " & Float'Image (V.F));
             Put_Line ("Float value:
15
          else
16
             Put_Line ("Integer value: " & Integer'Image (V.I));
17
          end if;
18
      end Display;
19
20
      F : constant Float_Int := (Use_Float => True, F => 10.0);
21
      I : constant Float_Int := (Use_Float => False, I => 9);
22
23
   begin
24
25
      Display (F);
26
      Display (I);
27
   end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Var_Rec_Ada
MD5: 72dd64c22d65fc527af0c3de73ff7966
```

Runtime output

Float value: 1.00000E+01 Integer value: 9

Here, we declare F containing a floating-point value, and I containing an integer value. In the Display procedure, we present the correct information to the user according to the Use_Float discriminant of the Float_Int type.

We can implement this example in C by using unions:

[C]

Listing 41: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   typedef struct {
4
        int use_float;
5
        union {
6
             float f;
7
             int
                   i;
8
        };
9
   } float_int;
10
11
   float_int init_float (float f)
12
13
   {
        float_int v;
14
15
        v.use_float = 1;
16
        v.f
                      = f;
17
        return v;
18
   }
19
20
   float_int init_int (int i)
21
22
    {
        float_int v;
23
24
        v.use_float = 0;
25
        v.i
                      = i;
26
```

```
return v;
27
   }
28
29
   void display (float_int v)
30
   {
31
        if (v.use_float) {
32
            printf("Float value
                                    : %f\n", v.f);
33
        }
34
        else {
35
            printf("Integer value : %d\n", v.i);
36
        }
37
   }
38
39
   int main(int argc, const char * argv[])
40
41
   {
        float_int f = init_float (10.0);
42
        float_int i = init_int (9);
43
44
        display (f);
45
        display (i);
46
47
        return 0;
48
   }
49
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Var_Rec_C
MD5: ac0ad1e6ff7f2154e9dbb6838999a62e
```

Runtime output

```
Float value : 10.000000
Integer value : 9
```

Similar to the Ada code, we declare f containing a floating-point value, and i containing an integer value. One difference is that we use the init_float() and init_int() functions to initialize the float_int struct. These functions initialize the correct field of the union and set the use_float field accordingly.

7.3.2.1 Variant records and unions

There is, however, a difference in accessibility between variant records in Ada and unions in C. In C, we're allowed to access any field of the union regardless of the initialization:

[C]

```
float_int v = init_float (10.0);
printf("Integer value : %d\n", v.i);
```

This feature is useful to create overlays. In this specific example, however, the information displayed to the user doesn't make sense, since the union was initialized with a floating-point value (v.f) and, by accessing the integer field (v.i), we're displaying it as if it was an integer value.

In Ada, accessing the wrong component would raise an exception at run-time ("discriminant check failed"), since the component is checked before being accessed:

[Ada]

Using this method prevents wrong information being used in other parts of the program.

To get the same behavior in Ada as we do in C, we need to explicitly use the Unchecked_Union aspect in the type declaration. This is the modified example:

[Ada]

Listing 42: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
4
      type Float_Int_Union (Use_Float : Boolean) is record
5
         case Use Float is
6
           when True => F : Float;
7
           when False => I : Integer;
8
         end case:
9
      end record
10
        with Unchecked_Union;
11
12
      V : constant Float Int Union := (Use Float => True, F => 10.0);
13
14
   beain
15
      Put_Line ("Integer value: " & Integer'Image (V.I));
16
   end Main;
17
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Unchecked_Union_Ada
MD5: f6c5eacbd96c23531d02bb47a9668ac5
```

Runtime output

Integer value: 1092616192

Now, we can display the integer component (V.I) even though we initialized the floatingpoint component (V.F). As expected, the information displayed by the test application in this case doesn't make sense.

Note that, when using the Unchecked_Union aspect in the declaration of a variant record, the reference discriminant is not available anymore, since it isn't stored as part of the record. Therefore, we cannot access the Use_Float discriminant as in the following code:

[Ada]

```
V : constant Float_Int_Union := (Use_Float => True, F => 10.0);
begin
if V.Use_Float then -- COMPILATION ERROR!
-- Do something...
end if;
```

Unchecked unions are particularly useful in Ada when creating bindings for C code.

7.3.2.2 Optional components

We can also use variant records to specify optional components of a record. For example: [Ada]

Listing 43: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Main is
3
      type Arr is array (Integer range <>) of Integer;
4
5
      type Extra Info is (No, Yes);
6
7
      type S_Var (Last : Integer; Has_Extra_Info : Extra_Info) is record
8
         A : Arr (0 .. Last);
9
10
         case Has_Extra_Info is
11
           when No => null;
12
           when Yes => B : Arr (0 .. Last);
13
         end case;
14
      end record;
15
16
      V1 : S_Var (Last => 9, Has_Extra_Info => Yes);
17
      V2 : S_Var (Last => 9, Has_Extra_Info => No);
18
   begin
19
      Put_Line ("Size of V1 is: " & Integer'Image (V1'Size));
20
      Put_Line ("Size of V2 is: " & Integer'Image (V2'Size));
21
   end Main;
22
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Var_Rec_Null_Ada
MD5: 548235fa8458302ba025c8fa49e61777
```

Build output

main.adb:17:04: warning: variable "V1" is read but never assigned [-gnatwv]
main.adb:18:04: warning: variable "V2" is read but never assigned [-gnatwv]

Runtime output

Size of V1 is: 704 Size of V2 is: 384

Here, in the declaration of S_Var, we don't have any component in case Has_Extra_Info is false. The component is simply set to **null** in this case.

When running the example above, we see that the size of V1 is greater than the size of V2 due to the extra B component — which is only included when Has_Extra_Info is true.

7.3.2.3 Optional output information

We can use optional components to prevent subprograms from generating invalid information that could be misused by the caller. Consider the following example:

[C]

Listing 44: main.c

```
1 #include <stdio.h>
#include vetdlik h
```

```
2 #include <stdlib.h>
```

```
3
    float calculate (float f1,
4
                       float f2,
5
                       int *success)
6
    {
7
        if (f1 < f2) {
8
             *success = 1;
9
             return f2 - f1;
10
        }
11
        else {
12
             *success = 0;
13
             return 0.0;
14
        }
15
   }
16
17
   void display (float v,
18
                    int
                          success)
19
    {
20
        if (success) {
21
            printf("Value = %f\n", v);
22
        }
23
        else {
24
             printf("Calculation error!\n");
25
        }
26
27
   }
28
    int main(int argc, const char * argv[])
29
30
    {
        float f;
31
        int success;
32
33
        f = calculate (1.0, 0.5, \& success);
34
        display (f, success);
35
36
        f = calculate (0.5, 1.0, \& success);
37
        display (f, success);
38
39
        return 0;
40
   }
41
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Non_Opt_C
MD5: 56f8a72782c4a54d8a6026aa39ce421a
```

Runtime output

Calculation error! Value = 0.500000

In this code, we're using the output parameter success of the calculate() function to indicate whether the calculation was successful or not. This approach has a major problem: there's no way to prevent that the invalid value returned by calculate() in case of an error is misused in another computation. For example:

[C]

```
int main(int argc, const char * argv[])
{
    float f;
    int success;
```

We cannot prevent access to the returned value or, at least, force the caller to evaluate success before using the returned value.

This is the corresponding code in Ada:

[Ada]

}

Listing 45: main.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Main is
3
4
       function Calculate (F1, F2 : Float;
5
                            Success : out Boolean) return Float is
6
       begin
7
          if F1 < F2 then
8
             Success := True;
9
             return F2 - F1;
10
11
          else
            Success := False;
12
            return 0.0;
13
          end if:
14
       end Calculate;
15
16
       procedure Display (V : Float; Success : Boolean) is
17
       begin
18
          if Success then
19
             Put Line ("Value = " & Float'Image (V));
20
          else
21
             Put_Line ("Calculation error!");
22
          end if;
23
       end Display;
24
25
               : Float:
       F
26
       Success : Boolean;
27
   begin
28
       F := Calculate (1.0, 0.5, Success);
29
       Display (F, Success);
30
31
       F := Calculate (0.5, 1.0, Success);
32
       Display (F, Success);
33
   end Main;
34
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Non_Opt_Ada
MD5: bb27fd31660ad604487f908934a3d3cb

Runtime output

Calculation error! Value = 5.00000E-01

The Ada code above suffers from the same drawbacks as the C code. Again, there's no way to prevent misuse of the invalid value returned by Calculate in case of errors.

However, in Ada, we can use variant records to make the component unavailable and therefore prevent misuse of this information. Let's rewrite the original example and *wrap* the returned value in a variant record:

[Ada]

Listing 46: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Main is
3
4
      type Opt_Float (Success : Boolean) is record
5
          case Success is
6
            when False => null;
7
            when True => F : Float;
8
          end case;
9
      end record;
10
11
      function Calculate (F1, F2 : Float) return Opt_Float is
12
      begin
13
          if F1 < F2 then
14
             return (Success => True, F => F2 - F1);
15
          else
16
             return (Success => False);
17
          end if:
18
      end Calculate;
19
20
      procedure Display (V : Opt_Float) is
21
      begin
22
          if V.Success then
23
             Put Line ("Value = " & Float'Image (V.F));
24
          else
25
             Put_Line ("Calculation error!");
26
          end if;
27
      end Display;
28
29
   begin
30
      Display (Calculate (1.0, 0.5));
31
      Display (Calculate (0.5, 1.0));
32
   end Main;
33
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Opt_Ada
MD5: 8b70cd16d5ff13611567fa71059d6891

Runtime output

Calculation error! Value = 5.00000E-01

In this example, we can determine whether the calculation was successful or not by evaluating the Success component of the Opt_Float. If the calculation wasn't successful, we won't be able to access the F component of the Opt_Float. As mentioned before, trying to access the component in this case would raise an exception. Therefore, in case of errors, we can ensure that no information is misused after the call to Calculate.

7.3.3 Object orientation

In the *previous section* (page 170), we've seen that we can add variability to records by using discriminants. Another approach is to use *tagged* records, which are the base for object-oriented programming in Ada.

7.3.3.1 Type extension

A tagged record type is declared by adding the tagged keyword. For example:

[Ada]

```
Listing 47: main.adb
```

```
procedure Main is
1
2
       type Rec is record
3
          V : Integer;
4
       end record;
5
6
       type Tagged_Rec is tagged record
7
          V : Integer;
8
       end record;
9
10
       R1 : Rec;
11
       R2 : Tagged_Rec;
12
13
       pragma Unreferenced (R1, R2);
14
   begin
15
       R1 := (V => 0);
16
       R2 := (V \Rightarrow 0);
17
   end Main;
18
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Tagged_Type_Decl
MD5: 53810d3bb5aa7e7b1483270d974eb025
```

In this simple example, there isn't much difference between the Rec and Tagged_Rec type. However, tagged types can be derived and extended. For example:

[Ada]

Listing 48: main.adb

```
procedure Main is
1
2
       type Rec is record
3
          V : Integer;
4
      end record;
5
6
       -- We cannot declare this:
7
8
          type Ext_Rec is new Rec with record
9
       - -
             V : Integer;
       - -
10
       -- end record;
11
12
       type Tagged_Rec is tagged record
13
         V : Integer;
14
      end record;
15
16
       -- But we can declare this:
17
18
```

```
type Ext_Tagged_Rec is new Tagged_Rec with record
19
           V2 : Integer;
20
       end record;
21
22
       R1 : Rec;
23
       R2 : Tagged_Rec;
24
       R3 : Ext_Tagged_Rec;
25
26
       pragma Unreferenced (R1, R2, R3);
27
    begin
28
       R1 := (V \implies 0);
29
       R2 := (V \implies 0);
30
       R3 := (V \implies 0, V2 \implies 0);
31
   end Main;
32
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Tagged_Type_Extension_Decl
MD5: 707a3e6b220357f50f6792190b000c91

As indicated in the example, a type derived from an untagged type cannot have an extension. The compiler indicates this error if you uncomment the declaration of the Ext_Rec type above. In contrast, we can extend a tagged type, as we did in the declaration of Ext_Tagged_Rec. In this case, Ext_Tagged_Rec has all the components of the Tagged_Rec type (V, in this case) plus the additional components from its own type declaration (V2, in this case).

7.3.3.2 Overriding subprograms

Previously, we've seen that subprograms can be overriden. For example, if we had implemented a Reset and a Display procedure for the Rec type that we declared above, these procedures would be available for an Ext_Rec type derived from Rec. Also, we could override these procedures for the Ext_Rec type. In Ada, we don't need object-oriented programming features to do that: simple (untagged) records can be used to derive types, inherit operations and override them. However, in applications where the actual subprogram to be called is determined dynamically at run-time, we need dispatching calls. In this case, we must use tagged types to implement this.

7.3.3.3 Comparing untagged and tagged types

Let's discuss the similarities and differences between untagged and tagged types based on this example:

[Ada]

Listing 49: p.ads

```
package P is
1
2
       type Rec is record
3
         V : Integer;
4
      end record;
5
6
      procedure Display (R : Rec);
7
      procedure Reset (R : out Rec);
8
9
      type New_Rec is new Rec;
10
11
      overriding procedure Display (R : New_Rec);
12
```

```
not overriding procedure New_Op (R : in out New_Rec);
13
14
       type Tagged_Rec is tagged record
15
         V : Integer;
16
      end record;
17
18
      procedure Display (R : Tagged_Rec);
19
      procedure Reset (R : out Tagged_Rec);
20
21
       type Ext_Tagged_Rec is new Tagged_Rec with record
22
          V2 : Integer;
23
      end record;
24
25
      overriding procedure Display (R : Ext_Tagged_Rec);
26
      overriding procedure Reset (R : out Ext_Tagged_Rec);
27
      not overriding procedure New_Op (R : in out Ext_Tagged_Rec);
28
29
   end P;
30
```

```
Listing 50: p.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   package body P is
З
4
      procedure Display (R : Rec) is
5
       begin
6
          Put Line ("TYPE: REC");
7
          Put_Line ("Rec.V = " & Integer'Image (R.V));
8
          New Line;
9
10
      end Display;
11
       procedure Reset (R : out Rec) is
12
       begin
13
          R.V := 0:
14
      end Reset;
15
16
      procedure Display (R : New Rec) is
17
       beain
18
          Put_Line ("TYPE: NEW_REC");
19
          Put_Line ("New_Rec.V = " & Integer'Image (R.V));
20
          New_Line;
21
      end Display;
22
23
      procedure New_Op (R : in out New_Rec) is
24
       begin
25
          R.V := R.V + 1;
26
      end New Op;
27
28
       procedure Display (R : Tagged_Rec) is
29
      begin
30
              Using External_Tag attribute to retrieve the tag as a string
31
          - -
          Put_Line ("TYPE: " & Tagged_Rec'External_Tag);
32
          Put_Line ("Tagged_Rec.V = " & Integer'Image (R.V));
33
          New Line;
34
      end Display;
35
36
      procedure Reset (R : out Tagged Rec) is
37
       beain
38
          R.V := 0;
39
       end Reset;
40
```

(continues on next page)

(continued from previous page)

```
procedure Display (R : Ext_Tagged_Rec) is
42
      begin
43
              Using External_Tag attribute to retrieve the tag as a string
44
         Put_Line ("TYPE: " & Ext_Tagged_Rec'External_Tag);
45
         Put_Line ("Ext_Tagged_Rec.V = " & Integer'Image (R.V));
46
         Put_Line ("Ext_Tagged_Rec.V2 = " & Integer'Image (R.V2));
47
         New_Line;
48
      end Display;
49
50
      procedure Reset (R : out Ext_Tagged_Rec) is
51
      begin
52
53
          Tagged_Rec (R).Reset;
         R.V2 := 0;
54
      end Reset;
55
56
      procedure New_Op (R : in out Ext_Tagged_Rec) is
57
      begin
58
          R.V := R.V + 1;
59
      end New_0p;
60
61
   end P;
62
```

41

Listing 51: main.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
   with P;
                       use P;
2
3
   procedure Main is
4
      X_Rec
5
                           : Rec;
      X_New_Rec
6
                           : New_Rec;
7
      X Tagged Rec
                           : aliased Tagged Rec;
8
      X_Ext_Tagged_Rec
                           : aliased Ext_Tagged_Rec;
9
10
      X Tagged Rec Array : constant array (1 .. 2) of access Tagged Rec'Class
11
                              := (X_Tagged_Rec'Access, X_Ext_Tagged_Rec'Access);
12
   begin
13
14
       -- Reset all objects
15
       - -
16
      Reset (X_Rec);
17
      Reset (X_New_Rec);
18
                               -- we could write "Reset (X Tagged Rec)" as well
      X_Tagged_Rec.Reset;
19
      X_Ext_Tagged_Rec.Reset;
20
21
22
       -- Use new operations when available
23
24
      New_Op (X_New_Rec);
25
      X_Ext_Tagged_Rec.New_Op;
26
27
28
       -- Display all objects
29
30
      Display (X_Rec);
31
      Display (X New Rec);
32
      X_Tagged_Rec.Display; -- we could write "Display (X_Tagged_Rec)" as well
33
      X Ext Tagged Rec.Display;
34
35
36
```

```
-- Resetting and display objects of Tagged_Rec'Class
37
38
      Put_Line ("Operations on Tagged_Rec'Class");
39
      Put_Line ("-----
                                          ----");
40
      for E of X_Tagged_Rec_Array loop
41
         E.Reset;
42
         E.Display;
43
      end loop;
44
  end Main;
45
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Tagged_Type_Extension_Decl
MD5: 29412b74db6680f0a0986b62e5284cf7

Runtime output

```
TYPE: REC
Rec.V = 0
TYPE: NEW REC
New Rec.V = 1
TYPE: P.TAGGED REC
Tagged Rec.V = 0
TYPE: P.EXT TAGGED REC
Ext Tagged Rec.V = 1
Ext Tagged Rec.V2 = 0
Operations on Tagged_Rec'Class
TYPE: P.TAGGED_REC
Tagged Rec.V = 0
TYPE: P.EXT TAGGED REC
Ext_Tagged_Rec.V = 0
Ext Tagged Rec.V2 = 0
```

These are the similarities between untagged and tagged types:

- We can derive types and inherit operations in both cases.
 - Both X_New_Rec and X_Ext_Tagged_Rec inherit the Display and Reset procedures from their respective ancestors.
- We can override operations in both cases.
- We can implement new operations in both cases.
 - Both X_New_Rec and X_Ext_Tagged_Rec implement a procedure called New_Op, which is not available for their respective ancestors.

Now, let's look at the differences between untagged and tagged types:

- We can dispatch calls for a given type class.
 - This is what we do when we iterate over objects of the Tagged_Rec class in the loop over X_Tagged_Rec_Array at the last part of the Main procedure.
- We can use the dot notation.
 - We can write both E.Reset or Reset (E) forms: they're equivalent.

7.3.3.4 Dispatching calls

Let's look more closely at the dispatching calls implemented above. First, we declare the X_Tagged_Rec_Array array and initialize it with the access to objects of both parent and derived tagged types:

[Ada]

Here, we use the **aliased** keyword to be able to get access to the objects (via the 'Access attribute).

Then, we loop over this array and call the Reset and Display procedures:

[Ada]

```
for E of X_Tagged_Rec_Array loop
    E.Reset;
    E.Display;
end loop;
```

Since we're using dispatching calls, the actual procedure that is selected depends on the type of the object. For the first element (X_Tagged_Rec_Array (1)), this is Tagged_Rec, while for the second element (X_Tagged_Rec_Array (2)), this is Ext_Tagged_Rec.

Dispatching calls are only possible for a type class — for example, the Tagged_Rec'Class. When the type of an object is known at compile time, the calls won't dispatch at runtime. For example, the call to the Reset procedure of the X_Ext_Tagged_Rec object (X_Ext_Tagged_Rec.Reset) will always take the overriden Reset procedure of the Ext_Tagged_Rec type. Similarly, if we perform a view conversion by writing Tagged_Rec (A_Ext_Tagged_Rec).Display, we're instructing the compiler to interpret A_Ext_Tagged_Rec as an object of type Tagged_Rec, so that the compiler selects the Display procedure of the Tagged_Rec type.

7.3.3.5 Interfaces

Another useful feature of object-oriented programming is the use of interfaces. In this case, we can define abstract operations, and implement them in the derived tagged types. We declare an interface by simply writing **type T is interface**. For example:

[Ada]

```
type My_Interface is interface;
procedure Op (Obj : My_Interface) is abstract;
-- We cannot declare actual objects of an interface:
-- Obj : My_Interface; -- ERROR!
```

All operations on an interface type are abstract, so we need to write **is abstract** in the signature — as we did in the declaration of 0p above. Also, since interfaces are abstract types and don't have an actual implementation, we cannot declare objects for it.

We can derive tagged types from an interface and implement the actual operations of that interface:

[Ada]

type My_Derived is new My_Interface with null record;

procedure Op (Obj : My_Derived);

Note that we're not using the **tagged** keyword in the declaration because any type derived from an interface is automatically tagged.

Let's look at an example with an interface and two derived tagged types:

[Ada]

Listing 52: p.ads

```
package P is
1
2
      type Display Interface is interface;
3
      procedure Display (D : Display_Interface) is abstract;
4
5
      type Small_Display_Type is new Display_Interface with null record;
6
      procedure Display (D : Small_Display_Type);
7
8
      type Big_Display_Type is new Display_Interface with null record;
9
      procedure Display (D : Big_Display_Type);
10
11
   end P;
12
```

Listing 53: p.adb

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   package body P is
3
4
      procedure Display (D : Small_Display_Type) is
5
          pragma Unreferenced (D);
6
      begin
7
          Put_Line ("Using Small_Display_Type");
8
      end Display;
9
10
      procedure Display (D : Big_Display_Type) is
11
          pragma Unreferenced (D);
12
      begin
13
          Put_Line ("Using Big_Display_Type");
14
      end Display;
15
16
   end P;
17
```

Listing 54: main.adb

```
with P; use P;
1
2
   procedure Main is
3
      D_Small : Small_Display_Type;
4
               : Big_Display_Type;
      D Big
5
6
      procedure Dispatching_Display (D : Display_Interface'Class) is
7
      beain
8
          D.Display;
9
      end Dispatching_Display;
10
11
   begin
12
      Dispatching Display (D Small);
13
      Dispatching_Display (D_Big);
14
```

15 end Main;

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Interfaces_1
MD5: 564eba158b2f8fc3efea9e892a21caa9
```

Runtime output

Using Small_Display_Type Using Big_Display_Type

In this example, we have an interface type Display_Interface and two tagged types that are derived from Display_Interface: Small_Display_Type and Big_Display_Type.

Both types (Small_Display_Type and Big_Display_Type) implement the interface by overriding the Display procedure. Then, in the inner procedure Dispatching_Display of the Main procedure, we perform a dispatching call depending on the actual type of D.

7.3.3.6 Deriving from multiple interfaces

We may derive a type from multiple interfaces by simply writing type Derived_T is new T1 and T2 with null record. For example:

[Ada]

Listing 55: transceivers.ads

```
package Transceivers is
1
2
      type Send_Interface is interface;
3
4
      procedure Send (Obj : in out Send Interface) is abstract;
5
6
      type Receive Interface is interface;
7
8
      procedure Receive (Obj : in out Receive Interface) is abstract;
9
10
      type Transceiver is new Send Interface and Receive Interface
11
        with null record;
12
13
      procedure Send (D : in out Transceiver);
14
      procedure Receive (D : in out Transceiver);
15
16
   end Transceivers;
17
```

Listing 56: transceivers.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   package body Transceivers is
3
4
      procedure Send (D : in out Transceiver) is
5
6
         pragma Unreferenced (D);
7
      begin
         Put_Line ("Sending data...");
8
      end Send;
9
10
      procedure Receive (D : in out Transceiver) is
11
         pragma Unreferenced (D);
12
```

```
begin
13
          Put_Line ("Receiving data...");
14
       end Receive;
15
16
   end Transceivers;
17
```

Listing 57: main.adb

```
with Transceivers; use Transceivers;
1
2
   procedure Main is
3
      D : Transceiver;
4
   beain
5
      D.Send:
6
      D.Receive;
7
  end Main;
8
```

Code block metadata

```
Project: Courses.Ada For Embedded C Dev.Reusability.Multiple Interfaces
MD5: c81813941bd3458eaf7b1fd39b010a03
```

Runtime output

Sending data... Receiving data...

In this example, we're declaring two interfaces (Send Interface and Receive Interface) and the tagged type Transceiver that derives from both interfaces. Since we need to implement the interfaces, we implement both Send and Receive for Transceiver.

7.3.3.7 Abstract tagged types

We may also declare abstract tagged types. Note that, because the type is abstract, we cannot use it to declare objects for it — this is the same as for interfaces. We can only use it to derive other types. Let's look at the abstract tagged type declared in the Abstract Transceivers package:

[Ada]

Listing 58: abstract transceivers.ads

```
with Transceivers; use Transceivers;
1
2
    package Abstract_Transceivers is
3
4
       type Abstract_Transceiver is abstract new Send_Interface and
5
         Receive_Interface with null record;
6
7
       procedure Send (D : in out Abstract Transceiver);
8
       -- We don't implement Receive for Abstract_Transceiver!
9
10
11
```

end Abstract_Transceivers;

Listing 59: abstract_transceivers.adb

```
with Ada.Text IO; use Ada.Text IO;
1
    package body Abstract_Transceivers is
3
Λ
```

```
s procedure Send (D : in out Abstract_Transceiver) is
    pragma Unreferenced (D);
    begin
    Put_Line ("Sending data...");
    end Send;
    end Abstract_Transceivers;
```

Listing 60: main.adb

```
with Abstract_Transceivers; use Abstract_Transceivers;
procedure Main is
    D : Abstract_Transceiver;
begin
    D.Send;
    D.Receive;
    end Main;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Multiple_Interfaces
MD5: c2b0b3aab1ffc9c3b9a0749bf6721088
```

Build output

```
main.adb:4:09: error: type of object cannot be abstract
main.adb:7:06: error: call to abstract procedure must be dispatching
gprbuild: *** compilation phase failed
```

In this example, we declare the abstract tagged type Abstract_Transceiver. Here, we're only partially implementing the interfaces from which this type is derived: we're implementing Send, but we're skipping the implementation of Receive. Therefore, Receive is an abstract operation of Abstract_Transceiver. Since any tagged type that has abstract operations is abstract, we must indicate this by adding the **abstract** keyword in type declaration.

Also, when compiling this example, we get an error because we're trying to declare an object of Abstract_Transceiver (in the Main procedure), which is not possible. Naturally, if we derive another type from Abstract_Transceiver and implement Receive as well, then we can declare objects of this derived type. This is what we do in the Full_Transceivers below:

[Ada]

Listing 61: full_transceivers.ads

```
with Abstract_Transceivers; use Abstract_Transceivers;
package Full_Transceivers is
type Full_Transceiver is new Abstract_Transceiver with null record;
procedure Receive (D : in out Full_Transceiver);
end Full_Transceivers;
```

Listing 62: full transceivers.adb

```
with Ada.Text_I0; use Ada.Text_I0;
```

```
package body Full_Transceivers is
3
4
      procedure Receive (D : in out Full_Transceiver) is
5
         pragma Unreferenced (D);
6
      begin
7
         Put_Line ("Receiving data...");
8
      end Receive;
9
10
   end Full_Transceivers;
11
```

Listing 63: main.adb

```
with Full_Transceivers; use Full_Transceivers;
procedure Main is
    D : Full_Transceiver;
begin
    D.Send;
    D.Receive;
end Main;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Multiple_Interfaces
MD5: 77a86a6d917547d306a89422e7522111

Runtime output

Sending data... Receiving data...

Here, we implement the Receive procedure for the Full_Transceiver. Therefore, the type doesn't have any abstract operation, so we can use it to declare objects.

7.3.3.8 From simple derivation to OOP

In the *section about simple derivation* (page 158), we've seen an example where the actual selection was done at *implementation* time by renaming one of the packages:

[Ada]

```
with Drivers_1;
```

package Drivers renames Drivers_1;

Although this approach is useful in many cases, there might be situations where we need to select the actual driver dynamically at runtime. Let's look at how we could rewrite that example using interfaces, tagged types and dispatching calls:

[Ada]

Listing 64: drivers_base.ads

```
package Drivers_Base is

type Transceiver is interface;

procedure Send (Device : Transceiver; Data : Integer) is abstract;
procedure Receive (Device : Transceiver; Data : out Integer) is abstract;
procedure Display (Device : Transceiver) is abstract;
```

9 end Drivers_Base;

Listing 65: drivers 1.ads

```
with Drivers Base;
1
2
   package Drivers_1 is
3
4
      type Transceiver is new Drivers Base.Transceiver with null record;
5
6
      procedure Send (Device : Transceiver; Data : Integer);
7
      procedure Receive (Device : Transceiver; Data : out Integer);
8
      procedure Display (Device : Transceiver);
9
10
   end Drivers 1;
11
```

Listing 66: drivers_1.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   package body Drivers 1 is
3
4
      procedure Send (Device : Transceiver; Data : Integer) is null;
5
6
      procedure Receive (Device : Transceiver; Data : out Integer) is
7
         pragma Unreferenced (Device);
8
      begin
9
         Data := 42;
10
      end Receive;
11
12
      procedure Display (Device : Transceiver) is
13
         pragma Unreferenced (Device);
14
      begin
15
         Put_Line ("Using Drivers_1");
16
      end Display;
17
18
   end Drivers_1;
19
```

Listing 67: drivers_2.ads

```
with Drivers Base;
1
2
   package Drivers 2 is
3
4
      type Transceiver is new Drivers_Base.Transceiver with null record;
5
6
      procedure Send (Device : Transceiver; Data : Integer);
7
      procedure Receive (Device : Transceiver; Data : out Integer);
8
      procedure Display (Device : Transceiver);
9
10
   end Drivers 2;
11
```

Listing 68: drivers 2.adb

```
with Ada.Text_I0; use Ada.Text_I0;
package body Drivers_2 is
procedure Send (Device : Transceiver; Data : Integer) is null;
(continues on next page)
```

6

(continued from previous page)

```
procedure Receive (Device : Transceiver; Data : out Integer) is
7
         pragma Unreferenced (Device);
8
9
      begin
         Data := 7;
10
      end Receive;
11
12
      procedure Display (Device : Transceiver) is
13
         pragma Unreferenced (Device);
14
      begin
15
         Put_Line ("Using Drivers_2");
16
      end Display;
17
18
19
   end Drivers_2;
```

Listing 69: main.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   with Drivers_Base;
3
   with Drivers_1;
4
   with Drivers_2;
5
6
   procedure Main is
7
      D1 : aliased Drivers_1.Transceiver;
8
      D2 : aliased Drivers_2.Transceiver;
9
      D : access Drivers_Base.Transceiver'Class;
10
11
12
      I : Integer;
13
      type Driver_Number is range 1 .. 2;
14
15
      procedure Select_Driver (N : Driver_Number) is
16
      begin
17
          if N = 1 then
18
             D := D1'Access;
19
          else
20
             D := D2'Access;
21
          end if;
22
          D.Display;
23
      end Select_Driver;
24
25
26
   begin
      Select_Driver (1);
27
      D.Send (999);
28
      D.Receive (I);
29
      Put_Line (Integer'Image (I));
30
31
      Select Driver (2);
32
      D.Send (999);
33
      D.Receive (I);
34
      Put_Line (Integer'Image (I));
35
   end Main;
36
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Tagged_Drivers
MD5: d823b7231f1adf003fb6f545cb482308
```

Runtime output

Using Drivers_1 42 Using Drivers_2 7

In this example, we declare the Transceiver interface in the Drivers_Base package. This interface is then used to derive the tagged types Transceiver from both Drivers_1 and Drivers_2 packages.

In the Main procedure, we use the access to Transceiver'Class — from the interface declared in the Drivers_Base package — to declare D. This object D contains the access to the actual driver loaded at any specific time. We select the driver at runtime in the inner Select_Driver procedure, which initializes D (with the access to the selected driver). Then, any operation on D triggers a dispatching call to the selected driver.

7.3.3.9 Further resources

In the appendices, we have a step-by-step *hands-on overview of object-oriented programming* (page 225) that discusses how to translate a simple system written in C to an equivalent system in Ada using object-oriented programming.

7.3.4 Pointer to subprograms

Pointers to subprograms allow us to dynamically select an appropriate subprogram at runtime. This selection might be triggered by an external event, or simply by the user. This can be useful when multiple versions of a routine exist, and the decision about which one to use cannot be made at compilation time.

This is an example on how to declare and use pointers to functions in C:

[C]

Listing 70: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   void show_msg_v1 (char *msg)
4
5
   {
        printf("Using version #1: %s\n", msg);
6
   }
7
8
   void show msg v2 (char *msg)
9
   {
10
        printf("Using version #2:\n %s\n", msg);
11
   }
12
13
   int main()
14
15
   {
        int selection = 1;
16
        void (*current show msg) (char *);
17
18
        switch (selection)
19
        {
20
            case 1: current show msg = \&show msg v1;
                                                              break;
21
            case 2: current show msg = \& show msg v2;
                                                              break;
22
            default: current_show_msg = NULL;
                                                              break;
23
        }
24
25
        if (current_show_msg != NULL)
26
        {
27
```

```
current_show_msg ("Hello there!");
28
        }
29
        else
30
        {
31
             printf("ERROR: no version of show_msg() selected!\n");
32
        }
33
34
        return 0;
35
   }
36
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Selecting_Subprogram_C
MD5: 414c99fca2490611d20d031f8549ff59

Runtime output

Using version #1: Hello there!

The example above contains two versions of the show_msg() function: show_msg_v1() and show_msg_v2(). The function is selected depending on the value of selection, which initializes the function pointer current_show_msg. If there's no corresponding value, current_show_msg is set to null — alternatively, we could have selected a default version of show_msg() function. By calling current_show_msg ("Hello there!"), we're calling the function that current_show_msg is pointing to.

This is the corresponding implementation in Ada:

[Ada]

```
Listing 71: show_subprogram_selection.adb
```

```
with Ada.Text_IO; use Ada.Text_IO;
1
2
   procedure Show_Subprogram_Selection is
3
4
      procedure Show_Msg_V1 (Msg : String) is
5
       begin
6
          Put_Line ("Using version #1: " & Msg);
7
      end Show_Msg_V1;
8
9
      procedure Show_Msg_V2 (Msg : String) is
10
11
      begin
          Put_Line ("Using version #2: ");
12
          Put_Line (Msg);
13
      end Show_Msg_V2;
14
15
       type Show Msg Proc is access procedure (Msg : String);
16
17
      Current_Show_Msg : Show_Msg_Proc;
18
      Selection
                         : Natural;
19
20
   begin
21
      Selection := 1;
22
23
       case Selection is
24
          when 1
                      => Current_Show_Msg := Show_Msg_V1'Access;
25
          when 2
                      => Current_Show_Msg := Show_Msg_V2'Access;
26
          when others => Current_Show_Msg := null;
27
       end case;
28
29
```

```
if Current_Show_Msg /= null then
Current_Show_Msg ("Hello there!");
else
put_Line ("ERROR: no version of Show_Msg selected!");
end if;
end Show_Subprogram_Selection;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Selecting_Subprogram_Ada
MD5: ee41e042e3b879b4a2671bfe6d8072aa

Runtime output

Using version #1: Hello there!

The structure of the code above is very similar to the one used in the C code. Again, we have two version of Show_Msg: Show_Msg_V1 and Show_Msg_V2. We set Current_Show_Msg according to the value of Selection. Here, we use 'Access to get access to the corresponding procedure. If no version of Show_Msg is available, we set Current_Show_Msg to null.

Pointers to subprograms are also typically used as callback functions. This approach is extensively used in systems that process events, for example. Here, we could have a two-layered system:

- A layer of the system (an event manager) triggers events depending on information from sensors.
 - For each event, callback functions can be registered.
 - The event manager calls registered callback functions when an event is triggered.
- Another layer of the system registers callback functions for specific events and decides what to do when those events are triggered.

This approach promotes information hiding and component decoupling because:

- the layer of the system responsible for managing events doesn't need to know what the callback function actually does, while
- the layer of the system that implements callback functions remains agnostic to implementation details of the event manager for example, how events are implemented in the event manager.

Let's see an example in C where we have a process_values() function that calls a callback function (process_one) to process a list of values:

[C]

```
Listing 72: process_values.h
```

```
1 typedef int (*process_one_callback) (int);
2
3 void process_values (int *values,
4 int len,
5 process_one_callback process_one);
```

Listing 73: process_values.c

```
1 #include "process_values.h"
```

```
#include <assert.h>
3
   #include <stdio.h>
4
5
   void process_values (int
                                                   *values,
6
                           int
                                                    len,
7
                           process_one_callback process_one)
8
   {
9
        int i;
10
11
        assert (process_one != NULL);
12
13
        for (i = 0; i < len; i++)</pre>
14
15
        {
             values[i] = process_one (values[i]);
16
17
        }
   }
18
```

Listing 74: main.c

```
#include <stdio.h>
1
   #include <stdlib.h>
2
3
   #include "process_values.h"
4
5
   int proc_10 (int val)
6
   {
7
        return val + 10;
8
9
   }
10
                              5
   # define LEN_VALUES
11
12
   int main()
13
14
   {
15
        int values[LEN_VALUES] = { 1, 2, 3, 4, 5 };
16
        int i;
17
18
        process_values (values, LEN_VALUES, &proc_10);
19
20
        for (i = 0; i < LEN_VALUES; i++)
21
        {
22
            printf("Value [%d] = %d\n", i, values[i]);
23
        }
24
25
        return 0;
26
   }
27
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Callback_C MD5: ff5c8611d0901f40b6c4a9effeb0a323

Runtime output

Value [0] = 11 Value [1] = 12 Value [2] = 13 Value [3] = 14 Value [4] = 15

As mentioned previously, process_values() doesn't have any knowledge about what pro-

cess_one() does with the integer value it receives as a parameter. Also, we could replace $proc_10()$ by another function without having to change the implementation of $process_values()$.

Note that process_values() calls an assert() for the function pointer to compare it against null. Here, instead of checking the validity of the function pointer, we're expecting the caller of process_values() to provide a valid pointer.

This is the corresponding implementation in Ada:

[Ada]

Listing 75: values processing.ads

```
package Values_Processing is
1
2
      type Integer Array is array (Positive range <>) of Integer;
3
4
      type Process_One_Callback is not null access
5
        function (Value : Integer) return Integer;
6
7
      procedure Process_Values (Values : in out Integer_Array;
8
                                Process_One : Process_One_Callback);
9
10
   end Values_Processing;
11
```

Listing 76: values_processing.adb

```
package body Values_Processing is
1
2
      procedure Process Values (Values
                                            : in out Integer Array;
3
                                 Process One :
                                                Process One Callback) is
4
      begin
5
         for I in Values'Range loop
6
            Values (I) := Process_One (Values (I));
7
         end loop;
8
      end Process_Values;
9
10
   end Values Processing;
11
```

Listing 77: proc_10.ads

1 function Proc_10 (Value : Integer) return Integer;

Listing 78: proc 10.adb

```
1 function Proc_10 (Value : Integer) return Integer is
2 begin
3 return Value + 10;
4 end Proc_10;
```

Listing 79: show_callback.adb

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
  with Values Processing; use Values Processing;
3
  with Proc 10;
4
5
  procedure Show Callback is
6
      Values : Integer_Array := (1, 2, 3, 4, 5);
7
  begin
8
      Process Values (Values, Proc 10'Access);
9
```

```
10
       for I in Values'Range loop
11
          Put_Line ("Value ["
12
                     & Positive'Image (I)
13
                     & "] = "
14
                     & Integer'Image (Values (I)));
15
       end loop;
16
   end Show_Callback;
17
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.Callback_Ada MD5: f49c54f0d14193d305c0e962a392ab67

Runtime output

Value [1] = 11 Value [2] = 12 Value [3] = 13 Value [4] = 14 Value [5] = 15

Similar to the implementation in C, the Process Values procedure receives the access to a callback routine, which is then called for each value of the Values array.

Note that the declaration of Process One Callback makes use of the not null access declaration. By using this approach, we ensure that any parameter of this type has a valid value, so we can always call the callback routine.

7.4 Design by components using dynamic libraries

In the previous sections, we have shown how to use packages to create separate components of a system. As we know, when designing a complex system, it is advisable to separate concerns into distinct units, so we can use Ada packages to represent each unit of a system. In this section, we go one step further and create separate dynamic libraries for each component, which we'll then link to the main application.

Let's suppose we have a main system (Main System) and a component A (Component A) that we want to use in the main system. For example:

[Ada]

- -

Listing 80: component a.ads

```
1
      File: component a.ads
   - -
2
3
   package Component_A is
4
5
      type Float_Array is array (Positive range <>) of Float;
6
7
      function Average (Data : Float_Array) return Float;
8
9
```

```
end Component A;
10
```

Listing 81: component a.adb

```
File: component_a.adb
   - -
2
```

(continues on next page)

- -1

```
3
   - -
   package body Component_A is
4
5
      function Average (Data : Float_Array) return Float is
6
         Total : Float := 0.0;
7
      begin
8
          for Value of Data loop
9
             Total := Total + Value;
10
         end loop;
11
         return Total / Float (Data'Length);
12
      end Average;
13
14
   end Component_A;
15
```

Listing 82: main_system.adb

```
1
   - -
   - -
      File: main system.adb
2
3
   with Ada.Text IO; use Ada.Text IO;
4
5
   with Component_A; use Component_A;
6
7
   procedure Main_System is
8
      Values
                    : constant Float Array := (10.0, 11.0, 12.0, 13.0);
9
      Average Value : Float;
10
   begin
11
      Average Value := Average (Values);
12
      Put_Line ("Average = " & Float'Image (Average_Value));
13
   end Main System;
14
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Reusability.System_For_Dyn_Lib MD5: d759132b787e636d4bcd5f8cd6393f2a

Runtime output

```
Average = 1.15000E+01
```

Note that, in the source-code example above, we're indicating the name of each file. We'll now see how to organize those files in a structure that is suitable for the GNAT build system (**GPRbuild**).

In order to discuss how to create dynamic libraries, we need to dig into some details about the build system. With GNAT, we can use project files for **GPRbuild** to easily design dynamic libraries. Let's say we use the following directory structure for the code above:

Here, we have two directories: *component_a* and *main_system*. Each directory contains a project file (with the *.gpr* file extension) and a source-code directory (*src*).

In the source-code example above, we've seen the content of files component_a.ads,

component_a.adb and main_system.adb. Now, let's discuss how to write the project file for Component_A (component_a.gpr), which will build the dynamic library for this component:

library project Component_A is

for Source_Dirs use ("src"); for Object_Dir use "obj"; for Create_Missing_Dirs use "True"; for Library_Name use "component_a"; for Library_Kind use "dynamic"; for Library_Dir use "lib";

```
end Component_A;
```

The project is defined as a *library project* instead of *project*. This tells **GPRbuild** to build a library instead of an executable binary. We then specify the library name using the *Library_Name* attribute, which is required, so it must appear in a library project. The next two library-related attributes are optional, but important for our use-case. We use:

- *Library_Kind* to specify that we want to create a dynamic library by default, this attribute is set to *static*;
- Library Dir to specify the directory where the library is stored.

In the project file of our main system (main_system.gpr), we just need to reference the project of Component_A using a *with* clause and indicating the correct path to that project file:

```
with "../component_a/component_a.gpr";
project Main_System is
   for Source_Dirs use ("src");
   for Object_Dir use "obj";
   for Create_Missing_Dirs use "True";
   for Main use ("main_system.adb");
end Main System;
```

GPRbuild takes care of selecting the correct settings to link the dynamic library created for Component_A with the main application (Main_System) and build an executable.

We can use the same strategy to create a Component_B and dynamically link to it in the Main_System. We just need to create the separate structure for this component — with the appropriate Ada packages and project file — and include it in the project file of the main system using a *with* clause:

```
with "../component_a/component_a.gpr";
with "../component_b/component_b.gpr";
```

• • •

Again, **GPRbuild** takes care of selecting the correct settings to link both dynamic libraries together with the main application.

You can find more details and special setting for library projects in the GPRbuild documentation¹⁸.

In the GNAT toolchain

The GNAT toolchain includes a more advanced example focusing on how to load dynamic libraries at runtime. You can find it in the share/examples/gnat/plugins directory of the GNAT toolchain installation. As described in the README file from that directory, this

¹⁸ https://docs.adacore.com/gprbuild-docs/html/gprbuild_ug/gnat_project_manager.html#library-projects

example "comprises a main program which probes regularly for the existence of shared libraries in a known location. If such libraries are present, it uses them to implement features initially not present in the main program."

PERFORMANCE CONSIDERATIONS

8.1 Overall expectations

All in all, there should not be significant performance differences between code written in Ada and code written in C, provided that they are semantically equivalent. Taking the current GNAT implementation and its GCC C counterpart for example, most of the code generation and optimization phases are shared between C and Ada — so there's not one compiler more efficient than the other. Furthermore, the two languages are fairly similar in the way they implement imperative semantics, in particular with regards to memory management or control flow. They should be equivalent on average.

When comparing the performance of C and Ada code, differences might be observed. This usually comes from the fact that, while the two piece *appear* semantically equivalent, they happen to be actually quite different; C code semantics do not implicitly apply the same run-time checks that Ada does. This section will present common ways for improving Ada code performance.

8.2 Switches and optimizations

Clever use of compilation switches might optimize the performance of an application significantly. In this section, we'll briefly look into some of the switches available in the GNAT toolchain.

8.2.1 Optimizations levels

Optimization levels can be found in many compilers for multiple languages. On the lowest level, the GNAT compiler doesn't optimize the code at all, while at the higher levels, the compiler analyses the code and optimizes it by removing unnecessary operations and making the most use of the target processor's capabilities.

By being part of GCC, GNAT offers the same -0_ switches as GCC:

Switc Description	
-00	No optimization: the generated code is completely unoptimized. This is the default optimization level.
-01	Moderate optimization.
- 02	Full optimization.
-03	Same optimization level as for -02. In addition, further optimization strategies, such as aggressive automatic inlining and vectorization.

Note that the higher the level, the longer the compilation time. For fast compilation during development phase, unless you're working on benchmarking algorithms, using -00 is probably a good idea.

In addition to the levels presented above, GNAT also has the -0s switch, which allows for optimizing code and data usage.

8.2.2 Inlining

As we've seen in the previous section, automatic inlining depends on the optimization level. The highest optimization level (-03), for example, performs aggressive automatic inlining. This could mean that this level inlines too much rather than not enough. As a result, the cache may become an issue and the overall performance may be worse than the one we would achieve by compiling the same code with optimization level 2 (-02). Therefore, the general recommendation is to not *just* select -03 for the optimized version of an application, but instead compare it the optimized version built with -02.

In some cases, it's better to reduce the optimization level and perform manual inlining instead of automatic inlining. We do that by using the Inline aspect. Let's reuse an example from a previous chapter and inline the Average function:

[Ada]

Listing 1: float_arrays.ads

```
package Float_Arrays is
type Float_Array is array (Positive range <>) of Float;
function Average (Data : Float_Array) return Float
with Inline;
end Float_Arrays;
```

Listing 2: float_arrays.adb

```
package body Float Arrays is
1
2
      function Average (Data : Float_Array) return Float is
3
         Total : Float := 0.0;
4
      beain
5
         for Value of Data loop
6
            Total := Total + Value;
7
         end loop;
8
         return Total / Float (Data'Length);
9
      end Average;
10
11
   end Float_Arrays;
12
```

Listing 3: compute_average.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   with Float Arrays; use Float Arrays;
3
4
   procedure Compute Average is
5
                    : constant Float_Array := (10.0, 11.0, 12.0, 13.0);
      Values
6
      Average_Value : Float;
7
   begin
8
      Average Value := Average (Values);
9
      Put Line ("Average = " & Float'Image (Average Value));
10
  end Compute Average;
11
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Inlining MD5: faf9d0d8cd5aefd7a48bcd950b1256fa

Runtime output

```
Average = 1.15000E+01
```

When compiling this example, GNAT will inline Average in the Compute_Average procedure.

In order to effectively use this aspect, however, we need to set the optimization level to at least -01 and use the -gnatn switch, which instructs the compiler to take the Inline aspect into account.

Note, however, that the Inline aspect is just a *recommendation* to the compiler. Sometimes, the compiler might not be able to follow this recommendation, so it won't inline the subprogram. In this case, we get a compilation warning from GNAT.

These are some examples of situations where the compiler might not be able to inline a subprogram:

- when the code is too large,
- when it's too complicated for example, when it involves exception handling —, or
- when it contains tasks, etc.

In addition to the Inline aspect, we also have the Inline_Always aspect. In contrast to the former aspect, however, the Inline_Always aspect isn't primarily related to performance. Instead, it should be used when the functionality would be incorrect if inlining was not performed by the compiler. Examples of this are procedures that insert Assembly instructions that only make sense when the procedure is inlined, such as memory barriers.

Similar to the Inline aspect, there might be situations where a subprogram has the Inline_Always aspect, but the compiler is unable to inline it. In this case, we get a compilation error from GNAT.

8.3 Checks and assertions

8.3.1 Checks

Ada provides many runtime checks to ensure that the implementation is working as expected. For example, when accessing an array, we would like to make sure that we're not accessing a memory position that is not allocated for that array. This is achieved by an index check.

Another example of runtime check is the verification of valid ranges. For example, when adding two integer numbers, we would like to ensure that the result is still in the valid range — that the value is neither too large nor too small. This is achieved by an range check. Likewise, arithmetic operations shouldn't overflow or underflow. This is achieved by an overflow check.

Although runtime checks are very useful and should be used as much as possible, they can also increase the overhead of implementations at certain hot-spots. For example, checking the index of an array in a sorting algorithm may significantly decrease its performance. In those cases, suppressing the check may be an option. We can achieve this suppression by using **pragma** *Suppress* (Index_Check). For example:

[Ada]

```
procedure Sort (A : in out Integer_Array) is
    pragma Suppress (Index_Check);
begin
```

```
-- (implementation removed...)
null;
end Sort;
```

In case of overflow checks, we can use **pragma** *Suppress* (Overflow_Check) to suppress them:

```
function Some_Computation (A, B : Int32) return Int32 is
    pragma Suppress (Overflow_Check);
begin
    -- (implementation removed...)
    null;
end Sort;
```

We can also deactivate overflow checks for integer types using the -gnato switch when compiling a source-code file with GNAT. In this case, overflow checks in the whole file are deactivated.

It is also possible to suppress all checks at once using **pragma** *Suppress* (All_Checks). In addition, GNAT offers a compilation switch called -gnatp, which has the same effect on the whole file.

Note, however, that this kind of suppression is just a recommendation to the compiler. There's no guarantee that the compiler will actually suppress any of the checks because the compiler may not be able to do so — typically because the hardware happens to do it. For example, if the machine traps on any access via address zero, requesting the removal of null access value checks in the generated code won't prevent the checks from happening.

It is important to differentiate between required and redundant checks. Let's consider the following example in C:

[C]

Listing 4: main.c

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
4
   {
        int a = 8, b = 0, res;
5
6
        res = a / b;
7
8
        // printing the result
9
        printf("res = %d\n", res);
10
11
        return 0;
12
   }
13
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Division_By_Zero_C
MD5: c8d95cbdd76618108119886c27ce7eb6

Because C doesn't have language-defined checks, as soon as the application tries to divide a value by zero in res = a / b, it'll break — on Linux, for example, you may get the following error message by the operating system: Floating point exception (core dumped). Therefore, we need to manually introduce a check for zero before this operation. For example:

[C]

```
Listing 5: main.c
```

```
#include <stdio.h>
1
2
   int main(int argc, const char * argv[])
3
   {
4
        int a = 8, b = 0, res;
5
6
        if (b != 0) {
7
            res = a / b;
8
9
            // printing the result
10
            printf("res = %d\n", res);
11
        }
12
        else
13
        {
14
            // printing error message
15
            printf("Error: cannot calculate value (division by zero)\n");
16
        }
17
18
        return 0;
19
   }
20
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Performance.Division_By_Zero_Check_C
MD5: 67ea0140d8248674b4aac06825c7cdbe
```

Runtime output

```
Error: cannot calculate value (division by zero)
```

This is the corresponding code in Ada:

[Ada]

```
Listing 6: show_division_by_zero.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   procedure Show_Division_By_Zero is
3
      A : Integer := 8;
4
      В
         : Integer := 0;
5
      Res : Integer;
6
   begin
7
      Res := A / B;
8
9
      Put Line ("Res = " & Integer'Image (Res));
10
   end Show_Division_By_Zero;
11
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Performance.Division_By_Zero_Ada
MD5: 2af6690eb977203ef7ce2178d15255af
```

Build output

Runtime output

raised CONSTRAINT_ERROR : show_division_by_zero.adb:8 divide by zero

Similar to the first version of the C code, we're not explicitly checking for a potential division by zero here. In Ada, however, this check is *automatically inserted* by the language itself. When running the application above, an exception is raised when the application tries to divide the value in A by zero. We could introduce exception handling in our example, so that we get the same message as we did in the second version of the C code:

[Ada]

Listing 7: show_division_by_zero.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Show Division By Zero is
3
      A : Integer := 8;
4
      В
          : Integer := 0;
5
      Res : Integer;
6
   beain
7
      Res := A / B;
8
9
      Put Line ("Res = " & Integer'Image (Res));
10
   exception
11
12
      when Constraint Error =>
         Put_Line ("Error: cannot calculate value (division by zero)");
13
      when others =>
14
         null:
15
  end Show Division By Zero;
16
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Division_By_Zero_Check_Ada
MD5: a96a94c15fda5f6c5feb232d615b1ea3

Build output

Runtime output

Error: cannot calculate value (division by zero)

This example demonstrates that the division check for Res := A / B is required and shouldn't be suppressed. In contrast, a check is redundant — and therefore not required — when we know that the condition that leads to a failure can never happen. In many cases, the compiler itself detects redundant checks and eliminates them (for higher optimization levels). Therefore, when improving the performance of your application, you should:

- 1. keep all checks active for most parts of the application;
- 2. identify the hot-spots of your application;
- 3. identify which checks haven't been eliminated by the optimizer on these hot-spots;
- 4. identify which of those checks are redundant;
- 5. only suppress those checks that are redundant, and keep the required ones.

8.3.2 Assertions

We've already discussed assertions in *this section of the SPARK chapter* (page 112). Assertions are user-defined checks that you can add to your code using the **pragma** *Assert*. For example:

[Ada]

```
function Some_Computation (A, B : Int32) return Int32 is
    Res : Int32;
begin
    -- (implementation removed...)
    pragma Assert (Res >= 0);
    return Res;
end Sort;
```

Assertions that are specified with **pragma** Assert are not enabled by default. You can enable them by setting the assertion policy to *check* — using **pragma** Assertion_Policy (Check) — or by using the -gnata switch when compiling with GNAT.

Similar to the checks discussed previously, assertions can generate significant overhead when used at hot-spots. Restricting those assertions to development (e.g. debug version) and turning them off on the release version may be an option. In this case, formal proof — as discussed in the *SPARK chapter* (page 105) — can help you. By formally proving that assertions will never fail at run-time, you can safely deactivate them.

8.4 Dynamic vs. static structures

Ada generally speaking provides more ways than C or C++ to write simple dynamic structures, that is to say structures that have constraints computed after variables. For example, it's quite typical to have initial values in record types:

[Ada]

```
type R is record
    F : Some_Field := Call_To_Some_Function;
end record;
```

However, the consequences of the above is that any declaration of a instance of this type without an explicit value for F will issue a call to Call_To_Some_Function. More subtle issue may arise with elaboration. For example, it's possible to write:

```
Listing 8: some_functions.ads
```

```
package Some_Functions is
function Some_Function_Call return Integer is (2);
function Some_Other_Function_Call return Integer is (10);
end Some_Functions;
```

Listing 9: values.ads

```
with Some_Functions; use Some_Functions;
package Values is
A_Start : Integer := Some_Function_Call;
```

```
5 A_End : Integer := Some_Other_Function_Call;
6 end Values;
```

Listing 10: arr_def.ads

```
with Values; use Values;
package Arr_Def is
type Arr is array (Integer range A_Start .. A_End) of Integer;
end Arr_Def;
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Performance.Dynamic_Array
MD5: 0c97cecb64d27e935724c8b5f941fb4f
```

It may indeed be appealing to be able to change the values of A_Start and A_End at startup so as to align a series of arrays dynamically. The consequence, however, is that these values will not be known statically, so any code that needs to access to boundaries of the array will need to read data from memory. While it's perfectly fine most of the time, there may be situations where performances are so critical that static values for array boundaries must be enforced.

Here's a last case which may also be surprising:

[Ada]

Listing 11: arr def.ads

```
package Arr_Def is
type Arr is array (Integer range <>) of Integer;

type R (D1, D2 : Integer) is record
F1 : Arr (1 .. D1);
F2 : Arr (1 .. D2);
end record;
end Arr_Def;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Record_With_Arrays
MD5: e7b2656433279d36db87506276b68398

In the code above, R contains two arrays, F1 and F2, respectively constrained by the discriminant D1 and D2. The consequence is, however, that to access F2, the run-time needs to know how large F1 is, which is dynamically constrained when creating an instance. Therefore, accessing to F2 requires a computation involving D1 which is slower than, let's say, two pointers in an C array that would point to two different arrays.

Generally speaking, when values are used in data structures, it's useful to always consider where they're coming from, and if their value is static (computed by the compiler) or dynamic (only known at run-time). There's nothing fundamentally wrong with dynamically constrained types, unless they appear in performance-critical pieces of the application.

8.5 Pointers vs. data copies

In the section about *pointers* (page 132), we mentioned that the Ada compiler will automatically pass parameters by reference when needed. Let's look into what "when needed" means. The fundamental point to understand is that the parameter types determine how the parameters are passed in and/or out. The parameter modes do not control how parameters are passed.

Specifically, the language standards specifies that scalar types are always passed by value, and that some other types are always passed by reference. It would not make sense to make a copy of a task when passing it as a parameter, for example. So parameters that can be passed reasonably by value will be, and those that must be passed by reference will be. That's the safest approach.

But the language also specifies that when the parameter is an array type or a record type, and the record/array components are all by-value types, then the compiler decides: it can pass the parameter using either mechanism. The critical case is when such a parameter is large, e.g., a large matrix. We don't want the compiler to pass it by value because that would entail a large copy, and indeed the compiler will not do so. But if the array or record parameter is small, say the same size as an address, then it doesn't matter how it is passed and by copy is just as fast as by reference. That's why the language gives the choice to the compiler. Although the language does not mandate that large parameters be passed by reference, any reasonable compiler will do the right thing.

The modes do have an effect, but not in determining how the parameters are passed. Their effect, for parameters passed by value, is to determine how many times the value is copied. For mode **in** and mode **out** there is just one copy. For mode **in out** there will be two copies, one in each direction.

Therefore, unlike C, you don't have to use access types in Ada to get better performance when passing arrays or records to subprograms. The compiler will almost certainly do the right thing for you.

Let's look at this example:

[C]

Listing 12: main.c

```
#include <stdio.h>
1
2
   struct Data {
3
        int prev, curr;
4
   };
5
6
   void update(struct Data *d,
7
                 int
                                 v)
8
   {
9
        d->prev = d->curr;
10
        d \rightarrow curr = v;
11
   }
12
13
   void display(const struct Data *d)
14
   {
15
        printf("Prev : %d\n", d->prev);
16
        printf("Curr : %d\n", d->curr);
17
   }
18
19
   int main(int argc, const char * argv[])
20
   {
21
        struct Data D1 = { 0, 1 };
22
23
        update (\&D1, 3);
24
        display (&D1);
25
26
        return 0;
27
   }
28
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Passing_Rec_By_Reference_C
MD5: 9087e26168e49d095b5e0776d6330d69

Runtime output

Prev : 1 Curr : 3

In this C code example, we're using pointers to pass D1 as a reference to update and display. In contrast, the equivalent code in Ada simply uses the parameter modes to specify the data flow directions. The mechanisms used to pass the values do not appear in the source code.

[Ada]

Listing 13: update_record.adb

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Update Record is
З
4
       type Data is record
5
          Prev : Integer;
6
          Curr : Integer;
7
      end record;
8
9
      procedure Update (D : in out Data;
10
                          V :
                                     Integer) is
11
      begin
12
          D.Prev := D.Curr:
13
          D.Curr := V;
14
      end Update;
15
16
      procedure Display (D : Data) is
17
      begin
18
          Put Line ("Prev: " & Integer'Image (D.Prev));
19
          Put Line ("Curr: " & Integer'Image (D.Curr));
20
      end Display;
21
22
      D1 : Data := (0, 1);
23
24
   begin
25
      Update (D1, 3);
26
      Display (D1);
27
   end Update Record;
28
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Passing_Rec_By_Reference_Ada
MD5: 6c64fb73e2cf490c0a129f0cd73c190b

Runtime output

Prev: 1 Curr: 3

In the calls to Update and Display, D1 is always be passed by reference. Because no extra copy takes place, we get a performance that is equivalent to the C version. If we had used arrays in the example above, D1 would have been passed by reference as well:

[Ada]

```
Listing 14: update_array.adb
```

```
with Ada.Text IO; use Ada.Text IO;
1
2
   procedure Update Array is
3
4
      type Data_State is (Prev, Curr);
5
      type Data is array (Data_State) of Integer;
6
7
      procedure Update (D : in out Data;
8
                          V :
                                      Integer) is
9
      begin
10
          D (Prev) := D (Curr);
11
          D (Curr) := V;
12
      end Update;
13
14
      procedure Display (D : Data) is
15
      begin
16
          Put Line ("Prev: " & Integer'Image (D (Prev)));
17
          Put_Line ("Curr: " & Integer'Image (D (Curr)));
18
      end Display;
19
20
      D1 : Data := (0, 1);
21
22
   begin
23
      Update (D1, 3);
24
      Display (D1);
25
   end Update_Array;
26
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Passing_Array_By_Reference_Ada
MD5: 5fb27811f34543fc4150eb4fddbe7034

Runtime output

Prev: 1 Curr: 3

Again, no extra copy is performed in the calls to Update and Display, which gives us optimal performance when dealing with arrays and avoids the need to use access types to optimize the code.

8.5.1 Function returns

Previously, we've discussed the cost of passing complex records as arguments to subprograms. We've seen that we don't have to use explicit access type parameters to get better performance in Ada. In this section, we'll briefly discuss the cost of function returns.

In general, we can use either procedures or functions to initialize a data structure. Let's look at this example in C:

[C]

Listing 15: main.c

```
1 #include <stdio.h>
2
3 struct Data {
4 int prev, curr;
5 };
```

```
6
   void init_data(struct Data *d)
7
    {
8
         d \rightarrow prev = 0;
9
         d \rightarrow curr = 1;
10
   }
11
12
    struct Data get_init_data()
13
    {
14
         struct Data d = { 0, 1 };
15
16
         return d;
17
18
    }
19
    int main(int argc, const char * argv[])
20
21
    {
         struct Data D1;
22
23
         D1 = get_init_data();
24
25
         init_data(&D1);
26
27
         return 0;
28
   }
29
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.Performance.Init_Rec_Proc_And_Func_C
MD5: 0586636d5e25c0d6bec2257af75ae998
```

This code example contains two subprograms that initialize the Data structure:

- init_data(), which receives the data structure as a reference (using a pointer) and initializes it, and
- get_init_data(), which returns the initialized structure.

In C, we generally avoid implementing functions such as get_init_data() because of the extra copy that is needed for the function return.

This is the corresponding implementation in Ada:

[Ada]

Listing 16: init_record.adb

```
procedure Init_Record is
1
2
       type Data is record
3
          Prev : Integer;
4
          Curr : Integer;
5
      end record;
6
7
      procedure Init (D : out Data) is
8
      begin
9
          D := (Prev => 0, Curr => 1);
10
      end Init;
11
12
       function Init return Data is
13
          D : constant Data := (Prev => 0, Curr => 1);
14
       begin
15
          return D;
16
      end Init;
17
```

```
18
19 D1 : Data;
20
21 pragma Unreferenced (D1);
22 begin
23 D1 := Init;
24
25 Init (D1);
26 end Init_Record;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Init_Rec_Proc_And_Func_Ada
MD5: 0f930eea432a82d78840b72c0714b283

Build output

In this example, we have two versions of Init: one using a procedural form, and the other one using a functional form. Note that, because of Ada's support for subprogram overloading, we can use the same name for both subprograms.

The issue is that assignment of a function result entails a copy, just as if we assigned one variable to another. For example, when assigning a function result to a constant, the function result is copied into the memory for the constant. That's what is happening in the above examples for the initialized variables.

Therefore, in terms of performance, the same recommendations apply: for large types we should avoid writing functions like the Init function above. Instead, we should use the procedural form of Init. The reason is that the compiler necessarily generates a copy for the Init function, while the Init procedure uses a reference for the output parameter, so that the actual record initialization is performed in place in the caller's argument.

An exception to this is when we use functions returning values of limited types, which by definition do not allow assignment. Here, to avoid allowing something that would otherwise look suspiciously like an assignment, the compiler generates the function body so that it builds the result directly into the object being assigned. No copy takes place.

We could, for example, rewrite the example above using limited types:

[Ada]

Listing 17: init_limited_record.adb

```
procedure Init Limited Record is
1
2
       type Data is limited record
3
          Prev : Integer;
4
          Curr : Integer;
5
       end record:
6
7
       function Init return Data is
8
      begin
9
          return D : Data do
10
             D.Prev := 0;
11
             D.Curr := 1;
12
          end return;
13
      end Init;
14
15
      D1 : Data := Init;
16
```

```
17
18
pragma Unreferenced (D1);
19
begin
20
null;
21
end Init_Limited_Record;
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.Performance.Init_Lim_Rec_Proc_And_Func_Ada
MD5: 57fc1b3f69b42dd4633b0c67e252c2d2

In this example, D1 : Data := Init; has the same cost as the call to the procedural form - Init (D1); - that we've seen in the previous example. This is because the assignment is done in place.

Note that limited types require the use of the extended return statements (**return ... do** ... **end** return) in function implementations. Also note that, because the Data type is limited, we can only use the Init function in the declaration of D1; a statement in the code such as D1 := Init; is therefore forbidden.

ARGUMENTATION AND BUSINESS PERSPECTIVES

The technical benefits of a migration from C to Ada are usually relatively straightforward to demonstrate. Hopefully, this course provides a good basis for it. However, when faced with an actual business decision to make, additional considerations need to be taken into account, such as return on investment, perennity of the solution, tool support, etc. This section will cover a number of usual questions and provide elements of answers.

9.1 What's the expected ROI of a C to Ada transition?

Switching from one technology to another is a cost, may that be in terms of training, transition of the existing environment or acquisition of new tools. This investment needs to be matched with an expected return on investment, or ROI, to be consistent. Of course, it's incredibly difficult to provide a firm answer to how much money can be saved by transitioning, as this is highly dependent on specific project objectives and constraints. We're going to provide qualitative and quantitative arguments here, from the perspective of a project that has to reach a relatively high level of integrity, that is to say a system where the occurrence of a software failure is a relatively costly event.

From a qualitative standpoint, there are various times in the software development life cycle where defects can be found:

- 1. on the developer's desk
- 2. during component testing
- 3. during integration testing
- 4. after deployment
- 5. during maintenance

Numbers from studies vary greatly on the relative costs of defects found at each of these phases, but there's a clear ordering between them. For example, a defect found while developing is orders of magnitude less expensive to fix than a defect found e.g. at integration time, which may involve costly debugging sessions and slow down the entire system acceptance. The whole purpose of Ada and SPARK is to push defect detection to the developer's desk as much as possible; at least for all of these defects that can be identified at that level. While the strict act of writing software may be taking more effort because of all of the additional safeguards, this should have a significant and positive impact down the line and help to control costs overall. The exact value this may translate into is highly business dependent.

From a quantitative standpoint, two studies have been done almost 25 years apart and provide similar insights:

- Rational Software in 1995 found that the cost of developing software in Ada was overall half as much as the cost of developing software in C.
- VDC ran a study in 2018, finding that the cost savings of developing with Ada over C ranged from 6% to 38% in savings.

From a qualitative standpoint, in particular with regards to Ada and C from a formal proof perspective, an interesting presentation was made in 2017 by two researchers. They tried to apply formal proof on the same piece of code, developed in Ada/SPARK on one end and C/Frama-C on the other. Their results indicate that the Ada/SPARK technology is indeed more conducive to formal proof methodologies.

Although all of these studies have their own biases, they provide a good idea of what to expect in terms of savings once the initial investment in switching to Ada is made. This is assuming everything else is equal, in particular that the level of integrity is the same. In many situations, the migration to Ada is justified by an increase in terms of integrity expectations, in which case it's expected that development costs will rise (it's more expensive to develop better software) and Ada is viewed as a means to mitigate this rise in development costs.

That being said, the point of this argument is not to say that it's not possible to write very safe and secure software with languages different than Ada. With the right expertise, the right processes and the right tools, it's done every day. The point is that Ada overall reduces the level of processes, expertise and tools necessary and will allow to reach the same target at a lower cost.

9.2 Who is using Ada today?

Ada was initially born as a DoD project, and thus got its initial customer base in aerospace and defence (A&D). At the time these lines are written and from the perspective of AdaCore, A&D is still the largest consumer of Ada today and covers about 70% of the market. This creates a consistent and long lasting set of established users as these project last often for decades, using the same codebase migrating from platform to platform.

More recently however, there has been an emerging interest for Ada in new communities of users such as automotive, medical device, industrial automation and overall cyber-security. This can probably be explained by a rise of safety, reliability and cyber-security requirements. The market is moving relatively rapidly today and we're anticipating an increase of the Ada footprint in these domains, while still remaining a technology of choice for the development of mission critical software.

9.3 What is the future of the Ada technology?

The first piece of the answer lies in the user base of the Ada language, as seen in the previous question. Projects using Ada in the aerospace and defence domain maintain source code over decades, providing healthy funding foundation for Ada-based technologies.

AdaCore being the author of this course, it's difficult for us to be fair in our description of other Ada compilation technologies. We will leave to the readers the responsibility of forging their own opinion. If they present a credible alternative to the GNAT compiler, then this whole section can be considered as void.

Assuming GNAT is the only option available, and acknowledging that this is an argument that we're hearing from a number of Ada adopters, let's discuss the "sole source" issue.

First of all, it's worth noting that industries are using a lot of software that is provided by only one source, so while non-ideal, these situations are also quite common.

In the case of the GNAT compiler however, while AdaCore is the main maintainer, this maintenance is done as part of an open-source community. This means that nothing prevents a third party to start selling a competing set of products based on the same compiler, provided that it too adopts the open-source approach. Our job is to be more cost-effective than the alternative, and indeed for the vast part this has prevented a competing offering to emerge. However, should AdaCore disappear or switch focus, Ada users would not be prevented from carrying on using its software (there is no lock) and a third party could take over maintenance. This is not a theoretical case, this has been done in the past either by companies looking at supporting their own version of GNAT, vendors occupying a specific niche that was left uncovered , or hobbyists developing their own builds.

With that in mind, it's clear that the "sole source" provider issue is a circumstantial — nothing is preventing other vendors from emerging if the conditions are met.

9.4 Is the Ada toolset complete?

A language by itself is of little use for the development of safety-critical software. Instead, a complete toolset is needed to accompany the development process, in particular tools for edition, testing, static analysis, etc.

AdaCore provides a number of these tools either in through its core or add-on package. These include (as of 2019):

- An IDE (GNAT Studio)
- An Eclipse plug-in (GNATbench)
- A debugger (GDB)
- A testing tool (GNATtest)
- A structural code coverage tool (GNATcoverage)
- A metric computation tool (GNATmetric)
- A coding standard checker (GNATcheck)
- Static analysis tools (CodePeer, SPARK Pro)
- A Simulink code generator (QGen)
- An Ada parser to develop custom tools (libadalang)

Ada is, however, an internationally standardized language, and many companies are providing third party solutions to complete the toolset. Overall, the language can be and is used with tools on par with their equivalent C counterparts.

9.5 Where can I find Ada or SPARK developers?

A common question from teams on the verge of selecting Ada and SPARK is how to manage the developer team growth and turnover. While Ada and SPARK are taught by a growing number of universities worldwide, it may still be challenging to hire new staff with prior Ada experience.

Fortunately, Ada's base semantics are very close to those of C/C++, so that a good embedded software developer should be able to learn it relatively easily. This course is definitely a resource available to get started. Online training material is also available, together with on-site in person training.

In general, getting an engineer operational in Ada and SPARK shouldn't take more than a few weeks worth of time.

9.6 How to introduce Ada and SPARK in an existing code base?

The most common scenario when introducing Ada and SPARK to a project or a team is to do it within a pre-existing C codebase, which can already spread over hundreds of thousands if

not millions lines of code. Re-writing this software to Ada or SPARK is of course not practical and counterproductive.

Most teams select either a small piece of existing code which deserves particular attention, or new modules to develop, and concentrate on this. Developing this module or part of the application will also help in developing the coding patterns to be used for the particular project and company. This typically concentrates an effort of a few people on a few thousands lines of code. The resulting code can be linked to the rest of the C application. From there, the newly established practices and their benefit can slowly spread through the rest of the environment.

Establishing this initial core in Ada and SPARK is critical, and while learning the language isn't a particularly difficult task, applying it to its full capacity may require some expertise. One possibility to accelerate this initial process is to use AdaCore mentorship services.

CONCLUSION

Although Ada's syntax might seem peculiar to C developers at first glance, it was designed to increase readability and maintainability, rather than making it faster to write in a condensed manner — as it is often the case in C.

Especially in the embedded domain, C developers are used to working at a very low level, which includes mathematical operations on pointers, complex bit shifts, and logical bitwise operations. C is well designed for such operations because it was designed to replace Assembly language for faster, more efficient programming.

Ada can be used to describe high level semantics and architectures. The beauty of the language, however, is that it can be used all the way down to the lowest levels of the development, including embedded Assembly code or bit-level data management. However, although Ada supports bitwise operations such as masks and shifts, they should be relatively rarely needed. When translating C code to Ada, it's good practice to consider alternatives. In a lot of cases, these operations are used to insert several pieces of data into a larger structure. In Ada, this can be done by describing the structure layout at the type level through representation clauses, and then accessing this structure as any other. For example, we can interpret an arbitrary data type as a bit-field and perform low-level operations on it.

Because Ada is a strongly typed language, it doesn't define any implicit type conversions like C. If we try to compile Ada code that contains type mismatches, we'll get a compilation error. Because the compiler prevents mixing variables of different types without explicit type conversion, we can't accidentally end up in a situation where we assume something will happen implicitly when, in fact, our assumption is incorrect. In this sense, Ada's type system encourages programmers to think about data at a high level of abstraction. Ada supports overlays and unchecked conversions as a way of converting between unrelated data type, which are typically used for interfacing with low-level elements such as registers.

In Ada, arrays aren't interchangeable with operations on pointers like in C. Also, array types are considered first-class citizens and have dedicated semantics such as the availability of the array's boundaries at run-time. Therefore, unhandled array overflows are impossible unless checks are suppressed. Any discrete type can serve as an array index, and we can specify both the starting and ending bounds. In addition, Ada offers high-level operations for copying, slicing, and assigning values to arrays.

Although Ada supports pointers, most situations that would require a pointer in C do not in Ada. In the vast majority of the cases, indirect memory management can be hidden from the developer and thus prevent many potential errors. In C, pointers are typically used to pass references to subprograms, for example. In contrast, Ada parameter modes indicate the flow of information to the reader, leaving the means of passing that information to the compiler.

When translating pointers from C code to Ada, we need to assess whether they are needed in the first place. Ada pointers (access types) should only be used with complex structures that cannot be allocated at run-time. There are many situations that would require a pointer in C, but do not in Ada. For example, arrays — even when dynamically allocated —, results of functions, passing of large structures as parameters, access to registers, etc. Because of the absence of namespaces, global names in C tend to be very long. Also, because of the absence of overloading, they can even encode type names in their name. In Ada, a package is a namespace. Also, we can use the private part of a package to declare private types and private subprograms. In fact, private types are useful for preventing the users of those types from depending on the implementation details. Another use-case is the prevention of package users from accessing the package state/data arbitrarily.

Ada has a dedicated set of features for interfacing with other languages, so we can easily interface with our existing C code before translating it to Ada. Also, GNAT includes automatic binding generators. Therefore, instead of re-writing the entire C code upfront, which isn't practical or cost-effective, we can selectively translate modules from C to Ada.

When it comes to implementing concurrency and real time, Ada offers several options. Ada provides high level constructs such as tasks and protected objects to express concurrency and synchronization, which can be used when running on top of an operating system such as Linux. On more constrained systems, such as bare metal or some real-time operating systems, a subset of the Ada tasking capabilities — known as the Ravenscar and Jorvik profiles — is available. Though restricted, this subset also has nice properties, in particular the absence of deadlock, the absence of priority inversion, schedulability and very small footprint. On bare metal systems, this also essentially means that Ada comes with its own real-time kernel. The advantage of using the full Ada tasking model or the restricted profiles is to enhance portability.

Ada includes many features typically used for embedded programming:

- Built-in support for handling interrupts, so we can process interrupts by attaching a handler as a protected procedure to it.
- Built-in support for handling both volatile and atomic data.
- Support for register overlays, which we can use to create a structure that facilitates manipulating bits from registers.
- Support for creating data streams for serialization of arbitrary information and transmission over a communication channel, such as a serial port.
- Built-in support for fixed-point arithmetic, which is an option when our target device doesn't have a floating-point unit or the result of calculations needs to be bit-exact.

Also, Ada compilers such as GNAT have built-in support for directly mixing Ada and Assembly code.

Ada also supports contracts, which can be associated with types and variables to refine values and define valid and invalid values. The most common kind of contract is a *range constraint* — using the **range** reserved word. Ada also supports contract-based programming in the form of preconditions and postconditions. One typical benefit of contract-based programming is the removal of defensive code in subprogram implementations.

It is common to see embedded software being used in a variety of configurations that require small changes to the code for each instance. In C, variability is usually achieved through macros and function pointers, the former being tied to static variability and the latter to dynamic variability. Ada offers many alternatives for both techniques, which aim at structuring possible variations of the software. Examples of static variability in Ada are: genericity, simple derivation, configuration pragma files, and configuration packages. Examples of dynamic variability in Ada are: records with discriminants, variant records which may include the use of unions —, object orientation, pointers to subprograms, and design by components using dynamic libraries.

There shouldn't be significant performance differences between code written in Ada and code written in C — provided that they are semantically equivalent. One reason is that the two languages are fairly similar in the way they implement imperative semantics, in particular with regards to memory management or control flow. Therefore, they should be equivalent on average. However, when a piece of code in Ada is significantly slower than its counterpart in C, this usually comes from the fact that, while the two pieces of code appear

to be semantically equivalent, they happen to be actually quite different. Fortunately, there are strategies that we can use to improve the performance and make it equivalent to the C version. These are some examples:

- Clever use of compilation switches, which might optimize the performance of an application significantly.
- Suppression of checks at specific parts of the implementation.
 - Although runtime checks are very useful and should be used as much as possible, they can also increase the overhead of implementations at certain hot-spots.
- Restriction of assertions to development code.
 - For example, we may use assertions in the debug version of the code and turn them off in the release version.
 - Also, we may use formal proof to decide which assertions we turn off in the release version. By formally proving that assertions will never fail at run-time, we can safely deactivate them.

Formal proof — a form of static analysis — can give strong guarantees about checks, for all possible conditions and all possible inputs. It verifies conditions prior to execution, even prior to compilation, so we can remove bugs earlier in the development phase. This is far less expensive than doing so later because the cost to fix bugs increases exponentially over the phases of the project life cycle, especially after deployment. Preventing bug introduction into the deployed system is the least expensive approach of all.

Formal analysis for proof can be achieved through the SPARK subset of the Ada language combined with the **gnatprove** verification tool. SPARK is a subset encompassing most of the Ada language, except for features that preclude proof.

In Ada, several common programming errors that are not already detected at compile-time are detected instead at run-time, triggering *exceptions* that interrupt the normal flow of execution. However, we may be able to prove that the language-defined checks won't raise exceptions at run-time. This is known as proving *Absence of Run-Time Errors*. Successful proof of these checks is highly significant in itself. One of the major resulting benefits is that we can deploy the final executable with checks disabled.

In many situations, the migration of C code to Ada is justified by an increase in terms of integrity expectations, in which case it's expected that development costs will raise. However, Ada is a more expressive, powerful language, designed to reduce errors earlier in the life-cycle, thus reducing costs. Therefore, Ada makes it possible to write very safe and secure software at a lower cost than languages such as C.

CHAPTER ELEVEN

APPENDIX A: HANDS-ON OBJECT-ORIENTED PROGRAMMING

The goal of this appendix is to present a hands-on view on how to translate a system from C to Ada and improve it with object-oriented programming.

11.1 System Overview

Let's start with an overview of a simple system that we'll implement and use below. The main system is called AB and it combines two systems A and B. System AB is not supposed to do anything useful. However, it can serve as a good model for the hands-on we're about to start.

This is a list of requirements for the individual systems A and B, and the combined system AB:

- System A:
 - The system can be activated and deactivated.
 - * During activation, the system's values are reset.
 - Its current value (in floating-point) can be retrieved.
 - * This value is the average of the two internal floating-point values.
 - Its current state (activated or deactivated) can be retrieved.
- System B:
 - The system can be activated and deactivated.
 - * During activation, the system's value is reset.
 - Its current value (in floating-point) can be retrieved.
 - Its current state (activated or deactivated) can be retrieved.
- System AB
 - The system contains an instance of system A and an instance of system B.
 - The system can be activated and deactivated.
 - * System AB activates both systems A and B during its own activation.
 - * System AB deactivates both systems A and B during its own deactivation.
 - Its current value (in floating-point) can be retrieved.
 - * This value is the average of the current values of systems A and B.
 - Its current state (activated or deactivated) can be retrieved.
 - * AB is only considered activated when both systems A and B are activated.

- The system's health can be checked.
 - * This check consists in calculating the absolute difference D between the current values of systems A and B and checking whether D is below a threshold of 0.1.

The source-code in the following section contains an implementation of these requirements.

11.2 Non Object-Oriented Approach

In this section, we look into implementations (in both C and Ada) of system AB that don't make use of object-oriented programming.

11.2.1 Starting point in C

Let's start with an implementation in C for the system described above:

[C]

Listing 1: system_a.h

```
typedef struct {
1
        float val[2];
2
              active;
        int
3
   } A;
4
5
   void A activate (A *a);
6
7
   int A_is_active (A *a);
8
9
   float A_value (A *a);
10
11
   void A deactivate (A *a);
12
```

Listing 2: system_a.c

```
#include "system a.h"
1
2
   void A activate (A *a)
3
    {
4
        int i;
5
6
        for (i = 0; i < 2; i++)
7
8
        {
             a - val[i] = 0.0;
9
10
        }
11
        a->active = 1;
   }
12
13
    int A_is_active (A *a)
14
15
    ł
        return a->active == 1;
16
    }
17
18
    float A_value (A *a)
19
20
    ł
        return (a->val[0] + a->val[1]) / 2.0;
21
    }
22
23
   void A_deactivate (A *a)
24
    {
25
```

26 a->active = 0; 27 }

Listing 3: system_b.h

```
typedef struct {
1
       float val;
2
       int active;
3
   } B;
4
5
  void B_activate (B *b);
6
  int B_is_active (B *b);
8
9
  float B_value (B *b);
10
11
   void B_deactivate (B *b);
12
```

```
Listing 4: system_b.c
```

```
#include "system_b.h"
1
2
   void B_activate (B *b)
3
4
   {
        b->val = 0.0;
5
6
        b->active = 1;
   }
7
8
   int B_is_active (B *b)
9
   {
10
        return b->active == 1;
11
   }
12
13
   float B_value (B *b)
14
15
   {
        return b->val;
16
   }
17
18
   void B_deactivate (B *b)
19
   {
20
        b->active = 0;
21
   }
22
```

Listing 5: system_ab.h

```
#include "system a.h"
1
   #include "system b.h"
2
3
   typedef struct {
4
        Aa;
5
        Bb;
6
   } AB;
7
8
   void AB_activate (AB *ab);
9
10
   int AB_is_active (AB *ab);
11
12
   float AB_value (AB *ab);
13
14
   int AB_check (AB *ab);
15
```

```
void AB_deactivate (AB *ab);
```

16

Listing 6: system_ab.c

```
#include <math.h>
1
   #include "system ab.h"
2
3
   void AB activate (AB *ab)
4
   {
5
        A_activate (&ab->a);
6
        B_activate (&ab->b);
7
   }
8
9
   int AB_is_active (AB *ab)
10
   {
11
        return A_is_active(&ab->a) && B_is_active(&ab->b);
12
   }
13
14
   float AB_value (AB *ab)
15
16
   {
        return (A_value (&ab->a) + B_value (&ab->b)) / 2;
17
   }
18
19
   int AB check (AB *ab)
20
   {
21
        const float threshold = 0.1;
22
23
        return fabs (A_value (&ab->a) - B_value (&ab->b)) < threshold;
24
   }
25
26
   void AB_deactivate (AB *ab)
27
28
   {
        A_deactivate (&ab->a);
29
        B_deactivate (&ab->b);
30
   }
31
```

```
Listing 7: main.c
```

```
#include <stdio.h>
1
   #include "system_ab.h"
2
3
   void display_active (AB *ab)
4
5
   {
        if (AB_is_active (ab))
6
            printf ("System AB is active.\n");
7
        else
8
            printf ("System AB is not active.\n");
9
   }
10
11
   void display_check (AB *ab)
12
   {
13
        if (AB check (ab))
14
            printf ("System AB check: PASSED.\n");
15
        else
16
17
            printf ("System AB check: FAILED.\n");
18
   }
19
   int main()
20
21
   {
```

```
AB s;
22
23
        printf ("Activating system AB...\n");
24
        AB_activate (&s);
25
26
        display_active (&s);
27
        display_check (&s);
28
29
        printf ("Deactivating system AB...\n");
30
        AB_deactivate (&s);
31
32
        display_active (&s);
33
   }
34
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.HandsOnOOP.System_AB_C MD5: 649bcfe39504c853a0c3f43e1e048f34

Runtime output

Activating system AB... System AB is active. System AB check: PASSED. Deactivating system AB... System AB is not active.

Here, each system is implemented in a separate set of header and source-code files. For example, the API of system AB is in system_ab.h and its implementation in system_ab.c.

In the main application, we instantiate system AB and activate it. Then, we proceed to display the activation state and the result of the system's health check. Finally, we deactivate the system and display the activation state again.

11.2.2 Initial translation to Ada

The direct implementation in Ada is:

[Ada]

Listing 8: system_a.ads

```
package System A is
1
2
      type Val_Array is array (Positive range <>) of Float;
3
4
      type A is record
5
                : Val Array (1 .. 2);
         Val
6
          Active : Boolean;
7
      end record;
8
9
      procedure A_Activate (E : in out A);
10
11
      function A_Is_Active (E : A) return Boolean;
12
13
      function A_Value (E : A) return Float;
14
15
      procedure A_Deactivate (E : in out A);
16
17
   end System A;
18
```

```
Listing 9: system_a.adb
```

```
package body System_A is
1
2
      procedure A_Activate (E : in out A) is
3
      begin
4
          E.Val
                   := (others => 0.0);
5
          E.Active := True;
6
      end A_Activate;
7
8
      function A_Is_Active (E : A) return Boolean is
9
      begin
10
          return E.Active;
11
      end A_Is_Active;
12
13
      function A_Value (E : A) return Float is
14
      begin
15
          return (E.Val (1) + E.Val (2)) / 2.0;
16
      end A_Value;
17
18
       procedure A_Deactivate (E : in out A) is
19
      begin
20
          E.Active := False;
21
      end A_Deactivate;
22
23
   end System_A;
24
```

Listing 10: system_b.ads

```
package System_B is
1
2
      type B is record
3
          Val
                 : Float;
4
          Active : Boolean;
5
      end record;
6
7
      procedure B_Activate (E : in out B);
8
9
      function B_Is_Active (E : B) return Boolean;
10
11
      function B_Value (E : B) return Float;
12
13
      procedure B Deactivate (E : in out B);
14
15
   end System B;
16
```

Listing 11: system_b.adb

```
package body System_B is
1
2
      procedure B_Activate (E : in out B) is
3
      begin
4
         E.Val
                   := 0.0;
5
         E.Active := True;
6
      end B_Activate;
7
8
      function B_Is_Active (E : B) return Boolean is
9
      begin
10
         return E.Active;
11
      end B Is Active;
12
13
```

```
function B_Value (E : B) return Float is
14
       begin
15
          return E.Val;
16
       end B_Value;
17
18
       procedure B_Deactivate (E : in out B) is
19
       beain
20
          E.Active := False;
21
       end B_Deactivate;
22
23
   end System_B;
24
```

Listing 12: system_ab.ads

```
with System A; use System A;
1
   with System_B; use System_B;
2
3
   package System AB is
4
5
      type AB is record
6
          SA : A;
7
          SB : B;
8
      end record;
9
10
      procedure AB_Activate (E : in out AB);
11
12
      function AB_Is_Active (E : AB) return Boolean;
13
14
      function AB_Value (E : AB) return Float;
15
16
      function AB_Check (E : AB) return Boolean;
17
18
      procedure AB_Deactivate (E : in out AB);
19
20
   end System_AB;
21
```

Listing 13: system ab.adb

```
package body System_AB is
1
2
      procedure AB_Activate (E : in out AB) is
3
      begin
4
5
         A_Activate (E.SA);
6
          B_Activate (E.SB);
      end AB_Activate;
7
8
      function AB_Is_Active (E : AB) return Boolean is
9
      begin
10
          return A_Is_Active (E.SA) and B_Is_Active (E.SB);
11
      end AB_Is_Active;
12
13
      function AB_Value (E : AB) return Float is
14
      begin
15
          return (A_Value (E.SA) + B_Value (E.SB)) / 2.0;
16
17
      end AB_Value;
18
      function AB_Check (E : AB) return Boolean is
19
          Threshold : constant := 0.1;
20
      begin
21
          return abs (A_Value (E.SA) - B_Value (E.SB)) < Threshold;</pre>
22
```

```
end AB_Check;
23
24
       procedure AB_Deactivate (E : in out AB) is
25
       begin
26
          A_Deactivate (E.SA);
27
          B_Deactivate (E.SB);
28
       end AB_Deactivate;
29
30
   end System_AB;
31
```

```
Listing 14: main.adb
```

```
with Ada.Text_I0; use Ada.Text_I0;
1
2
   with System AB;
                       use System AB;
3
4
   procedure Main is
5
6
      procedure Display_Active (E : AB) is
7
8
      begin
          if AB_Is_Active (E) then
9
             Put_Line ("System AB is active");
10
          else
11
             Put_Line ("System AB is not active");
12
          end if;
13
      end Display_Active;
14
15
      procedure Display_Check (E : AB) is
16
17
      begin
          if AB_Check (E) then
18
             Put_Line ("System AB check: PASSED");
19
20
          else
             Put_Line ("System AB check: FAILED");
21
          end if:
22
      end Display_Check;
23
24
      S : AB;
25
   begin
26
      Put Line ("Activating system AB...");
27
      AB_Activate (S);
28
29
      Display_Active (S);
30
      Display_Check (S);
31
32
      Put_Line ("Deactivating system AB...");
33
      AB Deactivate (S);
34
35
      Display_Active (S);
36
   end Main;
37
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.HandsOnOOP.System_AB_Ada
MD5: f2e3df0b3874e5edc5ea90c01961cf64

Runtime output

Activating system AB... System AB is active System AB check: PASSED Deactivating system AB...

System AB is not active

As you can see, this is a direct translation that doesn't change much of the structure of the original C code. Here, the goal was to simply translate the system from one language to another and make sure that the behavior remains the same.

11.2.3 Improved Ada implementation

By analyzing this direct implementation, we may notice the following points:

- Packages System_A, System_B and System_AB are used to describe aspects of the same system. Instead of having three distinct packages, we could group them as child packages of a common parent package — let's call it Simple, since this system is supposed to be simple. This approach has the advantage of allowing us to later use the parent package to implement functionality that is common for all parts of the system.
- Since we have subprograms that operate on types A, B and AB, we should avoid exposing the record components by moving the type declarations to the private part of the corresponding packages.
- Since Ada supports subprogram overloading as discussed in this section from chapter 2 (page 62) —, we don't need to have different names for subprograms with similar functionality. For example, instead of having A_Is_Active and B_Is_Active, we can simply name these functions Is_Active for both types A and B.
- Some of the functions such as A_Is_Active and A_Value are very simple, so we could simplify them with expression functions.

This is an update to the implementation that addresses all the points above:

[Ada]

Listing 15: simple.ads

```
package Simple
with Pure
is
end Simple;
```

Listing 16: simple-system_a.ads

```
package Simple.System A is
1
2
      type A is private;
3
4
      procedure Activate (E : in out A);
5
6
      function Is Active (E : A) return Boolean;
7
8
      function Value (E : A) return Float;
9
10
      procedure Finalize (E : in out A);
11
12
   private
13
14
      type Val Array is array (Positive range <>) of Float;
15
16
       type A is record
17
          Val : Val Array (1 .. 2);
18
         Active : Boolean:
19
```

20 end record; 21 22 end Simple.System_A;

Listing 17: simple-system_a.adb

```
package body Simple.System A is
1
2
      procedure Activate (E : in out A) is
3
      begin
4
         E.Val
                   := (others => 0.0);
5
         E.Active := True;
6
      end Activate:
7
8
      function Is Active (E : A) return Boolean is
9
          (E.Active);
10
11
      function Value (E : A) return Float is
12
      begin
13
          return (E.Val (1) + E.Val (2)) / 2.0;
14
      end Value;
15
16
      procedure Finalize (E : in out A) is
17
      begin
18
         E.Active := False;
19
      end Finalize;
20
21
   end Simple.System A;
22
```

Listing 18: simple-system_b.ads

```
package Simple.System_B is
1
2
      type B is private;
3
4
      procedure Activate (E : in out B);
5
6
      function Is_Active (E : B) return Boolean;
7
8
      function Value (E : B) return Float;
9
10
      procedure Finalize (E : in out B);
11
12
13
   private
14
       type B is record
15
                : Float;
          Val
16
          Active : Boolean;
17
      end record;
18
19
   end Simple.System_B;
20
```

Listing 19: simple-system_b.adb

```
1 package body Simple.System_B is
2
3 procedure Activate (E : in out B) is
4 begin
5 E.Val := 0.0;
6 E.Active := True;
```

```
end Activate;
7
8
      function Is_Active (E : B) return Boolean is
9
10
      begin
          return E.Active;
11
      end Is_Active;
12
13
       function Value (E : B) return Float is
14
         (E.Val);
15
16
      procedure Finalize (E : in out B) is
17
      begin
18
          E.Active := False;
19
       end Finalize;
20
21
   end Simple.System_B;
22
```

Listing 20: simple-system_ab.ads

```
with Simple.System_A; use Simple.System_A;
1
   with Simple.System_B; use Simple.System_B;
2
3
   package Simple.System_AB is
4
5
      type AB is private;
6
7
      procedure Activate (E : in out AB);
8
9
      function Is_Active (E : AB) return Boolean;
10
11
      function Value (E : AB) return Float;
12
13
      function Check (E : AB) return Boolean;
14
15
      procedure Finalize (E : in out AB);
16
17
   private
18
19
       type AB is record
20
          SA : A;
21
          SB : B;
22
      end record;
23
24
   end Simple.System_AB;
25
```

Listing 2	21: :	simp	le-sy	/stem	ab.adb

```
package body Simple.System_AB is
1
2
      procedure Activate (E : in out AB) is
3
      begin
4
         Activate (E.SA);
5
         Activate (E.SB);
6
      end Activate;
7
8
9
      function Is_Active (E : AB) return Boolean is
          (Is_Active (E.SA) and Is_Active (E.SB));
10
11
      function Value (E : AB) return Float is
12
          ((Value (E.SA) + Value (E.SB)) / 2.0);
13
```

14

(continued from previous page)

```
function Check (E : AB) return Boolean is
15
          Threshold : constant := 0.1;
16
       begin
17
          return abs (Value (E.SA) - Value (E.SB)) < Threshold;
18
       end Check;
19
20
       procedure Finalize (E : in out AB) is
21
       begin
22
          Finalize (E.SA);
23
          Finalize (E.SB);
24
       end Finalize;
25
26
   end Simple.System_AB;
27
```

Listing 22: main.adb

```
with Ada.Text IO;
                            use Ada.Text I0;
1
2
   with Simple.System_AB; use Simple.System_AB;
3
4
   procedure Main is
5
6
      procedure Display_Active (E : AB) is
7
      begin
8
          if Is Active (E) then
9
             Put_Line ("System AB is active");
10
          else
11
             Put_Line ("System AB is not active");
12
          end if;
13
14
      end Display_Active;
15
      procedure Display_Check (E : AB) is
16
      begin
17
          if Check (E) then
18
             Put_Line ("System AB check: PASSED");
19
          else
20
             Put Line ("System AB check: FAILED");
21
          end if;
22
      end Display_Check;
23
24
      S : AB;
25
26
   begin
      Put_Line ("Activating system AB...");
27
      Activate (S);
28
29
      Display_Active (S);
30
      Display_Check (S);
31
32
      Put_Line ("Deactivating system AB...");
33
      Finalize (S);
34
35
      Display_Active (S);
36
   end Main;
37
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.HandsOnOOP.System_AB_Ada_Enhanced
MD5: 5019a7088ab4160f5e3b33c73db2b03b
```

Runtime output

Activating system AB... System AB is active System AB check: PASSED Deactivating system AB... System AB is not active

11.3 First Object-Oriented Approach

Until now, we haven't used any of the object-oriented programming features of the Ada language. So we can start by analyzing the API of systems A and B and deciding how to best abstract some of its elements using object-oriented programming.

11.3.1 Interfaces

The first thing we may notice is that we actually have two distinct sets of APIs there:

- one API for activating and deactivating the system.
- one API for retrieving the value of the system.

We can use this distinction to declare two interface types:

- Activation_IF for the Activate and Deactivate procedures and the Is_Active function;
- Value_Retrieval_IF for the Value function.

This is how the declaration could look like:

type Activation IF is interface;

```
procedure Activate (E : in out Activation_IF) is abstract;
function Is_Active (E : Activation_IF) return Boolean is abstract;
procedure Deactivate (E : in out Activation IF) is abstract;
```

```
type Value_Retrieval_IF is interface;
```

function Value (E : Value_Retrieval_IF) return Float is abstract;

Note that, because we are declaring interface types, all operations on those types must be abstract or, in the case of procedures, they can also be declared **null**. For example, we could change the declaration of the procedures above to this:

```
procedure Activate (E : in out Activation_IF) is null;
procedure Deactivate (E : in out Activation_IF) is null;
```

When an operation is declared abstract, we must override it for the type that derives from the interface. When a procedure is declared **null**, it acts as a do-nothing default. In this case, overriding the operation is optional for the type that derives from this interface.

11.3.2 Base type

Since the original system needs both interfaces we've just described, we have to declare another type that combines those interfaces. We can do this by declaring the interface type Sys_Base, which serves as the base type for systems A and B. This is the declaration:

type Sys_Base is interface and Activation_IF and Value_Retrieval_IF;

Since the system activation functionality is common for both systems A and B, we could implement it as part of Sys_Base. That would require changing the declaration from a simple interface to an abstract record:

```
type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF
  with null record;
```

Now, we can add the Boolean component to the record (as a private component) and override the subprograms of the Activation IF interface. This is the adapted declaration:

```
type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF with private;
overriding procedure Activate (E : in out Sys_Base);
overriding function Is_Active (E : Sys_Base) return Boolean;
overriding procedure Deactivate (E : in out Sys_Base);
```

private

```
type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF with record
Active : Boolean;
end record;
```

11.3.3 Derived types

In the declaration of the Sys_Base type we've just seen, we're not overriding the Value function — from the Value_Retrieval_IF interface — for the Sys_Base type, so it remains an abstract function for Sys_Base. Therefore, the Sys_Base type itself remains abstract and needs be explicitly declared as such.

We use this strategy to ensure that all types derived from Sys_Base need to implement their own version of the Value function. For example:

```
type A is new Sys_Base with private;
```

```
overriding function Value (E : A) return Float;
```

Here, the A type is derived from the Sys_Base and it includes its own version of the Value function by overriding it. Therefore, A is not an abstract type anymore and can be used to declare objects:

```
procedure Main is
    Obj : A;
    V : Float;
begin
    Obj.Activate;
    V := Obj.Value;
end Main:
```

Important

Note that the use of the **overriding** keyword in the subprogram declaration is not strictly necessary. In fact, we could leave this keyword out, and the code would still compile. However, if provided, the compiler will check whether the information is correct.

Using the **overriding** keyword can help to avoid bad surprises — when you *may think* that you're overriding a subprogram, but you're actually not. Similarly, you can also write **not overriding** to be explicit about subprograms that are new primitives of a derived type. For example:

not overriding function Check (E : AB) return Boolean;

We also need to declare the values that are used internally in systems A and B. For system A, this is the declaration:

```
type A is new Sys_Base with private;
overriding function Value (E : A) return Float;
private
type Val_Array is array (Positive range <>) of Float;
type A is new Sys_Base with record
Val : Val_Array (1 .. 2);
end record;
```

11.3.4 Subprograms from parent

In the previous implementation, we've seen that the A_Activate and B_Activate procedures perform the following steps:

- initialize internal values;
- indicate that the system is active (by setting the Active flag to True).

In the implementation of the Activate procedure for the Sys_Base type, however, we're only dealing with the second step. Therefore, we need to override the Activate procedure and make sure that we initialize internal values as well. First, we need to declare this procedure for type A:

```
type A is new Sys_Base with private;
```

overriding procedure Activate (E : in out A);

In the implementation of Activate, we should call the Activate procedure from the parent (Sys_Base) to ensure that whatever was performed for the parent will be performed in the derived type as well. For example:

Here, by writing Sys_Base (E), we're performing a view conversion. Basically, we're telling the compiler to view E not as an object of type A, but of type Sys_Base. When we do this, any operation performed on this object will be done as if it was an object of Sys_Base type, which includes calling the Activate procedure of the Sys_Base type.

Important

If we write T (Obj).Proc, we're telling the compiler to call the Proc procedure of type T and apply it on Obj.

If we write T'Class (Obj).Proc, however, we're telling the compiler to dispatch the call. For example, if Obj is of derived type T2 and there's an overridden Proc procedure for type T2, then this procedure will be called instead of the Proc procedure for type T.

11.3.5 Type AB

While the implementation of systems A and B is almost straightforward, it gets more interesting in the case of system AB. Here, we have a similar API, but we don't need the activation mechanism implemented in the abstract type Sys_Base. Therefore, deriving from Sys_Base is not the best option. Instead, when declaring the AB type, we can simply use the same interfaces as we did for Sys_Base, but keep it independent from Sys_Base. For example:

```
type AB is new Activation_IF and Value_Retrieval_IF with private;
```

private

```
type AB is new Activation_IF and Value_Retrieval_IF with record
SA : A;
SB : B;
end record;
```

Naturally, we still need to override all the subprograms that are part of the Activation_IF and Value_Retrieval_IF interfaces. Also, we need to implement the additional Check function that was originally only available on system AB. Therefore, we declare these sub-programs:

```
overriding procedure Activate (E : in out AB);
overriding function Is_Active (E : AB) return Boolean;
overriding procedure Deactivate (E : in out AB);
overriding function Value (E : AB) return Float;
not overriding function Check (E : AB) return Boolean;
```

11.3.6 Updated source-code

Finally, this is the complete source-code example:

[Ada]

Listing	23:	simp	le.ads
Listing	20.	Shinp	

```
package Simple is
1
2
      type Activation_IF is interface;
3
4
      procedure Activate (E : in out Activation_IF) is abstract;
5
      function Is_Active (E : Activation_IF) return Boolean is abstract;
6
      procedure Deactivate (E : in out Activation_IF) is abstract;
7
8
      type Value_Retrieval_IF is interface;
9
10
      function Value (E : Value Retrieval IF) return Float is abstract;
11
12
      type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF
13
        with private;
14
15
      overriding procedure Activate (E : in out Sys Base);
16
      overriding function Is Active (E : Sys Base) return Boolean;
17
      overriding procedure Deactivate (E : in out Sys Base);
18
19
   private
20
21
      type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF
22
```

```
(continues on next page)
```

```
23 with record
24 Active : Boolean;
25 end record;
26
27 end Simple;
```

Listing 24: simple.adb

```
package body Simple is
1
2
      overriding procedure Activate (E : in out Sys_Base) is
3
      begin
4
         E.Active := True:
5
      end Activate:
6
7
      overriding function Is_Active (E : Sys_Base) return Boolean is
8
          (E.Active);
9
10
      overriding procedure Deactivate (E : in out Sys_Base) is
11
      begin
12
         E.Active := False;
13
      end Deactivate;
14
15
   end Simple;
16
```

Listing 25: simple-system_a.ads

```
package Simple.System_A is
1
2
      type A is new Sys_Base with private;
3
4
      overriding procedure Activate (E : in out A);
5
6
      overriding function Value (E : A) return Float;
7
8
   private
9
10
      type Val_Array is array (Positive range <>) of Float;
11
12
      type A is new Sys_Base with record
13
         Val : Val_Array (1 .. 2);
14
      end record;
15
16
   end Simple.System_A;
17
```

```
Listing 26: simple-system_a.adb
```

```
package body Simple.System A is
1
2
      procedure Activate (E : in out A) is
3
      begin
4
         E.Val := (others => 0.0);
5
         Sys_Base (E).Activate;
6
      end Activate;
7
8
      function Value (E : A) return Float is
9
         pragma Assert (E.Val'Length = 2);
10
      begin
11
         return (E.Val (1) + E.Val (2)) / 2.0;
12
      end Value;
13
```

```
15 end Simple.System_A;
```

14

Listing 27: simple-system b.ads

```
package Simple.System B is
1
2
      type B is new Sys_Base with private;
3
4
      overriding procedure Activate (E : in out B);
5
6
      overriding function Value (E : B) return Float;
7
8
   private
9
10
      type B is new Sys_Base with record
11
         Val : Float;
12
      end record;
13
14
   end Simple.System B;
15
```

Listing 28: simple-system_b.adb

```
package body Simple.System_B is
1
2
      procedure Activate (E : in out B) is
3
      begin
4
          E.Val := 0.0;
5
          Sys_Base (E).Activate;
6
      end Activate;
7
8
      function Value (E : B) return Float is
9
         (E.Val);
10
11
   end Simple.System_B;
12
```

Listing 29: simple-system_ab.ads

```
with Simple.System A; use Simple.System A;
1
   with Simple.System_B; use Simple.System_B;
2
3
   package Simple.System AB is
4
5
      type AB is new Activation_IF and Value_Retrieval_IF with private;
6
7
      overriding procedure Activate (E : in out AB);
8
      overriding function Is Active (E : AB) return Boolean;
9
      overriding procedure Deactivate (E : in out AB);
10
11
      overriding function Value (E : AB) return Float;
12
13
      not overriding function Check (E : AB) return Boolean;
14
15
   private
16
17
      type AB is new Activation_IF and Value_Retrieval_IF with record
18
         SA : A;
19
         SB : B:
20
      end record;
21
22
```

23 end Simple.System_AB;

```
Listing 30: simple-system_ab.adb
```

```
package body Simple.System AB is
1
2
      procedure Activate (E : in out AB) is
3
      begin
4
          E.SA.Activate;
5
          E.SB.Activate;
6
      end Activate;
7
8
      function Is_Active (E : AB) return Boolean is
9
         (E.SA.Is_Active and E.SB.Is_Active);
10
11
      procedure Deactivate (E : in out AB) is
12
      begin
13
          E.SA.Deactivate;
14
          E.SB.Deactivate;
15
      end Deactivate;
16
17
       function Value (E : AB) return Float is
18
         ((E.SA.Value + E.SB.Value) / 2.0);
19
20
       function Check (E : AB) return Boolean is
21
          Threshold : constant := 0.1;
22
       begin
23
          return abs (E.SA.Value - E.SB.Value) < Threshold;</pre>
24
       end Check;
25
26
   end Simple.System_AB;
27
```

```
Listing 31: main.adb
```

```
1
   with Ada.Text_I0;
                            use Ada.Text_I0;
2
   with Simple.System_AB; use Simple.System_AB;
3
4
   procedure Main is
5
6
      procedure Display_Active (E : AB) is
7
8
      begin
9
          if Is_Active (E) then
10
             Put_Line ("System AB is active");
          else
11
             Put_Line ("System AB is not active");
12
          end if;
13
      end Display_Active;
14
15
      procedure Display_Check (E : AB) is
16
       begin
17
          if Check (E) then
18
             Put_Line ("System AB check: PASSED");
19
          else
20
21
             Put_Line ("System AB check: FAILED");
22
          end if;
      end Display_Check;
23
24
      S : AB;
25
   begin
26
```

```
Put_Line ("Activating system AB...");
27
      Activate (S);
28
29
      Display_Active (S);
30
      Display_Check (S);
31
32
      Put_Line ("Deactivating system AB...");
33
      Deactivate (S);
34
35
      Display_Active (S);
36
   end Main;
37
```

Code block metadata

```
Project: Courses.Ada_For_Embedded_C_Dev.HandsOnOOP.System_AB_Ada_00P_1
MD5: 02adee1f81b025007244bd6d13e8b5a3
```

Runtime output

```
Activating system AB...
System AB is active
System AB check: PASSED
Deactivating system AB...
System AB is not active
```

11.4 Further Improvements

When analyzing the complete source-code, we see that there are at least two areas that we could still improve.

11.4.1 Dispatching calls

The first issue concerns the implementation of the Activate procedure for types derived from Sys_Base. For those derived types, we're expecting that the Activate procedure of the parent must be called in the implementation of the overriding Activate procedure. For example:

```
package body Simple.System_A is
    procedure Activate (E : in out A) is
    begin
        E.Val := (others => 0.0);
        Activate (Sys_Base (E));
    end;
```

If a developer forgets to call that specific Activate procedure, however, the system won't work as expected. A better strategy could be the following:

- Declare a new Activation_Reset procedure for Sys_Base type.
- Make a dispatching call to the Activation_Reset procedure in the body of the Activate procedure (of the Sys_Base type).
- Let the derived types implement their own version of the Activation_Reset procedure.

This is a simplified view of the implementation using the points described above:

```
package Simple is
   type Sys Base is abstract new Activation IF and Value Retrieval IF with
     private;
  not overriding procedure Activation Reset (E : in out Sys Base) is abstract;
end Simple;
package body Simple is
  procedure Activate (E : in out Sys Base) is
  begin
      -- NOTE: calling "E.Activation Reset" does NOT dispatch!
                We need to use the 'Class attribute here --- not using this
      - -
                attribute is an error that will be caught by the compiler.
      - -
      Sys_Base'Class (E).Activation_Reset;
     E.Active := True:
   end Activate:
end Simple;
package Simple.System A is
  type A is new Sys Base with private;
private
  type Val Array is array (Positive range <>) of Float;
   type A is new Sys Base with record
     Val : Val Array (1 .. 2);
  end record;
  overriding procedure Activation Reset (E : in out A);
end Simple.System A;
package body Simple.System A is
  procedure Activation Reset (E : in out A) is
  begin
               := (others => 0.0);
      E.Val
  end Activation Reset;
end Simple.System A;
```

An important detail is that, in the implementation of Activate, we use Sys_Base'Class to ensure that the call to Activation_Reset will dispatch. If we had just written E. Activation_Reset instead, then we would be calling the Activation_Reset procedure of Sys_Base itself, which is not what we actually want here. The compiler will catch the error if you don't do the conversion to the class-wide type, because it would otherwise be a statically-bound call to an abstract procedure, which is illegal at compile-time.

11.4.2 Dynamic allocation

The next area that we could improve is in the declaration of the system AB. In the previous implementation, we were explicitly describing the two components of that system, namely a component of type A and a component of type B:

```
type AB is new Activation_IF and Value_Retrieval_IF with record
SA : A;
SB : B;
end record;
```

Of course, this declaration matches the system requirements that we presented in the beginning. However, we could use strategies that make it easier to incorporate requirement changes later on. For example, we could hide this information about systems A and B by simply declaring an array of components of type **access** Sys_Base'Class and allocate them dynamically in the body of the package. Naturally, this approach might not be suitable for certain platforms. However, the advantage would be that, if we wanted to replace the component of type B by a new component of type C, for example, we wouldn't need to change the interface. This is how the updated declaration could look like:

```
type Sys_Base_Class_Access is access Sys_Base'Class;
type Sys_Base_Array is array (Positive range <>) of Sys_Base_Class_Access;
```

```
type AB is limited new Activation_IF and Value_Retrieval_IF with record
S_Array : Sys_Base_Array (1 .. 2);
end record;
```

1 Important

Note that we're now using the **limited** keyword in the declaration of type AB. That is necessary because we want to prevent objects of type AB being copied by assignment, which would lead to two objects having the same (dynamically allocated) subsystems A and B internally. This change requires that both Activation_IF and Value_Retrieval_IF are declared limited as well.

The body of Activate could then allocate those components:

```
procedure Activate (E : in out AB) is
begin
    E.S_Array := (new A, new B);
    for S of E.S_Array loop
        S.Activate;
    end loop;
end Activate;
```

And the body of Deactivate could deallocate them:

```
procedure Deactivate (E : in out AB) is
    procedure Free is
        new Ada.Unchecked_Deallocation (Sys_Base'Class, Sys_Base_Class_Access);
begin
    for S of E.S_Array loop
        S.Deactivate;
        Free (S);
    end loop;
end Deactivate;
```

11.4.3 Limited controlled types

Another approach that we could use to implement the dynamic allocation of systems A and B is to declare AB as a limited controlled type — based on the Limited_Controlled type of the Ada.Finalization package.

The Limited Controlled type includes the following operations:

- Initialize, which is called when objects of a type derived from the Limited_Controlled type are being created — by declaring an object of the derived type, for example —, and
- Finalize, which is called when objects are being destroyed for example, when an object gets out of scope at the end of a subprogram where it was created.

In this case, we must override those procedures, so we can use them for dynamic memory allocation. This is a simplified view of the update implementation:

```
package Simple.System AB is
   type AB is limited new Ada. Finalization. Limited Controlled and
     Activation IF and Value Retrieval IF with private;
  overriding procedure Initialize (E : in out AB);
  overriding procedure Finalize (E : in out AB);
end Simple.System AB;
package body Simple.System AB is
   overriding procedure Initialize (E : in out AB) is
  begin
      E.S Array := (new A, new B);
   end Initialize;
  overriding procedure Finalize (E : in out AB) is
      procedure Free is
        new Ada.Unchecked Deallocation (Sys Base'Class, Sys Base Class Access);
  beain
      for S of E.S Array loop
         Free (S);
      end loop:
  end Finalize;
end Simple.System AB;
```

11.4.4 Updated source-code

Finally, this is the complete updated source-code example: [Ada]

Listing 32: simple.ads

```
package Simple is
1
2
      type Activation_IF is limited interface;
3
4
      procedure Activate (E : in out Activation_IF) is abstract;
5
      function Is_Active (E : Activation_IF) return Boolean is abstract;
6
      procedure Deactivate (E : in out Activation_IF) is abstract;
7
8
      type Value_Retrieval_IF is limited interface;
9
10
      function Value (E : Value_Retrieval_IF) return Float is abstract;
11
12
      type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF with
13
        private;
14
15
      overriding procedure Activate (E : in out Sys_Base);
16
```

```
(continued from previous page)
      overriding function Is_Active (E : Sys_Base) return Boolean;
17
      overriding procedure Deactivate (E : in out Sys_Base);
18
19
      not overriding procedure Activation_Reset (E : in out Sys_Base) is abstract;
20
21
   private
22
23
      type Sys_Base is abstract new Activation_IF and Value_Retrieval_IF with
24
          record
25
             Active : Boolean;
26
          end record;
27
28
29
   end Simple;
```

Listing 33: simple.adb

```
package body Simple is
1
2
      procedure Activate (E : in out Sys_Base) is
3
      begin
4
         -- NOTE: calling "E.Activation_Reset" does NOT dispatch!
5
                    We need to use the 'Class attribute:
          - -
6
         Sys_Base'Class (E).Activation_Reset;
7
8
         E.Active := True;
9
      end Activate;
10
11
      function Is Active (E : Sys Base) return Boolean is
12
13
          (E.Active);
14
      procedure Deactivate (E : in out Sys_Base) is
15
      begin
16
          E.Active := False;
17
      end Deactivate:
18
19
   end Simple;
20
```

Listing 34: simple-system_a.ads

```
package Simple.System_A is
1
2
      type A is new Sys_Base with private;
3
4
      overriding function Value (E : A) return Float;
5
6
   private
7
8
      type Val_Array is array (Positive range <>) of Float;
9
10
      type A is new Sys_Base with record
11
         Val : Val_Array (1 .. 2);
12
      end record;
13
14
      overriding procedure Activation_Reset (E : in out A);
15
16
17
   end Simple.System_A;
```

```
Listing 35: simple-system_a.adb
```

```
package body Simple.System_A is
1
2
      procedure Activation_Reset (E : in out A) is
3
      begin
4
          E.Val := (others => 0.0);
5
      end Activation Reset;
6
7
      function Value (E : A) return Float is
8
          pragma Assert (E.Val'Length = 2);
9
      begin
10
          return (E.Val (1) + E.Val (2)) / 2.0;
11
      end Value;
12
13
   end Simple.System_A;
14
```

Listing 36: simple-system_b.ads

```
package Simple.System_B is
1
2
      type B is new Sys_Base with private;
3
4
      overriding function Value (E : B) return Float;
5
6
   private
7
8
      type B is new Sys_Base with record
9
         Val : Float;
10
      end record;
11
12
      overriding procedure Activation_Reset (E : in out B);
13
14
   end Simple.System_B;
15
```

Listing 37: simple-system_b.adb

```
package body Simple.System_B is
1
2
      procedure Activation_Reset (E : in out B) is
3
      begin
4
          E.Val := 0.0;
5
      end Activation_Reset;
6
7
      function Value (E : B) return Float is
8
         (E.Val);
9
10
   end Simple.System B;
11
```

Listing 38: simple-system_ab.ads

```
with Ada.Finalization;
package Simple.System_AB is
type AB is limited new Ada.Finalization.Limited_Controlled and
Activation_IF and Value_Retrieval_IF with private;
overriding procedure Activate (E : in out AB);
overriding function Is_Active (E : AB) return Boolean;
```

```
(continued from previous page)
      overriding procedure Deactivate (E : in out AB);
10
11
      overriding function Value (E : AB) return Float;
12
13
      not overriding function Check (E : AB) return Boolean;
14
15
   private
16
17
      type Sys_Base_Class_Access is access Sys_Base'Class;
18
       type Sys_Base_Array is array (Positive range <>) of Sys_Base_Class_Access;
19
20
       type AB is limited new Ada.Finalization.Limited_Controlled and
21
         Activation_IF and Value_Retrieval_IF with record
22
23
         S_Array : Sys_Base_Array (1 .. 2);
24
       end record;
25
      overriding procedure Initialize (E : in out AB);
26
      overriding procedure Finalize
                                       (E : in out AB);
27
28
   end Simple.System_AB;
29
```

Listing 39: simple-system_ab.adb

```
with Ada.Unchecked_Deallocation;
1
2
   with Simple.System A; use Simple.System A;
3
   with Simple.System_B; use Simple.System_B;
4
5
   package body Simple.System_AB is
6
7
       overriding procedure Initialize (E : in out AB) is
8
      begin
9
          E.S_Array := (new A, new B);
10
      end Initialize;
11
12
      overriding procedure Finalize
                                        (E : in out AB) is
13
          procedure Free is
14
            new Ada.Unchecked Deallocation (Sys Base'Class, Sys Base Class Access);
15
      begin
16
          for S of E.S_Array loop
17
             Free (S);
18
          end loop;
19
      end Finalize;
20
21
      procedure Activate (E : in out AB) is
22
       begin
23
          for S of E.S Array loop
24
             S.Activate;
25
          end loop;
26
      end Activate;
27
28
       function Is_Active (E : AB) return Boolean is
29
         (for all S of E.S_Array => S.Is_Active);
30
31
      procedure Deactivate (E : in out AB) is
32
      begin
33
          for S of E.S Array loop
34
             S.Deactivate;
35
          end loop;
36
      end Deactivate;
37
38
```

```
function Value (E : AB) return Float is
39
         ((E.S_Array (1).Value + E.S_Array (2).Value) / 2.0);
40
41
       function Check (E : AB) return Boolean is
42
          Threshold : constant := 0.1;
43
      beain
44
          return abs (E.S_Array (1).Value - E.S_Array (2).Value) < Threshold;</pre>
45
      end Check;
46
47
   end Simple.System_AB;
48
```

Listing 40: main.adb

```
with Ada.Text_I0;
                             use Ada.Text_I0;
1
2
   with Simple.System AB; use Simple.System AB;
3
4
   procedure Main is
5
6
       procedure Display_Active (E : AB) is
7
       begin
8
          if Is_Active (E) then
9
             Put_Line ("System AB is active");
10
          else
11
             Put Line ("System AB is not active");
12
          end if;
13
       end Display_Active;
14
15
       procedure Display_Check (E : AB) is
16
       begin
17
          if Check (E) then
18
             Put_Line ("System AB check: PASSED");
19
          else
20
             Put_Line ("System AB check: FAILED");
21
          end if:
22
       end Display_Check;
23
24
       S : AB;
25
   begin
26
       Put_Line ("Activating system AB...");
27
       Activate (S);
28
29
       Display_Active (S);
30
       Display_Check (S);
31
32
       Put Line ("Deactivating system AB...");
33
       Deactivate (S);
34
35
       Display Active (S);
36
   end Main;
37
```

Code block metadata

Project: Courses.Ada_For_Embedded_C_Dev.HandsOnOOP.System_AB_Ada_00P_2
MD5: f8d0d4a07aaa045cb30bddc88db2215a

Runtime output

```
Activating system AB...
System AB is active
System AB check: PASSED
```

Deactivating system AB... System AB is not active

Naturally, this is by no means the best possible implementation of system AB. By applying other software design strategies that we haven't covered here, we could most probably think of different ways to use object-oriented programming to improve this implementation. Also, in comparison to the *original implementation* (page 229), we recognize that the amount of source-code has grown. On the other hand, we now have a system that is factored nicely, and also more extensible.

BIBLIOGRAPHY

[Jorvik] A New Ravenscar-Based Profile by P. Rogers, J. Ruiz, T. Gingold and P. Bernardi, in Reliable Software Technologies — Ada Europe 2017, Springer-Verlag Lecture Notes in Computer Science, Number 10300.